



OM-4409

206 941N

October 2004

Processes



Stick (SMAW) Welding



MIG (GMAW) Welding



Flux Cored (FCAW) Welding



TIG (GTAW) Welding



Air Carbon Arc (CAC-A)
Cutting and Gouging

With Optional Equipment:




Battery Charging

Description




Engine Driven Welding Generator And
Air Compressor

Big Blue[®] Air Pak



OWNER'S MANUAL



Visit our website at

www.MillerWelds.com

From Miller to You

Thank you and congratulations on choosing Miller. Now you can get the job done and get it done right. We know you don't have time to do it any other way.

That's why when Niels Miller first started building arc welders in 1929, he made sure his products offered long-lasting value and superior quality. Like you, his customers couldn't afford anything less. Miller products had to be more than the best they could be. They had to be the best you could buy.

Today, the people that build and sell Miller products continue the tradition. They're just as committed to providing equipment and service that meets the high standards of quality and value established in 1929.

This Owner's Manual is designed to help you get the most out of your Miller products. Please take time to read the Safety precautions. They will help you protect yourself against potential hazards on the worksite.



Miller is the first welding equipment manufacturer in the U.S.A. to be registered to the ISO 9001:2000 Quality System Standard.

We've made installation and operation quick and easy. With Miller you can count on years of reliable service with proper maintenance. And if for some reason the unit needs repair, there's a Troubleshooting section that will help you figure out what the problem is. The parts list will then help you to decide the exact part you may need to fix the problem. Warranty and service information for your particular model are also provided.



Miller Electric manufactures a full line of welders and welding related equipment. For information on other quality Miller products, contact your local Miller distributor to receive the latest full line catalog or individual catalog sheets. **To locate your nearest distributor or service agency call 1-800-4-A-Miller, or visit us at www.MillerWelds.com on the web.**



Working as hard as you do – every power source from Miller is backed by the most hassle-free warranty in the business.



TABLE OF CONTENTS

SECTION 1 – SAFETY PRECAUTIONS – READ BEFORE USING	1
1-1. Symbol Usage	1
1-2. Arc Welding Hazards	1
1-3. Engine Hazards	2
1-4. Compressed Air Hazards	3
1-5. Additional Symbols For Installation, Operation, And Maintenance	3
1-6. California Proposition 65 Warnings	4
1-7. Principal Safety Standards	4
1-8. EMF Information	4
SECTION 2 – CONSIGNES DE SÉCURITÉ – LIRE AVANT UTILISATION	5
2-1. Signification des symboles	5
2-2. Dangers relatifs au soudage à l'arc	5
2-3. Dangers existant en relation avec le moteur	6
2-4. Dangers liés à l'air comprimé	7
2-5. Dangers supplémentaires en relation avec l'installation, le fonctionnement et la maintenance	7
2-6. Principales normes de sécurité	8
2-7. Information sur les champs électromagnétiques	8
SECTION 3 – DEFINITIONS	9
3-1. Symbols And Definitions	9
SECTION 4 – SPECIFICATIONS	10
4-1. Weld, Power, And Engine Specifications	10
4-2. Air Compressor Specifications	10
4-3. Sound Level Table	10
4-4. Dimensions, Weights, And Operating Angles	11
4-5. Stick And MIG Volt-Ampere Curves	12
4-6. TIG Volt-Ampere Curves	13
4-7. Fuel Consumption	14
4-8. Duty Cycle And Overheating	14
4-9. Generator AC Power Curve	15
4-10. Optional 3-Phase Generator Power Curves	16
4-11. Air Compressor Output Curve	17
4-12. Optional Battery Charging Output Curve	17
4-13. Manufacturing Rating Label	18
SECTION 5 – INSTALLATION	19
5-1. Installing Welding Generator	19
5-2. Mounting Welding Generator	20
5-3. Installing Optional Spark Arrestor Muffler	21
5-4. Activating The Dry Charge Battery (If Applicable)	22
5-5. Connecting The Battery	23
5-6. Using The Optional Battery Disconnect Switch	23
5-7. Engine/Compressor Prestart Checks	24
5-8. Connecting To Weld Output Terminals	25
5-9. Selecting Weld Cable Sizes*	26
5-10. Connecting To Remote 14 Receptacle RC14	27
5-11. Connecting To The Air Compressor	28
SECTION 6 – OPERATING THE WELDING GENERATOR	30
6-1. Controls (See Section 6-2)	30
6-2. Description Of Controls (See Section 6-1)	31
6-3. Process/Contactor Switch	32
6-4. Using Remote Voltage/Amperage Control	33

TABLE OF CONTENTS

SECTION 7 – OPERATING AUXILIARY EQUIPMENT	34
7-1. 120 Volt And 240 Volt Receptacles	34
7-2. Connecting To Optional AC Power Plant	35
7-3. Optional Generator Power Receptacles	36
SECTION 8 – OPERATING OPTIONAL BATTERY CHARGER	37
8-1. Battery Charge Controls	37
8-2. Determining Battery Charging Current	37
8-3. Battery Charge Cable Connections	38
8-4. Battery Charging Procedure	39
8-5. Jump Starting Procedure	40
SECTION 9 – ENGINE/GENERATOR MAINTENANCE	41
9-1. Engine Maintenance Label	41
9-2. Routine Engine/Generator Maintenance	42
9-3. Servicing Engine Air Cleaner	44
9-4. Inspecting/Cleaning Optional Spark Arrestor Muffler	45
9-5. Adjusting Engine Speed	46
9-6. Servicing Engine Fuel And Lubrication Systems	47
9-7. Engine/Generator Overload Protection	48
SECTION 10 – AIR COMPRESSOR MAINTENANCE	49
10-1. Air Compressor Maintenance Label	49
10-2. Routine Air Compressor Maintenance	50
10-3. Servicing Compressor Air Cleaner	51
10-4. Compressor Overload Protection	52
10-5. Servicing Air Compressor	53
10-6. Adjusting Compressor Air Pressure	54
SECTION 11 – TROUBLESHOOTING	55
11-1. Troubleshooting Tables	55
SECTION 12 – AIR COMPRESSOR DIAGRAM	59
SECTION 13 – ELECTRICAL DIAGRAM	60
SECTION 14 – RUN-IN PROCEDURE	62
14-1. Wetstacking	62
14-2. Run-In Procedure Using Load Bank	63
14-3. Run-In Procedure Using Resistance Grid	64
SECTION 15 – AIR COMPRESSOR TABLES	65
15-1. Flow Of Free Air (CFM) Through Orifices Of Various Diameters	65
15-2. Approximate Air Consumption (Cubic Feet) To Operate Pneumatic Equipment At 70-90 P.S.I.G.	66
SECTION 16 – GENERATOR POWER GUIDELINES	67
SECTION 17 – SELECTING AND PREPARING TUNGSTEN ELECTRODE	74
17-1. Selecting Tungsten Electrode	74
17-2. Preparing Tungsten For AC Or DC Electrode Positive (DCEP) Welding	75
17-3. Preparing Tungsten For DC Electrode Negative (DCEN) Welding	75
SECTION 18 – GUIDELINES FOR TIG WELDING (GTAW)	76
18-1. Positioning The Torch	76
18-2. Torch Movement During Welding	76
18-3. Positioning Torch Tungsten For Various Weld Joints	77
SECTION 19 – PARTS LIST	78
OPTIONS AND ACCESSORIES	
WARRANTY	

SECTION 1 – SAFETY PRECAUTIONS – READ BEFORE USING

rom_nd_10/02

▲ **Warning: Protect yourself and others from injury — read and follow these precautions.**

1-1. Symbol Usage



Means Warning! Watch Out! There are possible hazards with this procedure! The possible hazards are shown in the adjoining symbols.

▲ Marks a special safety message.

☞ Means "Note"; not safety related.



This group of symbols means Warning! Watch Out! possible ELECTRIC SHOCK, MOVING PARTS, and HOT PARTS hazards. Consult symbols and related instructions below for necessary actions to avoid the hazards.

1-2. Arc Welding Hazards

▲ The symbols shown below are used throughout this manual to call attention to and identify possible hazards. When you see the symbol, watch out, and follow the related instructions to avoid the hazard. The safety information given below is only a summary of the more complete safety information found in the Safety Standards listed in Section 1-7. Read and follow all Safety Standards.

▲ Only qualified persons should install, operate, maintain, and repair this unit.

▲ During operation, keep everybody, especially children, away.



ELECTRIC SHOCK can kill.


Touching live electrical parts can cause fatal shocks or severe burns. The electrode and work circuit is electrically live whenever the output is on. The input power circuit and machine internal circuits are also live when power is on. In semiautomatic or automatic wire welding, the wire, wire reel, drive roll housing, and all metal parts touching the welding wire are electrically live. Incorrectly installed or improperly grounded equipment is a hazard.

- Do not touch live electrical parts.
- Wear dry, hole-free insulating gloves and body protection.
- Insulate yourself from work and ground using dry insulating mats or covers big enough to prevent any physical contact with the work or ground.
- Do not use AC output in damp areas, if movement is confined, or if there is a danger of falling.
- Use AC output ONLY if required for the welding process.
- If AC output is required, use remote output control if present on unit.
- Additional safety precautions are required when any of the following electrically hazardous conditions are present: in damp locations or while wearing wet clothing; on metal structures such as floors, gratings, or scaffolds; when in cramped positions such as sitting, kneeling, or lying; or when there is a high risk of unavoidable or accidental contact with the workpiece or ground. For these conditions, use the following equipment in order presented: 1) a semiautomatic DC constant voltage (wire) welder, 2) a DC manual (stick) welder, or 3) an AC welder with reduced open-circuit voltage. In most situations, use of a DC, constant voltage wire welder is recommended. And, do not work alone!
- Disconnect input power or stop engine before installing or servicing this equipment. Lockout/tagout input power according to OSHA 29 CFR 1910.147 (see Safety Standards).
- Properly install and ground this equipment according to its Owner's Manual and national, state, and local codes.
- Always verify the supply ground — check and be sure that input power cord ground wire is properly connected to ground terminal in disconnect box or that cord plug is connected to a properly grounded receptacle outlet.
- When making input connections, attach proper grounding conductor first — double-check connections.
- Frequently inspect input power cord for damage or bare wiring — replace cord immediately if damaged — bare wiring can kill.
- Turn off all equipment when not in use.
- Do not use worn, damaged, undersized, or poorly spliced cables.
- Do not drape cables over your body.
- If earth grounding of the workpiece is required, ground it directly with a separate cable.
- Do not touch electrode if you are in contact with the work, ground, or another electrode from a different machine.

- Use only well-maintained equipment. Repair or replace damaged parts at once. Maintain unit according to manual.
- Wear a safety harness if working above floor level.
- Keep all panels and covers securely in place.
- Clamp work cable with good metal-to-metal contact to workpiece or worktable as near the weld as practical.
- Insulate work clamp when not connected to workpiece to prevent contact with any metal object.
- Do not connect more than one electrode or work cable to any single weld output terminal.

SIGNIFICANT DC VOLTAGE exists in inverters after stopping engine.

- Stop engine on inverter and discharge input capacitors according to instructions in Maintenance Section before touching any parts.



FUMES AND GASES can be hazardous.


Welding produces fumes and gases. Breathing these fumes and gases can be hazardous to your health.

- Keep your head out of the fumes. Do not breathe the fumes.
- If inside, ventilate the area and/or use exhaust at the arc to remove welding fumes and gases.
- If ventilation is poor, use an approved air-supplied respirator.
- Read the Material Safety Data Sheets (MSDSs) and the manufacturer's instructions for metals, consumables, coatings, cleaners, and degreasers.
- Work in a confined space only if it is well ventilated, or while wearing an air-supplied respirator. Always have a trained watchperson nearby. Welding fumes and gases can displace air and lower the oxygen level causing injury or death. Be sure the breathing air is safe.
- Do not weld in locations near degreasing, cleaning, or spraying operations. The heat and rays of the arc can react with vapors to form highly toxic and irritating gases.
- Do not weld on coated metals, such as galvanized, lead, or cadmium plated steel, unless the coating is removed from the weld area, the area is well ventilated, and if necessary, while wearing an air-supplied respirator. The coatings and any metals containing these elements can give off toxic fumes if welded.



BUILDUP OF GAS can injure or kill.

- Shut off shielding gas supply when not in use.
- Always ventilate confined spaces or use approved air-supplied respirator.



ARC RAYS can burn eyes and skin.

Arc rays from the welding process produce intense visible and invisible (ultraviolet and infrared) rays that can burn eyes and skin. Sparks fly off from the weld.


- Wear a welding helmet fitted with a proper shade of filter to protect your face and eyes from arc rays and sparks when welding or watching (see ANSI Z49.1 and Z87.1 listed in Safety Standards).
- Wear approved safety glasses with side shields under your helmet.
- Use protective screens or barriers to protect others from flash and glare; warn others not to watch the arc.
- Wear protective clothing made from durable, flame-resistant material (wool and leather) and foot protection.



WELDING can cause fire or explosion.

Welding on closed containers, such as tanks, drums, or pipes, can cause them to blow up. Sparks can fly off from the welding arc. The flying sparks, hot workpiece, and hot equipment can cause fires and burns. Accidental contact of electrode to metal objects can cause sparks, explosion, overheating, or fire. Check and be sure the area is safe before doing any welding.

- Protect yourself and others from flying sparks and hot metal.
- Do not weld where flying sparks can strike flammable material.
- Remove all flammables within 35 ft (10.7 m) of the welding arc. If this is not possible, tightly cover them with approved covers.
- Be alert that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas.
- Watch for fire, and keep a fire extinguisher nearby.
- Be aware that welding on a ceiling, floor, bulkhead, or partition can cause fire on the hidden side.
- Do not weld on closed containers such as tanks, drums, or pipes, unless they are properly prepared according to AWS F4.1 (see Safety Standards).
- Connect work cable to the work as close to the welding area as practical to prevent welding current from traveling long, possibly unknown paths and causing electric shock and fire hazards.
- Do not use welder to thaw frozen pipes.
- Remove stick electrode from holder or cut off welding wire at contact tip when not in use.
- Wear oil-free protective garments such as leather gloves, heavy shirt, cuffless trousers, high shoes, and a cap.
- Remove any combustibles, such as a butane lighter or matches, from your person before doing any welding.
- Follow requirements in OSHA 1910.252 (a) (2) (iv) and NFPA 51B for hot work and have a fire watcher and extinguisher nearby.




FLYING METAL can injure eyes.

- Welding, chipping, wire brushing, and grinding cause sparks and flying metal. As welds cool, they can throw off slag.
- Wear approved safety glasses with side shields even under your welding helmet.



HOT PARTS can cause severe burns.

- Allow cooling period before maintaining.
- Wear protective gloves and clothing when working on a hot engine.
- Do not touch hot engine parts or just-welded parts bare-handed.



NOISE can damage hearing.


Noise from some processes or equipment can damage hearing.

- Wear approved ear protection if noise level is high.



MAGNETIC FIELDS can affect pacemakers.

- Pacemaker wearers keep away.
- Wearers should consult their doctor before going near arc welding, gouging, or spot welding operations.



CYLINDERS can explode if damaged.

Shielding gas cylinders contain gas under high pressure. If damaged, a cylinder can explode. Since gas cylinders are normally part of the welding process, be sure to treat them carefully.

- Protect compressed gas cylinders from excessive heat, mechanical shocks, slag, open flames, sparks, and arcs.
- Install cylinders in an upright position by securing to a stationary support or cylinder rack to prevent falling or tipping.
- Keep cylinders away from any welding or other electrical circuits.
- Never drape a welding torch over a gas cylinder.
- Never allow a welding electrode to touch any cylinder.
- Never weld on a pressurized cylinder — explosion will result.
- Use only correct shielding gas cylinders, regulators, hoses, and fittings designed for the specific application; maintain them and associated parts in good condition.
- Turn face away from valve outlet when opening cylinder valve.
- Keep protective cap in place over valve except when cylinder is in use or connected for use.
- Read and follow instructions on compressed gas cylinders, associated equipment, and CGA publication P-1 listed in Safety Standards.

1-3. Engine Hazards



BATTERY EXPLOSION can BLIND.

- Always wear a face shield, rubber gloves, and protective clothing when working on a battery.
- Stop engine before disconnecting or connecting battery cables or servicing battery.
- Do not allow tools to cause sparks when working on a battery.
- Do not use welder to charge batteries or jump start vehicles.
- Observe correct polarity (+ and -) on batteries.
- Disconnect negative (-) cable first and connect it last.



FUEL can cause fire or explosion.

- Stop engine and let it cool off before checking or adding fuel.
- Do not add fuel while smoking or if unit is near any sparks or open flames.
- Do not overfill tank — allow room for fuel to expand.
- Do not spill fuel. If fuel is spilled, clean up before starting engine.
- Dispose of rags in a fireproof container.
- Always keep nozzle in contact with tank when fueling.



MOVING PARTS can cause injury.


- Keep away from fans, belts, and rotors.
- Keep all doors, panels, covers, and guards closed and securely in place.
- Stop engine before installing or connecting unit.
- Have only qualified people remove guards or covers for maintenance and troubleshooting as necessary.
- To prevent accidental starting during servicing, disconnect negative (-) battery cable from battery.
- Keep hands, hair, loose clothing, and tools away from moving parts.
- Reinstall panels or guards and close doors when servicing is finished and before starting engine.
- Before working on generator, remove spark plugs or injectors to keep engine from kicking back or starting.
- Block flywheel so that it will not turn while working on generator components.

**STEAM AND HOT COOLANT can burn.**


- If possible, check coolant level when engine is cold to avoid scalding.
- Always check coolant level at overflow tank, if present on unit, instead of radiator (unless told otherwise in maintenance section or engine manual).
- If the engine is warm, checking is needed, and there is no overflow tank, follow the next two statements.
- Wear safety glasses and gloves and put a rag over radiator cap.
- Turn cap slightly and let pressure escape slowly before completely removing cap.

**ENGINE EXHAUST GASES can kill.**

- Use equipment outside in open, well-ventilated areas.
- If used in a closed area, vent engine exhaust outside and away from any building air intakes.

**BATTERY ACID can BURN SKIN and EYES.**

- Do not tip battery.
- Replace damaged battery.
- Flush eyes and skin immediately with water.

**ENGINE HEAT can cause fire.**


- Do not locate unit on, over, or near combustible surfaces or flammables.
- Keep exhaust and exhaust pipes way from flammables.

**EXHAUST SPARKS can cause fire.**

- Do not let engine exhaust sparks cause fire.
- Use approved engine exhaust spark arrestor in required areas — see applicable codes.

1-4. Compressed Air Hazards**BREATHING COMPRESSED AIR can cause serious injury or death.**

- Do not use compressed air for breathing.
- Use only for cutting, gouging, and tools.

**COMPRESSED AIR can cause injury.**

- Wear approved safety goggles.
- Do not direct air stream toward self or others.

**TRAPPED AIR PRESSURE AND WHIPPING HOSES can cause injury.**


- Release air pressure from tools and system before servicing, adding or changing attachments, or opening compressor oil drain or oil fill cap.

**HOT METAL from air arc cutting and gouging can cause fire or explosion.**

- Do not cut or gouge near flammables.
- Watch for fire; keep extinguisher nearby.

**HOT PARTS can cause burns and injury.**


- Do not touch hot compressor or air system parts.
- Let system cool down before touching or servicing.

**READ INSTRUCTIONS.**


- Read Owner's Manual before using or servicing unit.
- Stop engine and release air pressure before servicing.

1-5. Additional Symbols For Installation, Operation, And Maintenance**FALLING UNIT can cause injury.**


- Use lifting eye to lift unit only, NOT running gear, gas cylinders, trailer, or any other accessories.
- Use equipment of adequate capacity to lift and support unit.
- If using lift forks to move unit, be sure forks are long enough to extend beyond opposite side of unit.

**OVERUSE can cause OVERHEATING.**


- Allow cooling period; follow rated duty cycle.
- Reduce current or reduce duty cycle before starting to weld again.
- Do not block or filter airflow to unit.

**OVERHEATING can damage motors.**

- Turn off or unplug equipment before starting or stopping engine.
- Do not let low voltage and frequency caused by low engine speed damage electric motors.
- Do not connect 50 or 60 Hertz motors to the 100 Hertz receptacle where applicable.

**STATIC (ESD) can damage PC boards.**


- Put on grounded wrist strap BEFORE handling boards or parts.
- Use proper static-proof bags and boxes to store, move, or ship PC boards.

**FLYING SPARKS can cause injury.**

- Wear a face shield to protect eyes and face.
- Shape tungsten electrode only on grinder with proper guards in a safe location wearing proper face, hand, and body protection.
- Sparks can cause fires — keep flammables away.


**TILTING OF TRAILER can cause injury.**

- Use tongue jack or blocks to support weight.
- Properly install welding generator onto trailer according to instructions supplied with trailer.




READ INSTRUCTIONS.

- Use only genuine MILLER/Hobart replacement parts.
- Perform engine and air compressor (if applicable) maintenance and service according to this manual and the engine/air compressor (if applicable) manuals.



H.F. RADIATION can cause interference.

- High-frequency (H.F.) can interfere with radio navigation, safety services, computers, and communications equipment.
- Have only qualified persons familiar with electronic equipment perform this installation.
- The user is responsible for having a qualified electrician promptly correct any interference problem resulting from the installation.
- If notified by the FCC about interference, stop using the equipment at once.
- Have the installation regularly checked and maintained.
- Keep high-frequency source doors and panels tightly shut, keep spark gaps at correct setting, and use grounding and shielding to minimize the possibility of interference.



ARC WELDING can cause interference.

- Electromagnetic energy can interfere with sensitive electronic equipment such as microprocessors, computers, and computer-driven equipment such as robots.
- Be sure all equipment in the welding area is electromagnetically compatible.
- To reduce possible interference, keep weld cables as short as possible, close together, and down low, such as on the floor.
- Locate welding operation 100 meters from any sensitive electronic equipment.
- Be sure this welding machine is installed and grounded according to this manual.
- If interference still occurs, the user must take extra measures such as moving the welding machine, using shielded cables, using line filters, or shielding the work area.

1-6. California Proposition 65 Warnings

- ▲ **Welding or cutting equipment produces fumes or gases which contain chemicals known to the State of California to cause birth defects and, in some cases, cancer. (California Health & Safety Code Section 25249.5 et seq.)**
- ▲ **Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.**

For Gasoline Engines:

- ▲ **Engine exhaust contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.**

For Diesel Engines:

- ▲ **Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.**

1-7. Principal Safety Standards

Safety in Welding, Cutting, and Allied Processes, ANSI Standard Z49.1, from American Welding Society, 550 N.W. LeJeune Rd, Miami FL 33126 (phone: 305-443-9353, website: www.aws.org).

Recommended Safe Practices for the Preparation for Welding and Cutting of Containers and Piping, American Welding Society Standard AWS F4.1, from American Welding Society, 550 N.W. LeJeune Rd, Miami, FL 33126 (phone: 305-443-9353, website: www.aws.org).

National Electrical Code, NFPA Standard 70, from National Fire Protection Association, P.O. Box 9101, 1 Battery March Park, Quincy, MA 02269-9101 (phone: 617-770-3000, website: www.nfpa.org and www.sparky.org).

Safe Handling of Compressed Gases in Cylinders, CGA Pamphlet P-1, from Compressed Gas Association, 1735 Jefferson Davis Highway, Suite 1004, Arlington, VA 22202-4102 (phone: 703-412-0900, website: www.cganet.com).

Code for Safety in Welding and Cutting, CSA Standard W117.2, from Canadian Standards Association, Standards Sales, 178 Rexdale Bou-

levard, Rexdale, Ontario, Canada M9W 1R3 (phone: 800-463-6727 or in Toronto 416-747-4044, website: www.csa-international.org).

Practice For Occupational And Educational Eye And Face Protection, ANSI Standard Z87.1, from American National Standards Institute, 11 West 42nd Street, New York, NY 10036-8002 (phone: 212-642-4900, website: www.ansi.org).

Standard for Fire Prevention During Welding, Cutting, and Other Hot Work, NFPA Standard 51B, from National Fire Protection Association, P.O. Box 9101, 1 Battery March Park, Quincy, MA 02269-9101 (phone: 617-770-3000, website: www.nfpa.org and www.sparky.org).

OSHA, Occupational Safety and Health Standards for General Industry, Title 29, Code of Federal Regulations (CFR), Part 1910, Subpart Q, and Part 1926, Subpart J, from U.S. Government Printing Office, Superintendent of Documents, P.O. Box 371954, Pittsburgh, PA 15250 (there are 10 Regional Offices—phone for Region 5, Chicago, is 312-353-2220, website: www.osha.gov).

1-8. EMF Information

Considerations About Welding And The Effects Of Low Frequency Electric And Magnetic Fields

Welding current, as it flows through welding cables, will cause electromagnetic fields. There has been and still is some concern about such fields. However, after examining more than 500 studies spanning 17 years of research, a special blue ribbon committee of the National Research Council concluded that: "The body of evidence, in the committee's judgment, has not demonstrated that exposure to power-frequency electric and magnetic fields is a human-health hazard." However, studies are still going forth and evidence continues to be examined. Until the final conclusions of the research are reached, you may wish to minimize your exposure to electromagnetic fields when welding or cutting.

To reduce magnetic fields in the workplace, use the following procedures:

1. Keep cables close together by twisting or taping them.
2. Arrange cables to one side and away from the operator.
3. Do not coil or drape cables around your body.
4. Keep welding power source and cables as far away from operator as practical.
5. Connect work clamp to workpiece as close to the weld as possible.

About Pacemakers:

Pacemaker wearers consult your doctor first. If cleared by your doctor, then following the above procedures is recommended.

SECTION 2 – CONSIGNES DE SÉCURITÉ – LIRE AVANT UTILISATION

rom_fre 8/03

▲ Avertissement: Protégez vous et les autres des blessures – lisez et suivez ces précautions.

2-1. Signification des symboles



Signifie Mise en garde ! Soyez vigilant ! Cette procédure présente des risques de danger ! Ceux-ci sont identifiés par des symboles adjacents aux directives.

▲ Identifie un message de sécurité particulier.

 Signifie NOTA ; n'est pas relatif à la sécurité.



Ce groupe de symboles signifie Mise en garde ! Soyez vigilant ! Il y a des risques de danger reliés

aux CHOCs ÉLECTRIQUES, aux PIÈCES EN MOUVEMENT et aux PIÈCES CHAUDES. Reportez-vous aux symboles et aux directives ci-dessous afin de connaître les mesures à prendre pour éviter tout danger.

2-2. Dangers relatifs au soudage à l'arc

▲ Les symboles présentés ci-après sont utilisés tout au long du présent manuel pour attirer votre attention et identifier les risques de danger. Lorsque vous voyez un symbole, soyez vigilant et suivez les directives mentionnées afin d'éviter tout danger. Les consignes de sécurité présentées ci-après ne font que résumer l'information contenue dans les normes de sécurité énumérées à la section 2-6. Veuillez lire et respecter toutes ces normes de sécurité.

▲ L'installation, l'utilisation, l'entretien et les réparations ne doivent être confiés qu'à des personnes qualifiées.

▲ Au cours de l'utilisation, tenir toute personne à l'écart et plus particulièrement les enfants.



UN CHOC ÉLECTRIQUE peut tuer.


Un simple contact avec des pièces électriques peut provoquer une électrocution ou des blessures graves. L'électrode et le circuit de soudage sont sous tension dès que l'appareil est sur ON. Le circuit d'entrée et les circuits internes de l'appareil sont également sous tension à ce moment-là. En soudage semi-automatique ou automatique, le fil, le dévidoir, le logement des galets d'entraînement et les pièces métalliques en contact avec le fil de soudage sont sous tension. Des matériels mal installés ou mal mis à la terre présentent un danger.

- Ne jamais toucher les pièces électriques sous tension.
- Porter des gants et des vêtements de protection secs ne comportant pas de trous.
- S'isoler de la pièce et de la terre au moyen de tapis ou d'autres moyens isolants suffisamment grands pour empêcher le contact physique éventuel avec la pièce ou la terre.
- Ne pas se servir de source électrique à courant électrique dans les zones humides, dans les endroits confinés ou là où on risque de tomber.
- Se servir d'une source électrique à courant électrique UNIQUEMENT si le procédé de soudage le demande.
- Si l'utilisation d'une source électrique à courant électrique s'avère nécessaire, se servir de la fonction de télécommande si l'appareil en est équipé.
- Des précautions de sécurité supplémentaires sont requises dans des environnements à risque comme: les endroits humides ou lorsque l'on porte des vêtements mouillés; sur des structures métalliques au sol, grillages et échafaudages; dans des positions assises, à genoux et allongées; ou quand il y a un risque important de contact accidentel avec la pièce ou le sol. Dans ces cas utiliser les appareils suivants dans l'ordre de préférence: 1) un poste à souder DC semi-automatique de type CV (MIG/MAG), 2) un poste à souder manuel (électrode enrobée) DC, 3) un poste à souder manuel AC avec tension à vide réduite. Dans la plupart des cas, un poste courant continu de type CV est recommandé. Et, ne pas travailler seul!
- Couper l'alimentation ou arrêter le moteur avant de procéder à l'installation, à la réparation ou à l'entretien de l'appareil. Déverrouiller l'alimentation selon la norme OSHA 29 CFR 1910.147 (voir normes de sécurité).
- Installer et mettre à la terre correctement cet appareil conformément à son manuel d'utilisation et aux codes nationaux, provinciaux et municipaux.
- Toujours vérifier la terre du cordon d'alimentation – Vérifier et s'assurer que le fil de terre du cordon d'alimentation est bien raccordé à la borne de terre du sectionneur ou que la fiche du cordon est raccordée à une prise correctement mise à la terre.

- En effectuant les raccordements d'entrée fixer d'abord le conducteur de mise à la terre approprié et contre-vérifier les connexions.
- Vérifier fréquemment le cordon d'alimentation pour voir s'il n'est pas endommagé ou dénudé – remplacer le cordon immédiatement s'il est endommagé – un câble dénudé peut provoquer une électrocution.
- Mettre l'appareil hors tension quand on ne l'utilise pas.
- Ne pas utiliser des câbles usés, endommagés, de grosseur insuffisante ou mal épluchés.
- Ne pas enrouler les câbles autour du corps.
- Si la pièce soudée doit être mise à la terre, le faire directement avec un câble distinct – ne pas utiliser le connecteur de pièce ou le câble de retour.
- Ne pas toucher l'électrode quand on est en contact avec la pièce, la terre ou une électrode provenant d'une autre machine.
- N'utiliser qu'un matériel en bon état. Réparer ou remplacer sur-le-champ les pièces endommagées. Entretenir l'appareil conformément à ce manuel.
- Porter un harnais de sécurité quand on travaille en hauteur.
- Maintenir solidement en place tous les panneaux et capots.
- Fixer le câble de retour de façon à obtenir un bon contact métal-métal avec la pièce à souder ou la table de travail, le plus près possible de la soudure.
- Isoler la pince de masse quand pas mis à la pièce pour éviter le contact avec tout objet métallique.

Une tension DC importante subsiste à l'intérieur des onduleurs après avoir coupé l'alimentation.

- Couper l'alimentation du poste et décharger les condensateurs d'entrée comme indiqué dans la Section Maintenance avant de toucher des composants.



LES FUMÉES ET LES GAZ peuvent être dangereux.

Le soudage génère des fumées et des gaz. Leur inhalation peut être dangereuse pour votre santé.

- Eloigner votre tête des fumées. Ne pas respirer les fumées.
- À l'intérieur, ventiler la zone et/ou utiliser un échappement au niveau de l'arc pour l'évacuation des fumées et des gaz de soudage.
- Si la ventilation est insuffisante, utiliser un respirateur à alimentation d'air homologué.
- Lire les spécifications de sécurité des matériaux (MSDSs) et les instructions du fabricant concernant les métaux, les consommables, les revêtements, les nettoyants et les dégraissants.
- Travailler dans un espace fermé seulement s'il est bien ventilé ou en portant un respirateur à alimentation d'air. Demander toujours à un surveillant dûment formé de se tenir à proximité. Des fumées et des gaz de soudage peuvent déplacer l'air et abaisser le niveau d'oxygène provoquant des blessures ou des accidents mortels. S'assurer que l'air de respiration ne présente aucun danger.
- Ne pas souder dans des endroits situés à proximité d'opérations de dégraissage, de nettoyage ou de pulvérisation. La chaleur et les rayons de l'arc peuvent réagir en présence de vapeurs et former des gaz hautement toxiques et irritants.
- Ne pas souder des métaux munis d'un revêtement, tels que l'acier galvanisé, plaqué en plomb ou au cadmium à moins que le revêtement n'ait été enlevé dans la zone de soudure, que l'endroit soit bien ventilé, et si nécessaire, en portant un respirateur à alimentation d'air. Les revêtements et tous les métaux renfermant ces éléments peuvent dégager des fumées toxiques en cas de soudage.



LES ACCUMULATIONS DE GAZ risquent de provoquer des blessures ou même la mort.

- Fermer l'alimentation du gaz protecteur en cas de non utilisation.
- Veiller toujours à bien aérer les espaces confinés ou se servir d'un respirateur d'adduction d'air homologué.



LES RAYONS DE L'ARC peuvent provoquer des brûlures dans les yeux et sur la peau.

Le rayonnement de l'arc du procédé de soudage génère des rayons visibles et invisibles intenses (ultraviolets et infrarouges) susceptibles de provoquer des brûlures dans les yeux et sur la peau. Des étincelles sont projetées pendant le soudage.

- Porter un casque de soudage muni d'un écran de filtre approprié pour protéger votre visage et vos yeux pendant le soudage ou pour regarder (voir ANSI Z49.1 et Z87.1 énuméré dans les normes de sécurité).
- Porter des protections approuvés pour les oreilles si le niveau sonore est trop élevé.
- Utiliser des écrans ou des barrières pour protéger des tiers de l'éclair et de l'éblouissement; demander aux autres personnes de ne pas regarder l'arc.
- Porter des vêtements de protection constitué dans une matière durable, résistant au feu (laine ou cuir) et une protection des pieds.



LE SOUDAGE peut provoquer un incendie ou une explosion.

Le soudage effectué sur des conteneurs fermés tels que des réservoirs, tambours ou des conduites peut provoquer leur éclatement. Des étincelles peuvent être projetées de l'arc de soudure. La projection d'étincelles, des pièces chaudes et des équipements chauds peut provoquer des incendies et des brûlures. Le contact accidentel de l'électrode avec des objets métalliques peut provoquer des étincelles, une explosion, un surchauffement ou un incendie. Avant de commencer le soudage, vérifier et s'assurer que l'endroit ne présente pas de danger.

- Se protéger et d'autres personnes de la projection d'étincelles et de métal chaud.
- Ne pas souder dans un endroit là où des étincelles peuvent tomber sur des substances inflammables.
- Déplacer toutes les substances inflammables à une distance de 10,7 m de l'arc de soudage. En cas d'impossibilité les recouvrir soigneusement avec des protections homologués.
- Des étincelles et des matériaux chauds du soudage peuvent facilement passer dans d'autres zones en traversant de petites fissures et des ouvertures.
- Surveiller tout déclenchement d'incendie et tenir un extincteur à proximité.
- Le soudage effectué sur un plafond, plancher, paroi ou séparation peut déclencher un incendie de l'autre côté.
- Ne pas effectuer le soudage sur des conteneurs fermés tels que des réservoirs, tambours, ou conduites, à moins qu'ils n'aient été préparés correctement conformément à AWS F4.1 (voir les normes de sécurité).
- Brancher le câble sur la pièce la plus près possible de la zone de soudage pour éviter le transport du courant sur une longue distance par des chemins inconnus éventuels en provoquant des risques d'électrocution et d'incendie.
- Ne pas utiliser le poste de soudage pour dégeler des conduites gelées.
- En cas de non utilisation, enlever la baguette d'électrode du porte-électrode ou couper le fil à la pointe de contact.
- Porter des vêtements de protection dépourvus d'huile tels que des gants en cuir, une chemise en matériau lourd, des pantalons sans revers, des chaussures hautes et un couvre chef.
- Avant de souder, retirer toute substance combustible de vos poches telles qu'un allumeur au butane ou des allumettes.


2-3. Dangers existant en relation avec le moteur



LES ACCUMULATIONS DE GAZ risquent de provoquer des blessures ou même la mort.

- Fermer l'alimentation du gaz protecteur en cas de non utilisation.
- Veiller toujours à bien aérer les espaces confinés ou se servir d'un respirateur d'adduction d'air homologué.

- Suivre les recommandations dans OSHA 1910.252(a)(2)(iv) et NFPA 51B pour les travaux à chaud et avoir de la surveillance et un extincteur à proximité.




DES PARTICULES VOLANTES peuvent blesser les yeux.

- Le soudage, l'écaillage, le passage de la pièce à la brosse en fil de fer, et le meulage génèrent des étincelles et des particules métalliques volantes. Pendant la période de refroidissement des soudures, elles risquent de projeter du laitier.
- Porter des lunettes de sécurité avec écrans latéraux ou un écran facial.



DES PIÈCES CHAUDES peuvent provoquer des brûlures graves.


- Prévoir une période de refroidissement avant d'effectuer des travaux d'entretien.
- Porter des gants et des vêtements de protection pour travailler sur un moteur chaud.
- Ne pas toucher à mains nues les parties chaudes du moteur ni les pièces récemment soudées.



LE BRUIT peut affecter l'ouïe.


Le bruit des processus et des équipements peut affecter l'ouïe.

- Porter des protections approuvés pour les oreilles si le niveau sonore est trop élevé.



LES CHAMPS MAGNÉTIQUES peuvent affecter les stimulateurs cardiaques.

- Porteurs de stimulateur cardiaque, restez à distance.
- Les porteurs d'un stimulateur cardiaque doivent d'abord consulter leur médecin avant de s'approcher des opérations de soudage à l'arc, de gougeage ou de soudage par points.



Si des BOUTEILLES sont endommagées, elles pourront exploser.


Des bouteilles de gaz protecteur contiennent du gaz sous haute pression. Si une bouteille est endommagée, elle peut exploser. Du fait que les bouteilles de gaz font normalement partie du procédé de soudage, les manipuler avec précaution.

- Protéger les bouteilles de gaz comprimé d'une chaleur excessive, des chocs mécaniques, du laitier, des flammes ouvertes, des étincelles et des arcs.
- Placer les bouteilles debout en les fixant dans un support stationnaire ou dans un porte-bouteilles pour les empêcher de tomber ou de se renverser.
- Tenir les bouteilles éloignées des circuits de soudage ou autres circuits électriques.
- Ne jamais placer une torche de soudage sur une bouteille à gaz.
- Une électrode de soudage ne doit jamais entrer en contact avec une bouteille.
- Ne jamais souder une bouteille pressurisée – risque d'explosion.
- Utiliser seulement des bouteilles de gaz protecteur, régulateurs, tuyaux et raccords convenables pour cette application spécifique; les maintenir ainsi que les éléments associés en bon état.
- Ne pas tenir la tête en face de la sortie en ouvrant la soupape de la bouteille.
- Maintenir le chapeau de protection sur la soupape, sauf en cas d'utilisation ou de branchement de la bouteille.
- Lire et suivre les instructions concernant les bouteilles de gaz comprimé, les équipements associés et les publication P-1 CGA énumérées dans les normes de sécurité.



L'ACIDE DE LA BATTERIE peut provoquer des brûlures dans les YEUX et sur la PEAU.

- Ne pas renverser la batterie.
- Remplacer une batterie endommagée.
- Rincer immédiatement les yeux et la peau à l'eau.



L'EXPLOSION DE LA BATTERIE peut RENDRE AVEUGLE.

- Toujours porter une protection faciale, des gants en caoutchouc et vêtements de protection lors d'une intervention sur la batterie.

- Arrêter le moteur avant de débrancher ou de brancher les câbles de batterie.
- Eviter de provoquer des étincelles avec les outils en travaillant sur la batterie.
- Ne pas utiliser le poste de soudage pour charger les batteries ou des véhicules de démarrage rapide.
- Observer la polarité correcte (+ et -) sur les batteries.
- Débrancher le câble négatif (-) en premier lieu. Le rebrancher en dernier lieu.



LE CARBURANT MOTEUR peut provoquer un incendie ou une explosion.

- Arrêter le moteur avant de vérifier le niveau de carburant ou de faire le plein.
- Ne pas faire le plein en fumant ou proche d'une source d'étincelles ou d'une flamme nue.

- Ne pas faire le plein de carburant à ras bord; prévoir de l'espace pour son expansion.
- Faire attention de ne pas renverser de carburant. Nettoyer tout carburant renversé avant de faire démarrer le moteur.
- Jeter les chiffons dans un récipient ignifuge.




DES ORGANES MOBILES peuvent provoquer des blessures.

- Ne pas approcher les mains des ventilateurs, courroies et autres pièces en mouvement.
- Maintenir fermés et fixement en place les portes, panneaux, recouvrements et dispositifs de protection.

- Arrêter le moteur avant d'installer ou brancher l'appareil.
- Demander seulement à un personnel qualifié d'enlever les dispositifs de sécurité ou les recouvrements pour effectuer, s'il y a lieu, des travaux d'entretien et de dépannage.

- Pour empêcher tout démarrage accidentel pendant les travaux d'entretien, débrancher le câble négatif (-) de batterie de la borne.
- Ne pas approcher les mains, cheveux, vêtements lâches et outils des organes mobiles.
- Remettre en place les panneaux ou les dispositifs de protection et fermer les portes à la fin des travaux d'entretien et avant de faire démarrer le moteur.
- Avant d'intervenir, déposer les bougies ou injecteurs pour éviter la mise en route accidentelle du moteur.
- Bloquer le volant moteur pour éviter sa rotation lors d'une intervention sur le générateur.



LA VAPEUR ET LE LIQUIDE DE REFROIDISSEMENT CHAUD peuvent provoquer des brûlures.

- Il est préférable de vérifier le liquide de refroidissement une fois le moteur refroidi pour éviter de se brûler.

- Toujours vérifier le niveau de liquide de refroidissement dans le vase d'expansion (si présent), et non dans le radiateur (sauf si précisé autrement dans la section maintenance du manuel du moteur).
- Si le moteur est chaud et que le liquide doit être vérifié, opérer comme suivant :
- Mettre des lunettes de sécurité et des gants, placer un torchon sur le bouchon du radiateur.
- Dévisser le bouchon légèrement et laisser la vapeur s'échapper avant d'enlever le bouchon.



LA CHALEUR DU MOTEUR peut provoquer un incendie.

- Ne pas placer l'appareil sur, au-dessus ou à proximité de surfaces inflammables.
- Tenir à distance les produits inflammables de l'échappement.



LES ÉTINCELLES À L'ÉCHAPPEMENT peuvent provoquer un incendie.


- Empêcher les étincelles d'échappement du moteur de provoquer un incendie.
- Utiliser uniquement un pare-étincelles approuvé – voir codes en vigueur.

2-4. Dangers liés à l'air comprimé




RESPIRER L'AIR COMPRIMÉ peut provoquer des blessures graves ou causer la mort.

- Ne pas utiliser l'air comprimé pour respirer.
- Utiliser l'air comprimé seulement pour le coupage, gougeage et les outils pneumatiques.



L'AIR COMPRIMÉ peut provoquer des blessures.

- Porter des lunettes de sécurité approuvées.
- Ne pas diriger le jet d'air vers d'autres ou soi-même.



L'AIR COMPRIME EMMAGASINE ET DES TUYAUX SOUS PRESSION peuvent provoquer des blessures.

- Relâcher la pression d'air de l'outillage ou du système avant d'effectuer la maintenance, avant de changer ou de rajouter des éléments ou avant d'ouvrir la purge ou le bouchon de remplissage d'huile.




Le METAL CHAUD lors du coupage et gougeage plasma peut provoquer un incendie ou une explosion.

- Ne pas couper ou gouger à proximité de produits inflammables.
- Surveillez et garder un extincteur à proximité.



DES PIÈCES CHAUDES peuvent provoquer des brûlures et blessures.

- Ne pas toucher le compresseur ou d'autres éléments du circuit air comprimé chauds.
- Laisser l'ensemble se refroidir avant de toucher ou d'effectuer la maintenance.



LIRE LES INSTRUCTIONS.

- Lisez le manuel d'instructions avant l'utilisation ou la maintenance de l'appareil.
- Arrêter le moteur et relâcher la pression avant d'effectuer la maintenance.

2-5. Dangers supplémentaires en relation avec l'installation, le fonctionnement et la maintenance



LA CHUTE DE L'APPAREIL peut blesser.


- Utiliser l'anneau de levage uniquement pour soulever l'appareil lui-même ; sans chariot, de bouteilles de gaz, remorque, ou autres accessoires.

- Utiliser un équipement de levage de capacité suffisante pour lever l'appareil.
- En utilisant des fourches de levage pour déplacer l'unité, s'assurer que les fourches sont suffisamment longues pour dépasser du côté opposé de l'appareil.




LE SURCHAUFFEMENT peut endommager le moteur électrique.

- Arrêter ou déconnecter l'équipement avant de démarrer ou d'arrêter le moteur.
- Ne pas laisser tourner le moteur trop lentement sous risque d'endommager le moteur électrique à cause d'une tension et d'une fréquence trop faibles.
- Ne pas brancher de moteur de 50 ou de 60 Hz à la prise de 100 Hz, s'il y a lieu.




LES ÉTINCELLES VOLANTES risquent de provoquer des blessures.

- Porter un écran facial pour protéger le visage et les yeux.
- Affûter l'électrode au tungstène uniquement à la meuleuse dotée de protecteurs. Cette manœuvre est à exécuter dans un endroit sûr lorsque l'on porte l'équipement homologué de protection du visage, des mains et du corps.
- Les étincelles risquent de causer un incendie – éloigner toute substance inflammable.



L'EMPLOI EXCESSIF peut SURCHAUFFER L'ÉQUIPEMENT.

- Laisser l'équipement refroidir ; respecter le facteur de marche nominal.
- Réduire le courant ou le facteur de marche avant de poursuivre le soudage.
- Ne pas obstruer les passages d'air du poste.




LES CHARGES ÉLECTROSTATIQUES peuvent endommager les circuits imprimés.

- Établir la connexion avec la barrette de terre avant de manipuler des cartes ou des pièces.
- Utiliser des pochettes et des boîtes antistatiques pour stocker, déplacer ou expédier des cartes de circuits imprimés.




UNE REMORQUE QUI BASCULE peut entraîner des blessures.

- Utiliser les supports de la remorque ou des blocs pour soutenir le poids.
- Installer convenablement le poste sur la remorque comme indiqué dans le manuel s'y rapportant.




LIRE LES INSTRUCTIONS.

- Utiliser seulement les pièces de rechange d'origine.
- Effectuer la maintenance du moteur et du compresseur (si applicable) suivant ce manuel et le manuel du moteur/compresseur (si applicable).



LE RAYONNEMENT HAUTE FRÉQUENCE (H.F.) risque de provoquer des interférences.

- Le rayonnement haute fréquence (H.F.) peut provoquer des interférences avec les équipements de radio-navigation et de communication, les services de sécurité et les ordinateurs.
- Demander seulement à des personnes qualifiées familiarisées avec des équipements électroniques de faire fonctionner l'installation.
- L'utilisateur est tenu de faire corriger rapidement par un électricien qualifié les interférences résultant de l'installation.
- Si le FCC signale des interférences, arrêter immédiatement l'appareil.
- Effectuer régulièrement le contrôle et l'entretien de l'installation.
- Maintenir soigneusement fermés les portes et les panneaux des sources de haute fréquence, maintenir les éclateurs à une distance correcte et utiliser une terre et un blindage pour réduire les interférences éventuelles.



LE SOUDAGE À L'ARC risque de provoquer des interférences.

- L'énergie électromagnétique risque de provoquer des interférences pour l'équipement électronique sensible tel que les ordinateurs et l'équipement commandé par ordinateur tel que les robots.
- Veiller à ce que tout l'équipement de la zone de soudage soit compatible électromagnétiquement.
- Pour réduire la possibilité d'interférence, maintenir les câbles de soudage aussi courts que possible, les grouper, et les poser aussi bas que possible (ex. par terre).
- Veiller à souder à une distance de 100 mètres de tout équipement électronique sensible.
- Veiller à ce que ce poste de soudage soit posé et mis à la terre conformément à ce mode d'emploi.
- En cas d'interférences après avoir pris les mesures précédentes, il incombe à l'utilisateur de prendre des mesures supplémentaires telles que le déplacement du poste, l'utilisation de câbles blindés, l'utilisation de filtres de ligne ou la pose de protecteurs dans la zone de travail.

2-6. Principales normes de sécurité

Safety in Welding, Cutting, and Allied Processes, norme ANSI Z49.1, de l'American Welding Society, 550 N.W. LeJeune Rd, Miami FL 33126 (téléphone : (305) 443-9353, site Web : www.aws.org). Recommended Safe Practices for the Preparation for Welding and Cutting of Containers and Piping, norme American Welding Society AWS F4.1, de l'American Welding Society, 550 N.W. LeJeune Rd, Miami, FL 33126 (téléphone : (305) 443-9353, site Web : www.aws.org). National Electrical Code, norme NFPA 70, de la National Fire Protection Association, P.O. Box 9101, 1 Battery March Park, Quincy, MA 02269-9101 (téléphone : (617) 770-3000, sites Web : www.nfpa.org et www.sparky.org). Safe Handling of Compressed Gases in Cylinders, brochure CGA P-1, de la Compressed Gas Association, 1735 Jefferson Davis Highway, Suite 1004, Arlington, VA 22202-4102 (téléphone : (703) 412-0900, site Web : www.cganet.com). Code for Safety in Welding and Cutting, norme CSA W117.2, de la Canadian Standards Association, Standards Sales, 178 boulevard Rexdale,

Rexdale (Ontario) Canada M9W 1R3 (téléphone : (800) 463-6727 ou à Toronto : (416) 747-4044, site Web : www.csa-international.org). Practice For Occupational And Educational Eye And Face Protection, norme ANSI Z87.1, de l'American National Standards Institute, 11 West 42nd Street, New York, NY 10036-8002 (téléphone : (212) 642-4900, site Web : www.ansi.org). Standard for Fire Prevention During Welding, Cutting, and Other Hot Work, norme NFPA 51B, de la National Fire Protection Association, P.O. Box 9101, 1 Battery March Park, Quincy, MA 02269-9101 (téléphone : (617) 770-3000, site Web : www.nfpa.org et www.sparky.org). OSHA, Occupational Safety and Health Standards for General Industry, Title 29, Code of Federal Regulations (CFR), Part 1910, Subpart Q, and Part 1926, Subpart J, de l'U.S. Government Printing Office, Superintendent of Documents, P.O. Box 371954, Pittsburgh, PA 15250 (il y a 10 bureaux régionaux – Téléphone pour la Région 5, Chicago : (312) 353-2220, site Web : www.osha.gov).

2-7. Information sur les champs électromagnétiques

Données sur le soudage électrique et les effets des champs magnétiques basse fréquence sur l'organisme
En parcourant les câbles de soudage, le courant crée des champs électromagnétiques. Les effets potentiels de tels champs restent préoccupants. Cependant, après avoir examiné plus de 500 études qui ont été faites pendant une période de recherche de 17 ans, un comité de spécialistes du National Research Council a conclu : « L'accumulation de preuves n'a pas démontré que l'exposition aux champs magnétiques et aux champs électriques à haute fréquence constitue un risque pour la santé humaine ». Toutefois, les études et l'examen des preuves se poursuivent. En attendant les conclusions finales de la recherche, il serait souhaitable de réduire l'exposition aux champs électromagnétiques pendant le soudage ou le coupage.

Afin de réduire les champs électromagnétiques en milieu de travail, respecter les consignes suivantes :






1. Garder les câbles ensemble en les torsadant ou en les fixant avec du ruban adhésif.
2. Mettre tous les câbles du côté opposé à l'opérateur.
3. Ne pas s'enrouler les câbles autour du corps.
4. Garder le poste de soudage et les câbles le plus loin possible de soi.
5. Placer la pince de masse le plus près possible de la zone de soudage.

Consignes relatives aux stimulateurs cardiaques :

Les personnes qui portent un stimulateur cardiaque doivent avant tout consulter leur médecin. Si ce dernier les déclare aptes, il leur est recommandé de respecter les consignes ci-dessus.

SECTION 3 – DEFINITIONS

3-1. Symbols And Definitions

	Stop Engine		Fast (Run, Weld/Power)		Slow (Idle)		Start Engine
	Check engine belt		Check Air Cleaner		Starting Aid		Engine
	Battery (Engine)		Jump start/Battery Charge		Battery Charge		Jump Start
	Do Not Switch Under Load		Read Operator's Manual		Certified/Trained Mechanic		Engine Oil
	Check Injectors/Pump		Check Valve Clearance		Fuel		Engine Coolant Temperature
	Hourmeter (HM)		Air Pressure		Temperature		Air Compressor
	Positive		Negative		Wire Feed		Welding Arc
	Amperes		Volts		Panel/Local		Remote
	Output		Direct Current (DC)		Alternating Current (AC)		Gas Tungsten Arc Welding (TIG)
	Stick (SMAW) Welding		Constant Current (CC)		MIG (GMAW) Welding		Constant Voltage (CV)
	Three Phase		Single Phase		Air Carbon Arc Cutting (CAC-A)		Protective Earth (Ground)
	DC Electrode Positive		DC Electrode Negative		Work Connection		Electrode Connection
	Circuit Breaker		Time		Hours		Seconds
	On		Off				

SECTION 4 – SPECIFICATIONS

4-1. Weld, Power, And Engine Specifications

Welding Mode	Weld Output Range	Rated Welding Output	Maximum Open-Circuit Voltage (Nominal)	Generator Power Rating	Engine	Engine Oil Capacity	Fuel Tank Capacity
CC/DC	20 – 750 A	500 A, 40 Volts DC, 100% Duty Cycle	95	Standard Single-Phase, 4 kVA/kW, 34/17 A, 120/240 V AC, 50/60 Hz 3-Phase Generator Option* Single-Phase/Three-Phase, 12/20 kVA/kW, 50/48A, 120/240 VAC, 60 Hz *In Addition To Standard 4 kVA/kW Generator Power	 Deutz BF4M2011 Oil-Cooled, Four-Cylinder, Turbo-Charged 64 HP Diesel Engine	11 qt (10.4 L)	25 gal (95 L)
CV/DC	14 – 40 V		56				
CC/AC (Optional)	20 - 575	600 A, 44 Volts DC, 40% Duty Cycle	64				
Battery Charge/ Jump Start	12/24 V	750 A, 12 Volt Jump Start 750 A, 24 Volt Jump Start	14/28				

4-2. Air Compressor Specifications


Compressor Model And Type	Air Output At Effective Working Pressure	Factory Pressure Setting	Safety Relief Valve Rating	Air Compressor Oil Capacity
Ingersoll Rand CE55 G Rotary Screw	60 scfm (1.7 m ³ min ⁻¹), 100 psi (690 kPa), 100% Duty Cycle	125 psi (862 kPa)	150 psi (1034 kPa)	4 qt (3.8 L)

4-3. Sound Level Table

	Idle Speed (1235 rpm)	Weld/Power Speed (1850 rpm)	40 Volts DC At 500 Amps	44 Volts DC At 600 Amps
Air Compressor On	96.6 Lwa sound power 71.7 dBA at 23 ft (7 m) 77.2 dBA 3.3 ft (1 m) from front panel	102.8 Lwa sound power 77.9 dBA at 23 ft (7 m) 83.0 dBA 3.3 ft (1 m) from front panel	103.9 Lwa sound power 79.0 dBA at 23 ft (7 m) 89.8 dBA 3.3 ft (1 m) from front panel	106.0 Lwa sound power 81.1 dBA at 23 ft (7 m) 93.3 dBA 3.3 ft (1 m) from front panel
Air Compressor Off	94.6 Lwa sound power 69.7 dBA at 23 ft (7 m) 74.5 dBA 3.3 ft (1 m) from front panel	100.6 Lwa sound power 75.7 dBA at 23 ft (7 m) 78.8 dBA 3.3 ft (1 m) from front panel	103.0 Lwa sound power 78.1 dBA at 23 ft (7 m) 86.0 dBA 3.3 ft (1 m) from front panel	104.5 Lwa sound power 79.6 dBA at 23 ft (7 m) 91.8 dBA 3.3 ft (1 m) from front panel

4-4. Dimensions, Weights, And Operating Angles

Dimensions	
Height	54-1/2 in (1384 mm) (to top of muffler)
Width	28-1/2 in (724 mm) (mtg. brackets turned in)
	30-3/4 in (781 mm) (mtg. brackets turned out)
Depth	69-1/2 in (1765 mm)
A	69-1/2 in (1765 mm)
B*	55-7/8 in (1419 mm)
C*	46-3/8 in (1178)
D*	11 in (279 mm)
E	27-1/2 in (699 mm)
F	1 in (25 mm)
G	29-1/2 in (749 mm)
H	9/16 in (14 mm) Dia. 4 Holes
* With mounting brackets in center position. Dimensions vary with location of mounting brackets.	
Weight	
No fuel: 2010 lb (907 kg) w/fuel: 2185 lb (993 kg)	




802 161-A




▲ Do not exceed tilt angles or engine could be damaged or unit could tip.

▲ Do not move or operate unit where it could tip.



803 231

Notes




Work like a Pro!

Pros weld and cut safely. Read the safety rules at the beginning of this manual.


4-5. Stick And MIG Volt-Ampere Curves

A. DC Stick Mode




The volt-ampere curve shows the minimum and maximum voltage and amperage output capabilities of the welding generator. Curves of all other settings fall between the curves shown.

B. AC Stick Mode (Optional)




C. MIG Mode




4-6. TIG Volt-Ampere Curves

The volt-ampere curve shows the minimum and maximum voltage and amperage output capabilities of the welding generator. Curves of all other settings fall between the curves shown.


A. DC TIG Mode



B. AC TIG Mode (Optional)



4-7. Fuel Consumption




The curve shows typical fuel use under weld or generator power loads.

208 211

4-8. Duty Cycle And Overheating




100% Duty Cycle At 500 Amperes



Continuous Welding

40% Duty Cycle At 600 Amperes




4 Minutes Welding

6 Minutes Resting

Duty Cycle is percentage of 10 minutes that unit can weld at rated load without overheating.


▲ Exceeding duty cycle can damage unit and void warranty.



202 356


4-9. Generator AC Power Curve

The ac power curve shows the generator power in amperes available at the 120 and 240 volt receptacles.



193 018

Notes




Work like a Pro!

Pros weld and cut safely. Read the safety rules at the beginning of this manual.


4-10. Optional 3-Phase Generator Power Curves

The ac power curves show the generator power available in amperes at the single-phase 120/240 volt receptacle or three-phase 240 volt terminals.

A. 12 kVA/kW Single-Phase AC Output (No Weld Load)




B. 20 kVA/kW Three-Phase AC Output (No Weld Load)



4-11. Air Compressor Output Curve

The air output curve shows the volume and pressure of air available from the air compressor.




208 955

4-12. Optional Battery Charging Output Curve

The battery charging curves show the charging amperage and voltage output of the welding generator.

As battery voltage nears the charging voltage, charging current decreases.



210 269

4-13. Manufacturing Rating Label

   					
		45A/22V		to	600A/44V
		X	40%	60%	100%
		I ₂	600A	550A	500A
	U ₀ = 91V	U ₂	44V	42V	40V
		20A/11V		to	450A/28V
		X			100%
		I ₂			450A
	U ₀ = 48V	U ₂			28V
		20A/15V		to	600A/30V
		X	40%	60%	100%
		I ₂	600A	550A	500A
	U ₀ = 56V	U ₂	30V	34V	40V
		35A/21V		to	450A/38V
		X	40%	60%	100%
		I ₂	450A	425A	400A
	U ₀ = 64V	U ₂	38V	37V	36V
		20A/11V		to	375A/25V
		X			100%
		I ₂			375A
	U ₀ = 34V	U ₂			25V
		10A/14V		to	750A/28V
		X	25%		100%
		I ₂	750A		500A
	U ₀ = 28V	U ₂	12/24V		12/24V
		100psi	60cfm		
		n = 1800 min ⁻¹			
		n ₀ = 1850 min ⁻¹	*n ₁ = 1235 min ⁻¹	IP 23	
1 ~ 60 Hz	120/240V	4kVA	20/17A		
*1 ~ 60 Hz	120/240V	12kw	50/50A		
*3 ~ 60 Hz	240V	20kw	48A		
*Optional					


206 463-B

SECTION 5 – INSTALLATION

5-1. Installing Welding Generator



Movement




▲ Always securely fasten welding generator onto transport vehicle or trailer and comply with all DOT and other applicable codes.

▲ Always ground generator frame to vehicle frame to prevent electric shock and static electricity hazards.

▲ If unit does not have GFCI receptacles, use GFCI-protected extension cord.

☞ See Section 5-2 for mounting information.

Location




Grounding:

- 1 Equipment Grounding Terminal (On Front Panel)
- 2 Grounding Cable (Not Supplied)
- 3 Metal Vehicle Frame

Connect cable from equipment ground terminal to metal vehicle frame. Use #10 AWG or larger insulated copper wire.


Grounding



Electrically bond generator frame to vehicle frame by metal-to-metal contact.

▲ Bed liners, shipping skids, and some running gears insulate the welding generator from the vehicle frame. Always connect a ground wire from the generator equipment grounding terminal to bare metal on the vehicle frame as shown.


Airflow Clearance




5-2. Mounting Welding Generator



Supporting The Unit



▲ Do not use flexible mounts.



▲ Do not weld on base. Welding on base can cause fuel tank fire or explosion. Weld only on the four mounting brackets or bolt unit down.

▲ Do not mount unit by supporting the base only at the four mounting brackets. Use cross-supports to adequately support unit and prevent damage to base.

Mounting Surface:

1 Cross-Supports
2 Mounting Brackets (Supplied)
Mount unit on flat surface or use cross-supports to support base. Secure unit with mounting brackets.

- 3 1/2 in Bolt And Washer (Minimum – Not Supplied)
- 4 3/8-16 x 1 in Screws (Supplied)

To Bolt Unit In Place:



Remove hardware securing the four mounting brackets to the base. Reverse brackets and reattach to base with original hardware.

Mount unit to truck or trailer with 1/2 in (12 mm) or larger hardware (not supplied).


To Weld Unit In Place:

Weld unit to truck or trailer only at the four mounting brackets.

Using Mounting Brackets






Tools Needed:



9/16 in

install3 6/04 803 274 / 190 250-A / 803 231

5-3. Installing Optional Spark Arrestor Muffler



▲ Stop engine and let cool.

- 1 Spark Arrestor Muffler
- 2 Double-Flanged Elbow
- 3 Nut
- 4 Flat Washer
- 5 Mount
- 6 Bracket
- 7 Screw
- 8 Single-Flanged Elbow
- 9 Rain Cap
- 10 Clamp


Loosely assemble components as shown.

☞ Mount the muffler with the clean-out plug to the outside.

After assembly, final-tighten all clamps and hardware.






☞ Be sure to tighten rain cap mounting screw.

Tools Needed:

 7/16, 1/2 in

803 230

5-4. Activating The Dry Charge Battery (If Applicable)



Remove battery from unit.

- 1 Eye Protection – Safety Glasses Or Face Shield
- 2 Rubber Gloves
- 3 Vent Caps
- 4 Sulfuric Acid Electrolyte (1.265 Specific Gravity)
- 5 Well

Fill each cell with electrolyte to **bottom** of well (maximum).

▲ **Do not overfill battery cells.**




Wait ten minutes and check electrolyte level. If necessary, add electrolyte to raise to proper level. Reinstall vent caps.

- 6 Battery Charger

▲ **Read and follow all instructions supplied with battery charger.**

Charge battery for 12 minutes at 30 amperes or 30 minutes at 5 amperes. Disconnect charging cables and install battery.

☞ *When electrolyte is low, add only distilled water to cells to maintain proper level.*




5 A For 30 Minutes

OR



30 A For 12 Minutes



Tools Needed:




rubber gloves



glasses


drybatt1 1/98 – 0886

5-5. Connecting The Battery




802 168-E / Ref. 202 705 / 802 313 / S-0756-C

5-6. Using The Optional Battery Disconnect Switch



803 228 / Ref. 803 324

5-7. Engine/Compressor Prestart Checks



803 228

☞ Check all engine/compressor fluids daily.

Engine must be cold and on a level surface. Unit is shipped with 20W break-in oil. The automatic shutdown system stops engine if oil pressure is too low or coolant temperature is too high.

☞ This unit has a low oil pressure shutdown switch. However, some conditions may cause engine damage before the engine shuts down. Check oil level often and do not use the oil pressure shutdown system to monitor oil level.

Follow run-in procedure in engine manual. If unburned fuel and oil collect in exhaust pipe during run-in, see Section 13.

Fuel

▲ Do not use gasoline. Gasoline will damage engine.

Add fresh diesel fuel before starting to prevent air from entering the fuel system (see engine maintenance label for fuel specifications). Leave filler neck empty to allow room for expansion.

Engine stops if fuel level is low on units with low fuel shutdown option. Do not run out of fuel or air may enter fuel system and cause starting problems. See engine manual to bleed air from fuel system.

Engine Oil

After fueling, check oil with unit on level surface. If oil is not up to full mark on dipstick, add oil (see maintenance label for engine oil specifications).

Compressor Oil

1 Compressor Oil Level Indicator (On Tank)

Check oil with unit on level surface. Add oil

if oil is not up to full mark on indicator (see maintenance label for oil specifications).

Cold Weather Starting



☞ To improve cold weather starting: Use Starting Aid switch (see Section 6-1).

Keep battery in good condition. Store battery in warm area.

Use fuel formulated for cold weather (diesel fuel can gel in cold weather). Contact local fuel supplier for fuel information.

Use correct grade oil for cold weather (see Section 9-1).

5-8. Connecting To Weld Output Terminals



▲ Stop engine.

- 1 Positive (+) Weld Output Terminal
- 2 Negative (-) Weld Output Terminal

Stick And TIG Welding

For Stick welding Direct Current Electrode Positive (DCEP), connect electrode holder cable to Positive (+) terminal on left and work cable to Negative (-) terminal on right.

For Stick and TIG Direct Current Electrode Negative (DCEN), connect electrode holder cable to Negative (-) terminal on right and work cable to Positive (+) terminal on left.

If equipped with optional Polarity/AC Selector switch, connect electrode holder cable to Electrode terminal on left and work cable to Work terminal on right.


MIG And FCAW Welding

For MIG welding Direct Current Electrode Positive (DCEP), connect wire feeder cable to Positive (+) terminal on left and work cable to Negative (-) terminal on right. Use Process/Contactor switch to select type of weld output (see Section 6-3).

For MIG and FCAW Direct Current Electrode Negative (DCEN), connect wire feeder cable to Negative (-) terminal on right and work cable to Positive (+) terminal on left. Use Process/Contactor switch to select type of weld output (see Section 6-3).

If equipped with optional Polarity/AC Selector switch, connect wire feeder cable to Electrode terminal on left and work cable to Work terminal on right.

Tools Needed:



3/4 in


803 231

5-9. Selecting Weld Cable Sizes*

 Weld Output Terminals ▲ Turn off power before connecting to weld output terminals. ▲ Do not use worn, damaged, undersized, or poorly spliced cables.		Weld Cable Size** and Total Cable (Copper) Length in Weld Circuit Not Exceeding***							
		100 ft (30 m) or Less		150 ft (45 m)	200 ft (60 m)	250 ft (70 m)	300 ft (90 m)	350 ft (105 m)	400 ft (120 m)
		10 – 60% Duty Cycle	60 – 100% Duty Cycle	10 – 100% Duty Cycle					
	100	4 (20)	4 (20)	4 (20)	3 (30)	2 (35)	1 (50)	1/0 (60)	1/0 (60)
	150	3 (30)	3 (30)	2 (35)	1 (50)	1/0 (60)	2/0 (70)	3/0 (95)	3/0 (95)
	200	3 (30)	2 (35)	1 (50)	1/0 (60)	2/0 (70)	3/0 (95)	4/0 (120)	4/0 (120)
	250	2 (35)	1 (50)	1/0 (60)	2/0 (70)	3/0 (95)	4/0 (120)	2 ea. 2/0 (2x70)	2 ea. 2/0 (2x70)
	300	1 (50)	1/0 (60)	2/0 (70)	3/0 (95)	4/0 (120)	2 ea. 2/0 (2x70)	2 ea. 3/0 (2x95)	2 ea. 3/0 (2x95)
	350	1/0 (60)	2/0 (70)	3/0 (95)	4/0 (120)	2 ea. 2/0 (2x70)	2 ea. 3/0 (2x95)	2 ea. 3/0 (2x95)	2 ea. 4/0 (2x120)
	400	1/0 (60)	2/0 (70)	3/0 (95)	4/0 (120)	2 ea. 2/0 (2x70)	2 ea. 3/0 (2x95)	2 ea. 4/0 (2x120)	2 ea. 4/0 (2x120)
	500	2/0 (70)	3/0 (95)	4/0 (120)	2 ea. 2/0 (2x70)	2 ea. 3/0 (2x95)	2 ea. 4/0 (2x120)	3 ea. 3/0 (3x95)	3 ea. 3/0 (3x95)
	600	3/0 (95)	4/0 (120)	2 ea. 2/0 (2x70)	2 ea. 3/0 (2x95)	2 ea. 4/0 (2x120)	3 ea. 3/0 (3x95)	3 ea. 4/0 (3x120)	3 ea. 4/0 (3x120)
	700	4/0 (120)	2 ea. 2/0 (2x70)	2 ea. 3/0 (2x95)	2 ea. 4/0 (2x120)	3 ea. 3/0 (3x95)	3 ea. 4/0 (3x120)	3 ea. 4/0 (3x120)	4 ea. 4/0 (4x120)
	800	4/0 (120)	2 ea. 2/0 (2x70)	2 ea. 3/0 (2x95)	2 ea. 4/0 (2x120)	3 ea. 4/0 (3x120)	3 ea. 4/0 (3x120)	4 ea. 4/0 (4x120)	4 ea. 4/0 (4x120)
* This chart is a general guideline and may not suit all applications. If cable overheats, use next size larger cable. **Weld cable size (AWG) is based on either a 4 volts or less drop or a current density of at least 300 circular mils per ampere. () = mm² for metric use ***For distances longer than those shown in this guide, call a factory applications representative at 920-735-4505.									


S-0007-F

5-10. Connecting To Remote 14 Receptacle RC14


 803 231	 REMOTE 14	Socket*	Socket Information
	 24 VOLTS AC OUTPUT (CONTACTOR)	A	24 volts ac. Protected by circuit breaker CB5.
		B	Contact closure to A completes 24 volt ac contactor control circuit.
	REMOTE OUTPUT CONTROL	C	Output to remote control: +10 volts dc in MIG or Stick mode; 0 to +10 volts dc in TIG mode.
		D	Remote control circuit common.
		E	DC input command signal: 0 to +10 volts from min. to max. of remote control with Voltage/ Amperage Adjust control at max.
	 115 VOLTS AC OUTPUT (CONTACTOR)	I	115 volts, 10 amperes, 60 Hz ac. Protected by circuit breaker CB6.
		J	Contact closure to I completes 115 volt ac contactor control circuit.
	GND	K	Chassis common.
	NEUTRAL	G	Circuit common for 24 and 115 volt ac circuit.

*The remaining sockets are not used.

5-11. Connecting To The Air Compressor



▲ Stop engine and release air pressure before servicing compressor.



▲ Air pressure is present at air shutoff valve whenever Air Pressure Gauge on front panel indicates air pressure.

- 1 3/4 in NPT Air Pressure Fitting
- 2 Air Shutoff Valve

Connect air hose with 3/4 in NPT fitting (not supplied) to air shutoff valve.

Be sure valve is in open position when using air compressor.

The compressor runs and air pressure is available whenever the engine is running and the front panel Compressor switch is moved to the On position (see Section 6-1).

Run engine at weld/power speed for maximum air compressor output. Compressor output is reduced when engine is running at idle speed.

803 231

The air compressor will not start if still under pressure. If air compressor is turned off, wait for air pressure to bleed off (about 20 seconds) before turning air compressor on again.

☞ Using the air compressor does not significantly affect weld or generator power output.


Notes

DECIMAL EQUIVALENTS


	$\frac{1}{64}$	.015625
$\frac{1}{32}$	$\frac{3}{64}$	.03125
	$\frac{5}{64}$	.046875
$\frac{1}{16}$	$\frac{7}{64}$	.0625
	$\frac{9}{64}$	.078125
$\frac{3}{32}$	$\frac{11}{64}$	.09375
	$\frac{13}{64}$	.109375
$\frac{1}{8}$	$\frac{15}{64}$	.125
	$\frac{17}{64}$	.140625
$\frac{5}{32}$	$\frac{19}{64}$	.15625
	$\frac{21}{64}$	.171875
$\frac{3}{16}$	$\frac{23}{64}$	.1875
	$\frac{25}{64}$	.203125
$\frac{7}{32}$	$\frac{27}{64}$	.21875
	$\frac{29}{64}$	.234375
$\frac{1}{4}$	$\frac{31}{64}$	.25
	$\frac{33}{64}$	.265625
$\frac{9}{32}$	$\frac{35}{64}$	.28125
	$\frac{37}{64}$	.296875
$\frac{5}{16}$	$\frac{39}{64}$	.3125
	$\frac{41}{64}$	.328125
$\frac{11}{32}$	$\frac{43}{64}$	.34375
	$\frac{45}{64}$	.359375
$\frac{3}{8}$	$\frac{47}{64}$	.375
	$\frac{49}{64}$	.390625
$\frac{13}{32}$	$\frac{51}{64}$	.40625
	$\frac{53}{64}$	.421875
$\frac{7}{16}$	$\frac{55}{64}$	.4375
	$\frac{57}{64}$	.453125
$\frac{15}{32}$	$\frac{59}{64}$	.46875
	$\frac{61}{64}$	.484375
$\frac{1}{2}$	$\frac{63}{64}$	.5
		.515625
$\frac{17}{32}$		.53125
		.546875
$\frac{9}{16}$		.5625
		.578125
$\frac{19}{32}$		.59375
		.609375
$\frac{5}{8}$		.625
		.640625
$\frac{21}{32}$		.65625
		.671875
$\frac{11}{16}$		.6875
		.703125
$\frac{23}{32}$		.71875
		.734375
$\frac{3}{4}$		.75
		.765625
$\frac{25}{32}$		.78125
		.796875
$\frac{13}{16}$		.8125
		.828125
$\frac{27}{32}$		.84375
		.859375
$\frac{7}{8}$		.875
		.890625
$\frac{29}{32}$		.90625
		.921875
$\frac{15}{16}$		.9375
		.953125
$\frac{31}{32}$		.96875
		.984375
1		1.

SECTION 6 – OPERATING THE WELDING GENERATOR

6-1. Controls (See Section 6-2)



6-2. Description Of Controls (See Section 6-1)



Engine Starting Controls

1 Starting Aid Switch

Use switch to energize starting aid for cold weather starting.

Push switch up for 60 seconds to operate the starting aid (intake air heater) before cranking engine (see starting instructions following).

2 Engine Control Switch

Use switch to start engine, select engine speed, and stop engine.

In Run position, engine runs at weld/power speed. In Run/Idle position, engine runs at idle speed with no generator power or weld load, and weld/power speed with load applied.

The air compressor load does not affect engine speed. Run engine at weld/power speed for maximum air compressor output.

To Start:

If engine does not start, let engine come to a complete stop before attempting re-start.

Above 32° F (0° C): turn Engine Control switch to Start. Release Engine Control switch when engine starts.

Below 32° F (0° C) using starting aid switch:

Turn Engine Control switch to Run/Idle position. Push Starting Aid switch up for 60 seconds. While still holding Starting Aid switch, turn Engine Control switch to Start. Release Engine Control switch and Starting Aid switch when engine starts.

To Stop: turn Engine Control switch to Off position.

Engine/Compressor Gauges

3 Engine Hour Meter

Use gauge to monitor engine running time for scheduling maintenance.

4 Fuel Gauge

Use gauge to check fuel level. Engine stops if fuel level is low on units with low fuel shut-down option.

To check fuel level when engine is not running, turn Engine Control switch to Run/Idle position.

5 Air Pressure Gauge

Use gauge to check compressor air pressure.

6 Engine Oil Pressure Gauge

Normal pressure is 30 – 60 psi (206 – 414 kPa). Engine stops if pressure is below 20 psi (138 kPa).

7 Engine Temperature Gauge

Normal temperature is 212 - 239° F (100 - 115° C). Engine stops if temperature exceeds 270° F (132° C).

8 Battery Voltmeter

Use gauge to check battery voltage and monitor the engine charging system. The meter should read about 14 volts dc when the engine is running, and about 12 volts dc when the engine is stopped.

9 Air Compressor Hour Meter (Optional)

Use gauge to monitor compressor running time for scheduling maintenance.

Weld Controls

10 Process/Contactor Switch

See Section 6-3 for Process/Contactor switch information.

11 Ampere Range Switch

▲ Do not switch under load.

Use switch to select weld amperage range.

Use all five ranges for Stick welding, and the lowest four ranges for TIG welding. Read the upper set of numbers at each range for Stick welding and the lower set at each range for TIG welding.

Use the highest range for MIG welding and for cutting and gouging (CAC-A).

For most welding applications, use lowest amperage range possible to help prevent arc outages.

12 Voltage/Amperage Adjust Control

With Process/Contactor switch in any Stick or TIG setting, use control to adjust amperage within range selected by Ampere Range switch. With Process/Contactor switch in any MIG position, use control to adjust voltage. With Voltage/Amperage Adjust Switch in Remote position, control limits the remote amperage in TIG mode, but has no effect in Stick and MIG modes.

Weld output would be about 263 A DC with controls set as shown (50% of 125 to 400 A).

The numbers around the Voltage/Amperage Adjust control are for reference only and do not represent an actual percentage value.

13 Voltage/Amperage Adjust Switch And Remote 14 Receptacle

Use switch to select front panel or remote voltage/amperage control. For remote control, place switch in Remote position and connect remote control to Remote 14 receptacle RC14 (see Sections 5-10 and 6-4).

14 Polarity/AC Selector Switch (Optional) Or Output Selector Switch (Optional)

▲ Do not switch under load.

Use Polarity/AC selector switch to select AC or DC weld output and DC weld output polarity.

Use Output Selector switch to select AC Weld, DC Weld, or battery charge output (see Section 8-1).

Weld Meters

15 AC/DC Voltmeter (Optional)

Voltmeter displays voltage at the weld output terminals, but not necessarily the welding arc due to resistance of cable and connections.

16 AC/DC Ammeter (Optional)

Ammeter displays amperage output of the unit.

Air Compressor Controls

17 Air Compressor Switch

Use switch to turn air compressor on and off. Air pressure is present at the compressor air shutoff valve whenever the compressor is running. The compressor shuts off when the engine stops. To use air, the compressor must be turned on each time the engine is started.


The air compressor will not start if still under pressure. If air compressor is turned off, wait for air pressure to bleed off (about 20 seconds) before turning air compressor on again.

18 Air Shutoff Valve

▲ Air pressure is present at valve whenever Air Pressure Gauge (item 5) indicates air pressure.

Close valve to stop air flow when connecting or changing tools or air hoses (see Section 5-11).

6-3. Process/Contactor Switch



1 Process/Contactor Switch

▲ **Weld output terminals are energized when Process/Contactor switch is in a Weld Terminals Always On position and the engine is running.**

▲ **DC voltage is still present at the weld terminals when Process/Contactor switch is in the Remote On/Off Switch Required – Stick position and the engine is running.**

Use switch to select weld process and weld output on/off control (see table below and Section 6-4).

Place switch in Remote On/Off Switch Required positions to turn weld output on and off with a device connected to the remote 14 receptacle.

Place switch in Weld Terminals Always On positions for weld output to be on whenever the engine is running.

Use Stick position for air carbon arc (CAC-A) cutting and gouging.

When switch is in a Stick position, the arc drive (dig) circuit provides additional amperage during low voltage (short arc length conditions) to prevent “sticking” electrodes.

The arc drive (dig) circuit is disabled when switch is in MIG or TIG positions.

☞ *The engine auto idle option does not work in the Remote On/Off Switch Required-TIG mode.*

217 638-A


Process/Contactor Switch Settings

Switch Setting	Process	Output On/Off Control	Engine Auto Idle (Optional)
Remote On/Off Switch Required – TIG, HF Required Or Scratch Start TIG	GTAW With HF Unit, Pulsing Device, Or Remote Control	At Remote 14 Receptacle	Not Active
Remote On/Off Switch Required – Stick	Stick (SMAW) With Remote On/Off	At Remote 14 Receptacle	Active
Remote On/Off Switch Required – CV Feeder Using Remote	MIG (GMAW)	At Remote 14 Receptacle	Active
Weld Terminals Always On – Wire	MIG (GMAW)	Electrode Hot	Active
Weld Terminals Always On – Stick	Stick (SMAW), Air Carbon Arc (CAC-A) Cutting And Gouging	Electrode Hot	Active
Weld Terminals Always On – TIG, Scratch Start	TIG Scratch Start (GTAW)	Electrode Hot	Active

6-4. Using Remote Voltage/Amperage Control




1 Remote 14 Receptacle RC14
Connect optional remote control to RC14 (see Section 5-10).



803 231


Example: Combination Remote Amperage Control (Stick)

In Example:
Process = Stick (Using Remote On/Off)
Range = 125 to 400 A DC
Min = 125 A DC
Max = 400 A DC




Example: Combination Remote Amperage Control (TIG)

In Example:
Process = TIG (Using Remote On/Off)
Range = 40 to 330 A DC
Percentage Of Range = 50%
Min = 40 A DC
Max = About 185 A DC (50% of 40 to 330)



SECTION 7 – OPERATING AUXILIARY EQUIPMENT

7-1. 120 Volt And 240 Volt Receptacles



- 1 120 V 20 A AC GFCI Receptacle GFCI1
- 2 240 V 30 A AC Twistlock Receptacle RC1

Receptacles supply 60 Hz single-phase power at weld/power speed.

If a ground fault is detected, GFCI Reset button pops out and receptacle does not work. Check for faulty tools plugged in receptacle. Press button to reset GFCI1.

At least once a month, run engine at weld/power speed and press test button to verify GFCI is working properly.

- 3 Circuit Breaker CB1
- 4 Circuit Breaker CB2

CB1 protects RC1 and the generator winding from overload. If CB1 opens, RC1 and GFCI1 do not work. Place switch in On position to reset breaker.

CB2 protects GFCI1 from overload. If CB2 opens, GFCI1 does not work. Press button to reset breaker.

If a circuit breaker continues to open, contact Factory Authorized Service Agent.

Generator power is not affected by weld output.

Maximum output is 2.4 kVA/kW from GFCI1 and 4 kVA/kW from RC1. Maximum output from all receptacles is 4 kVA/kW.


EXAMPLE: If 13 A is drawn from RC1, only 7 A is available at GFCI1:

$$(240 \text{ V} \times 13 \text{ A}) + (120 \text{ V} \times 7 \text{ A}) = 4.0 \text{ kVA/kW}$$


7-2. Connecting To Optional AC Power Plant




Single-Phase Power Connection



Three-Phase Power Connection



AC ~ Output	Single Phase 1 ~	Three Phase 3 ~
Volts	120/240	240
Amps	50	48
KVA/KW	12	20
Frequency	60 Hz	
Engine Speed	1850 RPM	
Lead 42 connects to GROUND stud on front of unit. Jumper 42 is connected to 90 at factory.		



Do not weld while using optional ac power plant.

Place Process/Contactor switch in Weld Terminals Always On - Stick position when using optional ac power plant (see Section 6-3).

Single-Phase Generator Power

- 120/240 V 50 A Receptacle RC5

RC5 is connected to the optional ac power plant and supplies 60 Hz single-phase power at weld/power speed. Maximum output from RC5 is 12 kVA/kW. Power available at RC5 is reduced when welding.

- Circuit Breaker CB7

Circuit breaker CB7 protects single-phase receptacle RC5 and the load wires from overload. If CB7 opens, all generator ac output stops and the receptacle does not work.

Three-Phase Generator Power

▲ Stop engine.

▲ Power and weld outputs are live at the same time. Disconnect or insulate unused cables.

Have qualified person install according to circuit diagram and Generator Power Guidelines (see Section 15).

Remove power panel mounting screws. Tilt panel forward.

- Lead 93
- Lead 92
- Lead 91
- Lead 42 (Circuit Grounding Lead)
- Lead 90 (Neutral)
- Isolated Neutral Terminal
- Jumper Lead 42
- Grounding Terminal

Jumper 42 is connected to lead 90 at factory. Jumper 42 may be disconnected from neutral to meet applicable electrical codes.

Lead 42 connects to front panel Ground stud.

- User-Supplied Leads
- Circuit Breaker CB7 User Terminals

Connect user-supplied leads to terminals on CB7 and to the isolated neutral terminal and grounding terminal as necessary.


Circuit breaker CB7 protects single-phase receptacle RC5 and the load wires from overload. If CB7 opens, all ac power plant output stops and the receptacle does not work.

Reinstall power panel.

7-3. Optional Generator Power Receptacles



European Receptacle



120 V 20A 1~ 60 Hz 240 V 15 A

- 1 120 V 20 A AC GFCI Receptacle GFCI1
- 2 240 V 16 A AC European Receptacle RC1
- 3 240 V 15 A AC Australian Receptacle RC1
- 4 240 V 15 A AC South African Receptacle RC1

Receptacles supply 60 Hz single-phase power at weld/power speed.

If a ground fault is detected, the GFCI Reset button pops out and the receptacle does not work. Check for faulty tools plugged in receptacle. Press button to reset GFCI1.

At least once a month, run engine at weld/power speed and press test button to verify GFCI is working properly.

- 5 Circuit Breaker CB2
- 6 Circuit Breaker CB3

CB2 protects GFCI1 from overload. If CB2 opens, GFCI1 does not work. Place button to reset breaker.

CB3 protects RC1 from overload. If CB3 opens, RC1 does not work. Press button to reset breaker.

If a circuit breaker continues to open, contact Factory Authorized Service Agent.


Generator power is not affected by weld output.

Maximum output is 2.4 kVA/kW from GFCI1 and 4 kVA/kW from RC1. Maximum output from all receptacles is 4 kVA/kW.

EXAMPLE: If 13 A is drawn from RC1, only 7 A is available at GFCI1:


$$(240 \text{ V} \times 13 \text{ A}) + (120 \text{ V} \times 7 \text{ A}) = 4.0 \text{ kVA/kW}$$

Australian Receptacle



120 V 20A 1~ 60 Hz 240 V 15 A


South African Receptacle



120 V 20A 1~ 60 Hz 240 V 15 A

SECTION 8 – OPERATING OPTIONAL BATTERY CHARGER

8-1. Battery Charge Controls




1 Output Selector Switch


▲ Do not switch under load. Stop engine or set Process/Contactor switch to any Remote position before switching.

Use switch to select weld or battery charge output. Output automatically decreases (but does not stop) when terminal voltage is 15 to 25 percent above required battery voltage.

ⓘ Before connecting charging cables, place Output Selector switch in position matching voltage of battery being charged.


When done charging, stop engine or set Process/Contactor switch to any Remote On/Off Switch Required position. Move Output Selector switch to AC Weld or DC Weld position.








803 231-A / 210 149-B

8-2. Determining Battery Charging Current



8-3. Battery Charge Cable Connections



803 231-A / 210 149 / Ref. S-0714 / Ref. S-0756

- ▲ Stop engine.
- ▲ Do not charge or jump start a battery which has loose terminals or one showing damage such as a cracked case or cover.
- ▲ Have only qualified persons do battery charging work.
- ▲ Keep cables away from moving parts.
- ▲ Do not use damaged cables.
- ▲ Be sure charger output voltage matches battery voltage.
- ▲ Read BCI Battery Service Manual before charging or jump starting.

☞ Before connecting to battery, place Output Selector switch in position matching voltage of battery being charged.

- 1 Battery
- 2 Battery Charging Cables

For battery charging, use less than 20 feet (6.1 m) of AWG #1 or larger cable. For jump starting, use less than 20 feet (6.1 m) of AWG 2/0 or larger cable.

- 3 Terminal Lug

Use lugs of proper amperage capacity and hole size for connecting to charge output terminals.


Install suitable connectors on remaining ends of battery cables.

- 4 Battery Charge Positive (+) Output Terminal
- 5 Battery Charge Negative (-) Output Terminal

☞ Connect charging cables to battery charge output terminals before connecting to battery terminals.

Connect Battery Charge Positive (+) cable to battery positive (+) terminal, and battery Charge Negative (-) cable to battery negative (-) terminal.

8-4. Battery Charging Procedure




In Example:
 Battery Voltage = 12 Volts
 Battery CCA Rating = 500
 Charge Current = 100 A (See Section 8-2)
 Ampere Range Setting = 55 to 125 A
 V/A Control Setting = Any Position


This battery charging procedure uses the front panel controls to turn charging output on and off.



Stop Engine.




Set Process/Contactor Switch To Any Remote On/Off Switch Required Position.




Set Output Selector Switch To Voltage Of Battery Being Charged (12 Or 24 Volt).

▲ Do not switch under load.




Determine Charge Current From Battery CCA Rating And Chart (See Section 8-2).



Set Ampere Range Switch To Lowest Range That Exceeds Charge Current.


▲ Do not switch under load.




Connect Cables (Observe Correct Polarity).



Start Engine.




Set Process/Contactor Switch To Any Weld Terminals Always On Position To Begin Charging.




Charge 10 minutes. Check Battery Voltage. Continue Charging If Necessary.

To control battery charging output using a remote device connected to the Remote 14 receptacle, keep Process/Contactor switch in Remote On/Off Switch Required position and use remote device to turn charging output on and off.


8-5. Jump Starting Procedure




☞ Charge battery for 10 minutes before jump starting battery.



Stop Engine.




Set Process/Contactor Switch To Any Remote On/Off Switch Required Position.




Set Output Selector Switch To Voltage Of Battery Being Charged (12 Or 24 Volt).

▲ Do not switch under load.





Set Ampere Range Switch To 300-Max Position.


▲ Do not switch under load.




Connect Cables (Observe Correct Polarity).



Connect Remote Control Device (Momentary-On Switch).




Press (close) switch only while cranking engine of equipment being started.



Start Engine.


Press (Close) Remote Momentary-On Switch While Cranking Engine Of Equipment Being Jump Started. Release Switch When Equipment Starts. Stop Welding Generator And Disconnect Cables.



Stop Engine. Disconnect Cables.

SECTION 9 – ENGINE/GENERATOR MAINTENANCE

9-1. Engine Maintenance Label













Note








Follow the storage procedure in the engine owner's manual if the unit will not be used for an extended period.

9-2. Routine Engine/Generator Maintenance

NOTE


See Section 10 for air compressor maintenance information.


						 Recycle engine fluids.	 See Engine Manual and Maintenance Label for important start-up, service, and storage information. Service engine more often if used in severe conditions. * To be done by Factory Authorized Service Agent.			
 Every 8 h										
 Wipe Up Spills.		 Check Fluid Levels. See Section 5-7.		FUEL WATER  Drain Water From Fuel System. See Section 9-7.						
 Every 50 h										
 Clean Engine Air Filter. See Section 9-4.			 Clean And Tighten Weld Terminals.							
 Every 100 h										
 Check Engine Air Cleaner Hoses For Cracks And Loose Clamps.			 Clean And Tighten Battery Connections.							
 Every 250 h										
 Replace Unreadable Labels.			1/2 in. (13 mm)  Inspect Belts And Check Tension.							
 Clean Radiator.			 Check And Clean Optional Spark Arrestor. See Section 9-5.							
 Every 500 h										
 Change Engine Oil. See Section 9-7.			 Change Engine Oil Filter. See Section 9-7. Service more often in dirty conditions.							
 Repair Or Replace Cracked Cables.										

 Every 1000 h			
	Change Engine Fuel Filters. See Section 9-7.		Service Welding Generator Brushes And Slip Rings. Service More Often In Dirty Conditions.*
	Drain Sludge From Fuel Tank. See Section 9-7.		Check Engine Valve Clearance.*
		Blow Out Or Vacuum Inside. During Heavy Service, Clean Monthly.	
 Every 3000 h			
		Clean/Set Engine Fuel Injectors.*	
 Every 6000 h / 5 Years			
		Replace Engine Timing Belt.	

9-3. Checking Generator Brushes







Minimum Length: 5/8 in (16 mm)

New Length: 1-1/4 in (32 mm)

Replace Damaged Brushes

1

▲ Stop engine and let cool.




1 Generator Brush

Remove brushes from brush holder.

Replace brushes if damaged or if brush material is at or near minimum length.

Ref. 206 467

9-4. Servicing Engine Air Cleaner



▲ Stop engine.

▲ Do not run engine without air cleaner or with dirty element. Engine damage caused by using a damaged element is not covered by the warranty.

1 Engine Air Cleaner

The air cleaner primary element can be cleaned but the dirt holding capacity of the filter is reduced with each cleaning. The chance of dirt reaching the clean side of the filter while cleaning and the possibility of filter damage makes cleaning a risk. Consider the risk of unwarrantable equipment damage when determining whether to clean or replace the primary element.

If you decide to clean the primary element, we strongly recommend installing an optional safety element to provide additional engine protection. **Never clean a safety element.** Replace the safety element after servicing the primary element three times.

Clean or replace primary element if dirty (see note above before cleaning). **Replace** primary element if damaged. Replace primary element yearly or after six cleanings.

- 2 Housing
- 3 Safety Element (Optional)
- 4 Primary Element
- 5 Dust Cap
- 6 Dust Ejector

To clean air filter:

Wipe off cap and housing. Remove cap and dump out dust. Remove element(s). Wipe dust from inside cap and housing with damp cloth. Reinstall safety element (if present). Reinstall cap.



▲ Do not clean housing with air hose.

Clean primary element with compressed air only.

Air pressure must not exceed 100 psi (690 kPa). Use 1/8 in (3 mm) nozzle and keep nozzle at least 2 in (51 mm) from inside of element. Replace primary element if it has holes or damaged gaskets.

Reinstall primary element and cap (dust ejector down).

9-5. Inspecting/Cleaning Optional Spark Arrestor Muffler



▲ Stop engine and let cool.



- 1 Spark Arrestor Muffler
- 2 Cleanout Plug

Remove plug and remove any dirt covering cleanout hole.


Start engine and run at idle speed to blow out cleanout hole. If nothing blows out of hole, briefly cover end of exhaust pipe with fireproof material.

▲ Stop engine and let cool.

Reinstall cleanout plug.





Tools Needed:



803 228 / 803 230

9-6. Adjusting Engine Speed



▲ Stop engine and let cool.

Engine speed is factory set and should not require adjustment. After tuning engine, check engine no load speed with a tachometer or frequency meter (see table for no load speeds). If necessary, adjust speed as follows:

Start engine and run until warm.

Turn Process/Contactor switch to Weld Terminals Always On – Stick position.

- 1 Throttle Rod
- 2 Locknut

Loosen locknuts. Place engine control switch in Run/Idle position.

Wait 15 seconds for throttle solenoid to energize and lower engine speed to idle rpm.

Turn throttle rod to adjust idle speed. Tighten locknuts.

- 3 Engine Speed Adjustment Screw
- 4 Locknut

Place engine control switch in Run position.

Loosen locknut. Turn screw to adjust weld/power speed. Tighten locknut.

Do not set engine speed higher than specified.

▲ Stop engine.

Close door.





	1850 rpm Max. (61.6 Hz)
	1235 rpm (41.1 Hz)

Tools Needed:

3/8, 7/16 in

803 228 / 802 313-A

9-8. Engine/Generator Overload Protection



▲ Stop engine.

☞ When a circuit breaker or fuse opens, it usually indicates a more serious problem exists. Contact Factory Authorized Service Agent.

☞ See Section 10-4 for air compressor overload protection.

- 1 Fuse F1
- 2 Fuse F2

F1 and F2 protect the stator exciter winding from overload. If F1 opens, weld and generator power is low or stops entirely. If F2 opens, weld output is low or stops entirely. 4 kVA/kW generator power is still available.

- 3 Circuit Breaker CB4 (Not Shown)
- 4 Circuit Breaker CB5
- 5 Circuit Breaker CB6
- 6 Circuit Breaker CB10 (Not Shown)
- 7 Circuit Breaker CB11
- 8 Circuit Breaker CB12
- 9 Circuit Breaker CB13
- 10 Circuit Breaker CB14 (Not Shown)

CB4 protects the welding arc drive (dig) circuit. If CB4 opens, electrode may stick to the workpiece more frequently during low voltage (short arc length) conditions. CB4 automatically resets when the fault is corrected.

CB5 protects the 24 volt ac output to remote receptacle RC14, and 24 volt output to field current regulator board PC1. If CB5 opens, weld output and 24 volt output to RC14 stops. On units with optional power plant, power at receptacle RC5 also stops if CB5 opens.

CB6 protects the 115 volt ac output to remote receptacle RC14. If CB6 opens, 115 volt output to RC14 stops.

CB10 protects the engine battery circuit. If CB10 opens, the engine will not crank. CB10 automatically resets when the fault is corrected.

CB11 protects the engine wiring harness. If CB11 opens, weld output stops (generator power is still available).

CB12 protects the field flashing circuit. If CB12 opens, the generator may not excite at start-up and weld and generator power output may not be available.

CB13 protects the engine shutdown circuit. If CB13 opens, the engine cranks but does not start.

Press button to reset breaker.

CB14 protects the throttle solenoid. If CB14 opens, the engine will not run at idle speed. CB14 automatically resets when the fault is corrected.

SECTION 10 – AIR COMPRESSOR MAINTENANCE

NOTE

Use only genuine Ingersoll Rand compressor oil and filters to maintain 3-year warranty on air compressor. The air compressor warranty will be reduced to 2 years if non-Ingersoll Rand oil and filters are used.


The air compressor normally requires service at the intervals listed in the maintenance schedule if used in a clean, dry environment. The compressor will require service more often if used in dirty, humid conditions.

10-1. Air Compressor Maintenance Label


INGERSOLL RAND CE55 G AIR COMPRESSOR




500 h / 6 m std.




3.8 L (4 qt.)




MILLER: 206 745
Ingersoll Rand: 39329602


125°F to -10°F 52°C to -23°C	125°F to -40°F 52°C to -40°C
Ingersoll Rand: PRO-TEC 36899698 MILSPEC: MIL-PRF 2104G SAE 10W	Mobil 1: Synthetic ATF MILSPEC: MIL-L-46167




8 h std.

250 h std.



MILLER: 218 609
Gates: K060578






MILLER: 197 679
Donaldson: P822858
WIX: 42985



MILLER: 197 676
Donaldson: P821575
WIX: 46438



1000 h / 1 yr std.

Air/Oil Separator
MILLER: 206 747
Ingersoll Rand: 89259337

207 448-C









Note

Follow the storage procedure in the engine owner's manual if the unit will not be used for an extended period.




10-2. Routine Air Compressor Maintenance

NOTE

See Section 9 for engine/generator maintenance information.

      						
			Recycle air compressor fluids.			
			▲ Stop engine before maintaining. 📖 See <i>Compressor Maintenance Label</i> . Service air compressor more often if used in severe conditions. * To be done by Factory Authorized Service Agent.			
 Every 8 h						
		Wipe Up Spills.				Check Compressor Fluid Level. See Section 5-7.
 Every 100 h						
			Check Compressor Air Cleaner Hoses For Cracks And Loose Clamps.			
 Every 250 h						
		Clean Radiator.				Inspect Compressor Air Filter Elements.
						Replace Worn Or Damaged Air/Oil Hoses
		Inspect Belts And Check Tension.				Replace Unreadable Labels.
 Every 500 h / 6 Months						
		Change Compressor Oil. See Section 9-7.				Change Compressor Oil Filter. See Section 9-7. Service more often in dirty conditions.
 Every 1000 h / 1 Year						
			Change Compressor Air/Oil Separator			

10-3. Servicing Compressor Air Cleaner



▲ Stop engine.

▲ Do not run air compressor without air cleaner or with dirty element. Compressor damage caused by using a damaged element is not covered by the warranty.

1 Compressor Air Cleaner

✎ Remove engine air cleaner cover and element to access compressor air cleaner (see Section 9-4)

✎ The air cleaner primary element can be cleaned but the dirt holding capacity of the filter is reduced with each cleaning. The chance of dirt reaching the clean side of the filter while cleaning and the possibility of filter damage makes cleaning a risk. Consider the risk of unwarrantable equipment damage when determining whether to clean or replace the primary element.

*If you decide to clean the primary element, we strongly recommend installing an optional safety element to provide additional air compressor protection. **Never clean a safety element.** Replace the safety element after servicing the primary element three times.*

Clean or replace primary element if dirty (see note above before cleaning). **Replace** primary element if damaged. Replace primary element yearly or after six cleanings.

2 Housing

3 Safety Element

4 Primary Element

5 Cover

6 Dust Ejector

To clean air filter:

Wipe off cover and housing. Remove cover and dump out dust. Remove element(s). Wipe dust from inside cover and housing with damp cloth. Reinstall safety element (if present). Reinstall cover.


▲ Do not clean housing with air hose.

Clean primary element with compressed air only.

Air pressure must not exceed 100 psi (690 kPa). Use 1/8 in (3 mm) nozzle and keep nozzle at least 2 in (51 mm) from inside of element. Replace primary element if it has holes or damaged gaskets.

Reinstall primary element and cover (dust ejector down).

10-4. Compressor Overload Protection



▲ Stop engine.



☞ When a circuit breaker or fuse opens, it usually indicates a more serious problem exists. Contact Factory Authorized Service Agent.

☞ See Section 9-8 for engine/generator overload protection.

1 Circuit Breaker CB15

Circuit breaker CB15 protects the air compressor clutch. If CB15 opens, the compressor does not run and air output stops.

Press button to reset breaker.






10-5. Servicing Air Compressor





Tools Needed:

7/8, 15/16 in



Right Side



803 228

▲ **Stop engine and let cool. Wait 20 seconds for system pressure to drop before changing oil.**

To change compressor oil and filter:

☞ *The engine oil drain and compressor oil drain hoses are located together in the base. Be sure to select the correct hose when draining compressor oil.*

☞ *Be sure o-rings at oil drain and oil fill fittings are in place before reinstalling caps.*

Drain compressor oil while compressor is still warm.

Route compressor oil drain hose through hole in base. Remove compressor oil fill cap. Remove cap from oil drain hose and drain oil into a suitable container. Reinstall oil drain hose cap. Tighten cap with wrench.

Remove filter by turning filter counterclockwise. Remove filter. Apply thin coat of oil to gasket on new filter. Install new filter and turn clockwise until tight.

Add recommended oil until oil level indicator shows system is full (see compressor maintenance label for oil specifications). Reinstall oil fill cap. Tighten cap with wrench.

To replace air/oil separator:

Loosen nut securing tube on separator base. Lift oil scavenge tube from separator. Turn filter counterclockwise. Remove filter.


Apply thin coat of oil to gasket on new filter. Install filter and turn clockwise. Reinstall oil scavenge tube.

Start engine, run air compressor, and check for oil leaks.


▲ **Stop engine.**

- 1 Air Compressor Oil Filter
- 2 Air Compressor Air/Oil Separator
- 3 Air Compressor Oil Drain Hose w/Removable Cap
- 4 Air Compressor Oil Fill Cap
- 5 Air Compressor Oil Level Indicator (On Tank)
- 6 Oil Scavenge Tube

10-6. Adjusting Compressor Air Pressure



Tools Needed:

 5/16, 3/8 in

Check compressor air pressure using air pressure gauge known to be accurate. If necessary, adjust air pressure as follows:

1 Screw


Loosen jam nut securing screw. Turn screw clockwise (increase pressure) or counterclockwise (decrease) until pressure is 125 psi (862 kPa).

 *Maximum weld output is reduced if compressor air pressure is set above 125 psi (862 kPa).*

Tighten nut.


2 Pressure Relief Valve

Pressure relief valve opens and releases pressure at 150 psi (1034 kPa). The pressure relief valve is not adjustable.



SECTION 11 – TROUBLESHOOTING

11-1. Troubleshooting Tables



A. Welding

Trouble	Remedy
No weld output; generator power output okay at ac receptacles.	Place Process/Contactor switch in a Weld Terminals Always On position, or place switch in a Remote On/Off Switch Required position and connect remote contactor to Remote 14 receptacle RC14 (see Sections 5-10 and 6-1).
	Check position of Ampere Range switch.
	Check position of optional Output Selector switch (see Section 8-1).
	Reset circuit breaker CB11 (see Section 9-8).
	Reset circuit breaker CB5 (see Section 9-8). Check for faulty remote device connected to RC14.
	Check and secure connections to Remote 14 receptacle RC14 (see Section 5-10).
	Have Factory Authorized Service Agent check connector board PC6 and connections.
	Check fuse F2, and replace if open (see Section 9-8). Have Factory Authorized Service Agent check brushes and slip rings, field excitation circuit, field current regulator board PC1, and the rotor.
No weld output or generator power output.	Disconnect equipment from generator power receptacles during start-up.
	Check fuses F1 and F2, and replace if open (see Section 9-8). Have Factory Authorized Service Agent check integrated rectifier SR1, capacitor C9, field current regulator board PC1, and the rotor.
	Reset circuit breaker CB12 (see Section 9-8).
	Have Factory Authorized Service Agent check brushes and slip rings, and field excitation circuit.
Erratic weld output.	Check and tighten connections inside and outside unit.
	Be sure connection to work piece is clean and tight.
	Use dry, properly stored electrodes.
	Remove excessive coils from weld cables.
High weld output.	Check position of Ampere Range switch and Voltage/Amperage Adjust control.
	Check engine weld/power speed, and adjust if necessary (see Section 9-6).
	Have Factory Authorized Service Agent check field current regulator board PC1.
Voltage/Amperage control does not work when welding in Stick mode.	Place Ampere Range switch in lower range. Voltage/Amperage control does not work with Ampere Range switch in highest range.
Low weld output.	Check engine weld/power speed, and adjust if necessary (see Section 9-6).
	Check fuses F1 and F2, and replace if open (see Section 9-8). Have Factory Authorized Service Agent check integrated rectifier SR1, capacitor C9, field current regulator board PC1, and the rotor.
Electrode sticks to the workpiece more frequently during low voltage (short arc length) conditions.	Circuit breaker CB4 may be open. CB4 automatically resets when the fault is corrected (see Section 9-8). Have Factory Authorized Service Agent check transformer T1 and integrated rectifiers SR4 and SR5.
	Have Factory Authorized Service Agent check optional battery charging relay CR7.
Low open-circuit voltage.	Check engine weld/power speed, and adjust if necessary.
No remote fine amperage or voltage control.	Place Voltage/Amperage Adjust switch in Remote position.
	Check and secure connections to Remote 14 receptacle RC14 (see Section 5-10).
	Repair or replace remote control device.

Trouble	Remedy
Constant speed wire feeder does not work.	Reset circuit breaker(s) CB5 and CB13 (see Section 9-8).
	Check and secure connections to Remote 14 receptacle RC14 (see Section 5-10).
	Repair or replace wire feeder.
Low CV weld output.	Set Ampere Range switch to highest range.
Min or max CV weld output only.	Check position of Voltage/Amperage Adjust control and Voltage/Amperage Adjust switch.
	Repair or replace remote control device.
	Have Factory Authorized Service Agent check field current regulator board PC1.

B. Standard Generator Power

Trouble	Remedy
No generator power output at ac receptacles; weld output okay.	Reset receptacle circuit breakers.
No generator power or weld output.	Disconnect equipment from generator power receptacles during start-up.
	Check fuses F1 and F2, and replace if open (see Section 9-8). Have Factory Authorized Service Agent check integrated rectifier SR1, capacitor C9, diode/capacitor board D1/C1, and the rotor.
	Reset circuit breaker CB12. Have Factory Authorized Service Agent check field current regulator board PC1 (see Section 10-4).
	Have Factory Authorized Service Agent check brushes and slip rings, and field excitation circuit.
High output at generator power receptacles.	Check engine weld/power speed, and adjust if necessary (see Section 9-6).
	Have Factory Authorized Service Agent adjust field current resistor R3.
Low output at generator power receptacles.	Check engine weld/power speed, and adjust if necessary (see Section 9-6).
	Check fuse F1, and replace if open (see Section 9-8). Have Factory Authorized Service Agent check integrated rectifier SR1, resistor R3, and capacitor C9.

C. Optional AC Power Plant

Trouble	Remedy
No or low output at optional ac power plant/receptacle RC5.	Place Process/Contactor switch in Weld Terminals Always On - Stick position (see Section 6-3).
	Reset circuit breaker CB7 (see Section 7-2).
	Reset circuit breaker CB5 (see Section 9-8).
	Check engine weld/power speed, and adjust if necessary (see Section 9-6).
	Have Factory Authorized Service Agent check brushes and slip rings, and field current regulator board PC1.
High output at optional ac power plant/receptacle RC5.	Check engine weld/power speed, and adjust if necessary (see Section 9-6).
	Have Factory Authorized Service Agent check field current regulator board PC1.
Erratic output at optional ac power plant/receptacle RC5.	Have Factory Authorized Service Agent check brushes and slip rings, and field current regulator board PC1.

D. Engine

Trouble	Remedy
Engine will not crank.	Check battery, and replace if necessary.
	Check battery connections and tighten if necessary.
	Circuit breaker CB10 may be open. CB10 automatically resets when fault is corrected (see Section 9-8). Have Factory Authorized Service Agent check engine wiring harness and components.
	Check engine wiring harness plug connections.
	Turn optional battery disconnect switch to On position (see Section 5-6).
	Have Factory Authorized Service Agent check Engine Control switch S1, control relay CR1, and diode/capacitor board D8/C8.
Engine cranks but does not start.	Check fuel level. Optional low fuel shutdown stops engine if fuel level is low.
	Reset circuit breaker CB13 (see Section 10-4). Have Factory Authorized Service Agent check engine wiring harness and components.
	Check battery and replace if necessary. Check engine charging system according to engine manual.
	Have Factory Authorized Service Agent check time delay relay TD1, control relay CR5, fuel pump, and fuel solenoid FS1.
	Air in fuel system. See engine manual.
Engine starts, but stops when Engine Control switch is released.	Check oil level. Automatic shutdown system stops engine if oil pressure is too low or engine temperature is too high (see Section 5-7).
	Have Factory Authorized Service Agent check time delay relay TD1, and control relay CR5.
Engine hard to start in cold weather.	Use starting aid switch (see Section 6-1). If Starting Aid switch does not work have Factory Authorized Service Agent check Engine Control switch S2, and control relay CR8.
	Keep battery in good condition. Store battery in warm area off cold surface.
	Use fuel formulated for cold weather (diesel fuel can gel in cold weather). Contact local fuel supplier for fuel information.
	Use correct grade oil for cold weather (see Section 9-1).
Engine suddenly stops.	Check fuel level. Optional low fuel shutdown stops engine if fuel level is low.
	Check oil level. Automatic shutdown system stops engine if oil pressure is too low or engine temperature is too high (see Section 5-7).
	Have Factory Authorized Service Agent check time delay relay TD1, control relay CR5, fuel pump, and fuel solenoid FS1.
	See engine manual.
Engine slowly stopped and cannot be restarted.	Check fuel level.
	Check engine air and fuel filters (see Sections 9-4 and 9-7).
	See engine manual.
Battery discharges between uses.	Turn Engine Control switch S1 off when unit is not running.
	Clean top of battery with baking soda and water solution; rinse with clear water.
	Recharge or replace battery if necessary.
	Periodically recharge battery (approximately every 3 months).
Engine idles, but does not come up to weld speed.	Have Factory Authorized Service Agent check idle module PC7.
	Check for obstructed throttle solenoid.

Trouble	Remedy
Engine does not run at idle speed.	Turn Process/Contactor switch to any position but Remote On/Off Switch Required-TIG.
	Check for obstructed throttle solenoid.
	Allow circuit breaker CB14 to reset. Have Factory Authorized Service Agent check throttle solenoid TS1 and linkage (see Section 9-8).
	Have Factory Authorized Service Agent check idle module PC7, control relays CR3 and CR6, and current transformer CT1.
Engine uses oil during run-in period; wetstacking occurs.	Dry engine (see Section 13).

E. Air Compressor

Trouble	Remedy
Air compressor does not operate; no air pressure at air shutoff valve.	Place Air Compressor switch in On position. The air compressor will not start if still under pressure. If compressor is turned off, wait for air pressure to bleed off (about 20 seconds) before turning compressor on again.
	Reset circuit breaker CB15 (see Section 10-4).
	Check compressor belt tension. Be sure correct belt is used and is properly installed.
	Have Factory Authorized Service Agent check Air Compressor switch S10, control relay CR10, air pressure switch S11, temperature switch S12, compressor control circuit, and air compressor clutch.
Air compressor stops after short period of operation.	Check compressor oil level (see Section 5-7). Automatic shutdown stops compressor if compressor temperature is too high.
	Clean debris from radiator. Automatic shutdown stops compressor if compressor temperature is too high.
Low air pressure.	Check for leaks in air lines and hoses.
	Adjust compressor air pressure (see Section 10-6).
	Check air compressor air cleaner (see Section 10-3).
	Have Factory Authorized Service Agent check compressor for rated output.
High air pressure.	Adjust compressor air pressure (see Section 10-6).
	Be sure control line is connected at regulator valve and inlet valve.
Pneumatic tools freeze up because of moisture in compressed air.	Install optional air dryer/filter kit (Part No. 195 117).
Oil in air from compressor.	Check compressor oil level (see Section 5-7). If oil level is too high, system becomes saturated with oil.
	Change compressor air/oil separator (see Section 10-5).
	Check connections of control lines (see air compressor circuit diagram in Section 12).
	Have Factory Authorized Service Agent check for blocked separator scavenge check valve/filter orifice.
Oil in compressor air cleaner.	Have Factory Authorized Service Agent verify compressor inlet valve is operating properly.

F. Optional Battery Charging

Trouble	Remedy
No battery charge output; weld output okay.	Place Output Selector switch in 12 Volt Charge or 24 Volt Charge position.
	Check and tighten battery connections if necessary.
	Turn on remote control device or turn Process/Contactor switch to any Weld Terminals Always On position (see Section 6-3).
No battery charge or weld output.	Disconnect equipment from generator power receptacles during start-up.
	Check fuses F1 and F2, and replace if open (see Section 9-8). Have Factory Authorized Service Agent check integrated rectifier SR1, capacitor C9, field current regulator board PC1, and the rotor.
	Reset circuit breaker CB12 (see Section 9-8).
	Have Factory Authorized Service Agent check brushes and slip rings, field current regulator board PC1, and field excitation circuit.

SECTION 12 – AIR COMPRESSOR DIAGRAM




Figure 12-1. Circuit Diagram For Air Compressor

PLG1/RC1

100 1 100
105 2 105
101 3 101
103 4 103
106 5 106
104 6 104
108 7 108
102 8 102
109 9

S1	OFF	RUN	RUN/IDLE	START
A				
B	X	X	X	
C				X
D			X	

X = CLOSED TO "A" TERMINAL

PLG3/RC3

136 1 136
42 2 42
102 3 102
103 4 103
106 5 106
105 6 105
108 7 108
109 8 109
110 9
111 10
113 11
113 12

PLG4/RC4

131 1 131
132 2 132
133 3 133
130 4 130

PLG6/RC6

125 1 125
126 2 126
36 3 36
4 4

PLG10/RC10

134 1 134
135 2 135
136 3 136
4 4
5 5
6 6

PLG13

139 1
2
3
4
5
6
7
8
9
10
11
12

S6		REMOTE		ELECTRODE HOT	
SWITCH NUMBERS	LEAD NUMBERS	TIG	STICK	MIG	STICK
1-2	119-120	X	X	X	X
2-3	120-121			X	X
5-6	122-123			X	X
6-7	123-124	X			
9-10	48-68	X	X	X	X
11-12	84-98			X	

X = CONTACT CLOSED

PLG14

87 1
121 2
121 3
119 4
118 5
117 6
116 7
116 8
83 9
83 10















Figure 13-1. Circuit Diagram For Welding Generator



SECTION 13 – RUN-IN PROCEDURE

run_in1 8/01

13-1. Wetstacking



▲ **Do not perform run-in procedure at less than 20 volts weld output and do not exceed duty cycle or equipment damage may occur.**

1 Welding Generator

Run diesel engines near rated voltage and current during run-in period to properly seat piston rings and prevent wetstacking. See nameplate, rating label, or specifications section in this manual to find rated voltage and current.

☞ *Do not idle engine longer than necessary. Piston rings seat faster if engine runs at weld/power rpm, and the welding generator is kept loaded during run-in.*


2 Engine Exhaust Pipe

Wetstacking is unburned fuel and oil in the exhaust pipe and occurs during run-in if the engine is run too long at light load or idle rpm.

If exhaust pipe is coated with a wet, black, tar-like substance, dry the engine using one of the following run-in procedures.

See the engine manual for additional engine run-in information.

13-2. Run-In Procedure Using Load Bank



▲ Stop engine.

▲ Do not touch hot exhaust pipe, engine parts, or load bank/grid.

▲ Keep exhaust and pipe away from flammables.

▲ Do not perform run-in procedure at less than 20 volts weld output and do not exceed duty cycle or equipment damage may occur.

1 Load Bank

Turn all load bank switches Off. If needed, connect load bank to 115 volts ac wall receptacle or generator auxiliary power receptacle.

2 Welding Generator

Place A/V range switch in maximum position, A/V control in minimum position, and Output Selector switch (if present) in either DC position.

3 Weld Cables

Connect load bank to generator weld output terminals using proper size weld cables with correct connectors. Observe correct polarity.

Start engine and run for several minutes.

Set load bank switches and then adjust generator A/V control so load equals rated voltage and current of generator (see nameplate, rating label, or the specifications section in this manual).

Check generator and load bank meters after first five minutes then every fifteen minutes to be sure generator is loaded properly.

Check oil level frequently during run-in; add oil if needed.


After one hour (minimum) place A/V control in minimum position, then turn off load bank to remove load. Run engine several minutes at no load.

▲ Stop engine and let cool.

4 Engine Exhaust Pipe

Repeat procedure if wetstacking is present.

13-3. Run-In Procedure Using Resistance Grid



- ▲ **Stop engine.**
- ▲ **Do not touch hot exhaust pipe, engine parts, or load bank/grid.**
- ▲ **Keep exhaust and pipe away from flammables.**
- ▲ **Do not perform run-in procedure at less than 20 volts weld output and do not exceed duty cycle or equipment damage may occur.**

1 Resistance Grid

Use grid sized for generator rated output.

Turn Off grid.

2 Welding Generator

Place A/V range switch in maximum position, A/V control in minimum position, and Output Selector switch (if present) in either DC position.

3 Weld Cables

Connect grid to generator weld output terminals using proper size weld cables with correct connectors (polarity is not important).

4 Voltmeter

5 Clamp-On Ammeter

Connect voltmeter and ammeter as shown, if not provided on generator.

Start engine and run for several minutes.

Set grid switches and then adjust generator A/V control so load equals rated voltage and current of the generator (see nameplate, rating label, or the specifications section in this manual).

Check generator and meters after first five minutes then every fifteen minutes to be sure generator is loaded properly.

☞ *Check oil level frequently during run-in; add oil if needed.*

After one hour (minimum), place A/V control in minimum position, then shut down grid to remove load. Run engine several minutes at no load.

▲ **Stop engine and let cool.**

6 Engine Exhaust Pipe

Repeat procedure if wetstacking is present.

SECTION 14 – AIR COMPRESSOR TABLES

14-1. Flow Of Free Air (CFM) Through Orifices Of Various Diameters

Gauge Pressure (psi)	Orifice Diameter (in) And Free Air Flow (CFM)							
	1/64	1/32	3/64	1/16	3/32	1/8	3/16	1/4
1	0.027	0.107	0.242	0.430	0.97	1.72	3.86	6.85
2	0.038	0.153	0.342	0.607	1.36	2.43	5.42	9.74
3	0.046	0.188	0.471	0.750	1.68	2.98	6.71	11.9
5	0.059	0.242	0.545	0.965	2.18	3.86	8.71	15.4
10	0.084	0.342	0.77	1.36	3.08	5.45	12.3	21.8
15	0.103	0.418	0.94	1.67	3.75	6.65	15.0	26.7
20	0.119	0.485	1.07	1.93	4.25	7.7	17.1	30.8
25	0.133	0.54	1.21	2.16	4.75	8.6	19.4	34.5
30	0.156	0.632	1.40	2.52	5.6	10.0	22.5	40.0
35	0.173	0.71	1.56	2.80	6.2	11.2	25.0	44.7
40	0.19	0.77	1.71	3.07	6.8	12.3	27.3	49.1
45	0.208	0.843	1.9	3.36	7.6	13.4	30.3	53.8
50	0.225	9.14	2.05	3.64	8.2	14.5	32.8	58.2
60	0.26	1.05	2.35	4.2	9.4	16.8	37.5	67.0
70	0.295	1.19	2.68	4.76	10.7	19.0	43.0	76.0
80	0.33	1.33	2.97	5.32	11.9	21.2	47.5	85.0
90	0.364	1.47	3.28	5.87	13.1	23.5	52.5	94.0
100	0.40	1.61	3.66	6.45	14.5	25.8	58.3	103.0
110	0.43	1.76	3.95	7.00	15.7	28.0	63.0	112.0
120	0.47	1.90	4.27	7.58	17.0	30.2	68.0	121.0
130	0.50	2.04	4.57	8.13	18.2	32.4	73.0	130.0
140	0.54	2.17	4.87	8.68	19.5	34.5	78.0	138.0
150	0.57	2.33	5.2	9.20	20.7	36.7	83.0	147.0
175	0.66	2.65	5.94	10.6	23.8	42.1	95.0	169.0
200	0.76	3.07	6.90	12.2	27.5	48.7	110.0	195.0

14-2. Approximate Air Consumption (Cubic Feet) To Operate Pneumatic Equipment At 70-90 P.S.I.G.

MISCELLANEOUS PORTABLE TOOLS	Percent Use Factor And Compressed Air Consumption (CF)				MISCELLANEOUS PORTABLE TOOLS	Percent Use Factor And Compressed Air Consumption (CF)			
	9 sec	15 sec	21 sec	1 min		9 sec	15 sec	21 sec	1 min
Drill, 1/18" to 3/8"	3.75	6.25	8.75	25	Burring Tool, Large	3.6	6.0	8.4	24
Drill, 3/8" to 5/16"	5.25	8.75	12.25	35	Rammers, Small	3.9	3.25	9.1	13
Screwdriver, #2 to #6 Screw	1.8	3.0	4.2	12	Rammers, Medium	5.1	8.5	11.9	34
Screwdriver, #6 to 5/16" Screw	3.6	6.0	8.4	24	Rammers, Large	6.0	10.0	14.0	40
Tapper, to 3/8"	3.0	5.0	7.0	20	Backfill Tamper	3.75	6.25	8.75	25
Nutsetters, to 3/8"	3.6	6.0	8.4	24	Compression Riveter	0.2 cu. ft. per cycle			
Nutsetters, to 3/4"	4.5	7.5	10.5	30	Air Motor, 1 Horsepower	3.75	6.3	8.75	25
Impact Wrench, 1/4"	2.25	3.75	5.3	15	Air Motor, 2 Horsepower	7.5	12.5	17.5	50
Impact Wrench, 3/8"	3.0	5.0	7.0	20	Air Motor, 3 Horsepower	11.25	18.75	26.3	75
Impact Wrench, 5/8"	4.5	7.5	10.5	30	Paint Spray Gun (Production)	3.0	5.00	7.00	20
Impact Wrench, 3/4"	5.25	8.75	12.25	35	,HAMMERS				
Impact Wrench, 1"	6.75	11.25	15.75	45					
Impact Wrench, 1-1/4"	8.25	13.75	19.2	55	Scaling Hammer	1.3	3.0	4.2	12
Die Grinder, Small	2.25	3.75	5.3	15	Chipping Hammer	4.5	7.5	10.5	30
Die Grinder, Medium	3.6	6.0	8.4	24	Riveting Hammer, Light	2.25	3.75	5.25	15
Horizontal Grinder, 2"	3.0	5.0	7.0	20	Riveting Hammer, Heavy	4.5	7.5	10.5	30
Horizontal Grinder, 4"	9.0	15.0	21.0	60	SAWS				
Horizontal Grinder, 6"	9.0	15.0	21.0	60					
Horizontal Grinder, 8"	12.0	20.0	28.0	80	Circular, 8"	6.75	11.25	15.75	45
Vertical Grinders and Sanders, 5" Pad	5.25	8.75	12.25	35	Circular, 12"	9.75	16.25	23.8	65
Vertical Grinders and Sanders, 7" Pad	9.0	15.0	21.0	60	Chain, Lightweight	4.20	7.0	9.8	28
Vertical Grinders and Sanders, 9" Pad	10.5	17.5	24.5	70	Chain, Heavy Duty	13.1	21.8	30.5	87
Burring Toll, Small	2.25	3.75	5.3	15					

Always check with tool manufacturers for actual air consumption of tools being used. The above is based on averages and should not be considered accurate for any particular make of tool.

Above tools are rated based upon typical "on-load" performance characteristics.

For other values, adjust the C.F. air consumption on a proportional basis.



The cubic feet (C.F.) air consumption for 1 minute may also be expressed as air consumption in cubic feet per minute (C.F.M.)

SECTION 15 – GENERATOR POWER GUIDELINES

NOTE

The views in this section are intended to be representative of all engine-driven welding generators. Your unit may differ from those shown.

15-1. Selecting Equipment






- 1 Generator Power Receptacles – Neutral Bonded To Frame
- 2 3-Prong Plug From Case Grounded Equipment
- 3 2-Prong Plug From Double Insulated Equipment

▲ **Do not use 2-prong plug unless equipment is double insulated.**

gen_pwr 11/02 – Ref. ST-159 730 / ST-800 577

15-2. Grounding Generator To Truck Or Trailer Frame



▲ **Always ground generator frame to vehicle frame to prevent electric shock and static electricity hazards.**

- 1 Equipment Grounding Terminal (On Front Panel)
- 2 Grounding Cable (Not Supplied)
- 3 Metal Vehicle Frame

Connect cable from equipment ground terminal to metal vehicle frame. Use #10 AWG or larger insulated copper wire.


▲ **If unit does not have GFCI receptacles, use GFCI-protected extension cord.**

Electrically bond generator frame to vehicle frame by metal-to-metal contact.

▲ **Bed liners, shipping skids, and some running gear insulate the welding generator from the vehicle frame. Always connect a ground wire from the generator equipment grounding terminal to bare metal on the vehicle frame as shown.**


S-0854

15-3. Grounding When Supplying Building Systems



ST-800 576-B

15-4. How Much Power Does Equipment Require?



$$\text{AMPERES} \times \text{VOLTS} = \text{WATTS}$$

EXAMPLE 1: If a drill uses 4.5 amperes at 115 volts, calculate its running power requirement in watts.

$$4.5 \text{ A} \times 115 \text{ V} = 520 \text{ W}$$

The load applied by the drill is 520 watts.

EXAMPLE 2: If three 200 watt flood lamps are used with the drill from Example 1, add the individual loads to calculate total load.

$$(200 \text{ W} + 200 \text{ W} + 200 \text{ W}) + 520 \text{ W} = 1120 \text{ W}$$

The total load applied by the three flood lamps and drill is 1120 watts.

S-0623

15-5. Approximate Power Requirements For Industrial Motors

Industrial Motors	Rating	Starting Watts	Running Watts
Split Phase	1/8 HP	800	300
	1/6 HP	1225	500
	1/4 HP	1600	600
	1/3 HP	2100	700
	1/2 HP	3175	875
Capacitor Start-Induction Run	1/3 HP	2020	720
	1/2 HP	3075	975
	3/4 HP	4500	1400
	1 HP	6100	1600
	1-1/2 HP	8200	2200
	2 HP	10550	2850
	3 HP	15900	3900
	5 HP	23300	6800
Capacitor Start-Capacitor Run	1-1/2 HP	8100	2000
	5 HP	23300	6000
	7-1/2 HP	35000	8000
	10 HP	46700	10700
Fan Duty	1/8 HP	1000	400
	1/6 HP	1400	550
	1/4 HP	1850	650
	1/3 HP	2400	800
	1/2 HP	3500	1100


15-6. Approximate Power Requirements For Farm/Home Equipment

Farm/Home Equipment	Rating	Starting Watts	Running Watts
Stock Tank De-Icer		1000	1000
Grain Cleaner	1/4 HP	1650	650
Portable Conveyor	1/2 HP	3400	1000
Grain Elevator	3/4 HP	4400	1400
Milk Cooler		2900	1100
Milker (Vacuum Pump)	2 HP	10500	2800
FARM DUTY MOTORS	1/3 HP	1720	720
Std. (e.g. Conveyors,	1/2 HP	2575	975
Feed Augers, Air	3/4 HP	4500	1400
Compressors)	1 HP	6100	1600
	1-1/2 HP	8200	2200
	2 HP	10550	2850
	3 HP	15900	3900
	5 HP	23300	6800
High Torque (e.g. Barn	1-1/2 HP	8100	2000
Cleaners, Silo Unloaders,	5 HP	23300	6000
Silo Hoists, Bunk Feeders)	7-1/2 HP	35000	8000
	10 HP	46700	10700
3-1/2 cu. ft. Mixer	1/2 HP	3300	1000
High Pressure 1.8 Gal/Min	500 PSI	3150	950
Washer 2 gal/min	550 PSI	4500	1400
2 gal/min	700 PSI	6100	1600
Refrigerator or Freezer		3100	800
Shallow Well Pump	1/3 HP	2150	750
	1/2 HP	3100	1000
Sump Pump	1/3 HP	2100	800
	1/2 HP	3200	1050

15-7. Approximate Power Requirements For Contractor Equipment

Contractor	Rating	Starting Watts	Running Watts
Hand Drill	1/4 in	350	350
	3/8 in	400	400
	1/2 in	600	600
Circular Saw	6-1/2 in	500	500
	7-1/4 in	900	900
	8-1/4 in	1400	1400
Table Saw	9 in	4500	1500
	10 in	6300	1800
Band Saw	14 in	2500	1100
Bench Grinder	6 in	1720	720
	8 in	3900	1400
	10 in	5200	1600
Air Compressor	1/2 HP	3000	1000
	1 HP	6000	1500
	1-1/2 HP	8200	2200
	2 HP	10500	2800
Electric Chain Saw	1-1/2 HP, 12 in	1100	1100
	2 HP, 14 in	1100	1100
Electric Trimmer	Standard 9 in	350	350
	Heavy Duty 12 in	500	500
Electric Cultivator	1/3 HP	2100	700
Elec. Hedge Trimmer	18 in	400	400
Flood Lights	HID	125	100
	Metal Halide	313	250
	Mercury	1000	
	Sodium	1400	
	Vapor	1250	1000
Submersible Pump	400 gph	600	200
Centrifugal Pump	900 gph	900	500
Floor Polisher	3/4 HP, 16 in	4500	1400
	1 HP, 20 in	6100	1600
High Pressure Washer	1/2 HP	3150	950
	3/4 HP	4500	1400
	1 HP	6100	1600
55 gal Drum Mixer	1/4 HP	1900	700
Wet & Dry Vac	1.7 HP	900	900
	2-1/2 HP	1300	1300

15-8. Power Required To Start Motor



- 1 Motor Start Code
- 2 Running Amperage
- 3 Motor HP
- 4 Motor Voltage

To find starting amperage:

Step 1: Find code and use table to find kVA/HP. If code is not listed, multiply running amperage by six to find starting amperage.

Step 2: Find Motor HP and Volts.

Step 3: Determine starting amperage (see example).

Welding generator amperage output must be at least twice the motor's running amperage.

Single-Phase Induction Motor Starting Requirements

Motor Start Code	G	H	J	K	L	M	N	P
KVA/HP	6.3	7.1	8.0	9.0	10.0	11.2	12.5	14.0

$$\frac{\text{kVA/HP} \times \text{HP} \times 1000}{\text{VOLTS}} = \text{STARTING AMPERAGE}$$


EXAMPLE: Calculate the starting amperage required for a 230 V, 1/4 HP motor with a motor start code of M.

Volts = 230 HP = 1/4 Using Table, Code M results in kVA/HP = 11.2

$$\frac{11.2 \times 1/4 \times 1000}{230} = 12.2 \text{ A} \quad \text{Starting the motor requires 12.2 amperes.}$$

S-0624

15-9. How Much Power Can Generator Supply?




- 1 Limit Load To 90% Of Generator Output

Always start non-resistive (motor) loads in order from largest to smallest, and add resistive loads last.

- 2 5 Second Rule

If motor does not start within 5 seconds, turn off power to prevent motor damage. Motor requires more power than generator can supply.

▲ Properly install and ground this equipment according to its Owner's Manual and national, state, and local codes.



- ▲ Have only qualified persons perform these connections according to all applicable codes and safety practices.
- ▲ Properly install and ground this equipment according to its Owner's Manual and national, state, and local codes.

 *Customer-supplied equipment is required if generator will supply standby power during emergencies or power outages.*

- 1 Utility Electrical Service
- 2 Transfer Switch (Double-Throw)

Switch transfers the electrical load from electric utility service to the generator. Transfer load back to electric utility when service is restored.

Install correct switch (customer-supplied). Switch rating must be same as or greater than the branch overcurrent protection.

3 Fused Disconnect Switch

Install correct switch (customer-supplied) if required by electrical code.

4 Welding Generator Output

Generator output voltage and wiring must be consistent with regular (utility) system voltage and wiring.


Connect generator with temporary or permanent wiring suitable for the installation.

Turn off or unplug all equipment connected to generator before starting or stopping engine. When starting or stopping, the engine has low speed which causes low voltage and frequency.

5 Essential Loads

Generator output may not meet the electrical requirements of the premises. If generator does not produce enough output to meet all requirements, connect only essential loads (pumps, freezers, heaters, etc. – See Section 15-4).

Notes



Work like a Pro!

Pros weld and cut safely. Read the safety rules at the beginning of this manual.

15-11. Selecting Extension Cord (Use Shortest Cord Possible)



Cord Lengths for 120 Volt Loads

▲ If unit does not have GFCI receptacles, use GFCI-protected extension cord.

Current (Amperes)	Load (Watts)	Maximum Allowable Cord Length in ft (m) for Conductor Size (AWG)*					
		4	6	8	10	12	14
5	600			350 (106)	225 (68)	137 (42)	100 (30)
7	840		400 (122)	250 (76)	150 (46)	100 (30)	62 (19)
10	1200	400 (122)	275 (84)	175 (53)	112 (34)	62 (19)	50 (15)
15	1800	300 (91)	175 (53)	112 (34)	75 (23)	37 (11)	30 (9)
20	2400	225 (68)	137 (42)	87 (26)	50 (15)	30 (9)	
25	3000	175 (53)	112 (34)	62 (19)	37 (11)		
30	3600	150 (46)	87 (26)	50 (15)	37 (11)		
35	4200	125 (38)	75 (23)	50 (15)			
40	4800	112 (34)	62 (19)	37 (11)			
45	5400	100 (30)	62 (19)				
50	6000	87 (26)	50 (15)				

*Conductor size is based on maximum 2% voltage drop

Cord Lengths for 240 Volt Loads

▲ If unit does not have GFCI receptacles, use GFCI-protected extension cord.

Current (Amperes)	Load (Watts)	Maximum Allowable Cord Length in ft (m) for Conductor Size (AWG)*					
		4	6	8	10	12	14
5	1200			700 (213)	450 (137)	225 (84)	200 (61)
7	1680		800 (244)	500 (152)	300 (91)	200 (61)	125 (38)
10	2400	800 (244)	550 (168)	350 (107)	225 (69)	125 (38)	100 (31)
15	3600	600 (183)	350 (107)	225 (69)	150 (46)	75 (23)	60 (18)
20	4800	450 (137)	275 (84)	175 (53)	100 (31)	60 (18)	
25	6000	350 (107)	225 (69)	125 (38)	75 (23)		
30	7000	300 (91)	175 (53)	100 (31)	75 (23)		
35	8400	250 (76)	150 (46)	100 (31)			
40	9600	225 (69)	125 (38)	75 (23)			
45	10,800	200 (61)	125 (38)				
50	12,000	175 (53)	100 (31)				

*Conductor size is based on maximum 2% voltage drop

SECTION 16 – SELECTING AND PREPARING TUNGSTEN ELECTRODE

gtaw 7/97

NOTE

For additional information, see your distributor for a handbook on the Gas Tungsten Arc Welding (GTAW) process. Wear clean gloves to prevent contamination of tungsten electrode.

16-1. Selecting Tungsten Electrode


Electrode Diameter	Amperage Range - Gas Type ♦ - Polarity			
	DC – Argon – Electrode Negative/Straight Polarity	DC – Argon – Electrode Positive/Reverse Polarity	AC – Argon – Using High Frequency	AC – Argon – Balanced Wave Using High Freq.
Pure Tungsten (Green Band)				
.010"	Up to 15	*	Up to 15	Up to 10
.020"	5-20	*	5-20	10-20
.040"	15-80	*	10-60	20-30
1/16"	70-150	10-20	50-100	30-80
3/32"	125-225	15-30	100-160	60-130
1/8"	225-360	25-40	150-210	100-180
5/32"	360-450	40-55	200-275	160-240
3/16"	450-720	55-80	250-350	190-300
1/4"	720-950	80-125	325-450	250-400
2% Thorium Alloyed Tungsten (Red Band)				
.010"	Up to 25	*	Up to 20	Up to 15
.020"	15-40	*	15-35	5-20
.040"	25-85	*	20-80	20-60
1/16"	50-160	10-20	50-150	60-120
3/32"	135-235	15-30	130-250	100-180
1/8"	250-400	25-40	225-360	160-250
5/32"	400-500	40-55	300-450	200-320
3/16"	500-750	55-80	400-500	290-390
1/4"	750-1000	80-125	600-800	340-525
Zirconium Alloyed Tungsten (Brown Band)				
.010"	*	*	Up to 20	Up to 15
.020"	*	*	15-35	5-20
.040"	*	*	20-80	20-60
1/16"	*	*	50-150	60-120
3/32"	*	*	130-250	100-180
1/8"	*	*	225-360	160-250
5/32"	*	*	300-450	200-320
3/16"	*	*	400-550	290-390
1/4"	*	*	600-800	340-525

♦ Typical argon shielding gas flow rates are 15 to 35 cfh (cubic feet per hour).

*Not Recommended.

The figures listed are intended as a guide and are a composite of recommendations from American Welding Society (AWS) and electrode manufacturers.

16-2. Preparing Tungsten For AC Or DC Electrode Positive (DCEP) Welding




- 1 Tungsten Electrode
- 2 Balled End

▲ Understand and follow safety symbols at start of Section 17-1 before preparing tungsten.

Ball end of tungsten before welding by applying either an ac amperage slightly higher than what is recommended for a given electrode diameter (see Section 16-1), or a dc electrode positive amperage.


Ref. S-0161

16-3. Preparing Tungsten For DC Electrode Negative (DCEN) Welding



- 1 Tungsten Electrode
- 2 Tapered End


Grind end of tungsten on fine grit, hard abrasive wheel before welding. Do not use wheel for other jobs or tungsten can become contaminated causing lower weld quality.



Ideal Tungsten Preparation – Stable Arc

- 1 Stable Arc
- 2 Flat
- 3 Grinding Wheel
- 4 Straight Ground

Diameter of this flat determines amperage capacity.



Wrong Tungsten Preparation – Wandering Arc

- 1 Arc Wander
- 2 Point
- 3 Grinding Wheel
- 4 Radial Ground


Ref. S-0161 / Ref. S-0162

SECTION 17 – GUIDELINES FOR TIG WELDING (GTAW)

17-1. Positioning The Torch



▲ Weld current can damage electronic parts in vehicles. Disconnect both battery cables before welding on a vehicle. Place work clamp as close to the weld as possible.



1 Workpiece

Make sure workpiece is clean before welding.

2 Work Clamp

Place as close to the weld as possible.

3 Torch

4 Filler Rod (If Applicable)

5 Tungsten Electrode

Select and prepare tungsten according to Sections 16-1, and 16-2 or 16-3.

Tungsten extension is the distance the tungsten extends out gas cup of torch.


Arc length is the distance from the tungsten to the workpiece.

As a general guide, start with an extension and arc length equal to diameter of tungsten.


ST-161 892

17-2. Torch Movement During Welding

Tungsten Without Filler Rod




Tungsten With Filler Rod





ST-162 002-B

17-3. Positioning Torch Tungsten For Various Weld Joints



Butt Weld And Stringer Bead





"T" Joint



Lap Joint



Corner Joint



SECTION 18 – PARTS LIST

 Hardware is common and not available unless listed.





Figure 18-1. Main Assembly



Item No.	Dia. Mkgs.	Part No.	Description	Quantity
Figure 18-1. Main Assembly				
1		189824	Panel, Gen LH	1
2		189828	Panel, Engine Side	1
3		206601	Panel, Engine Extension LH	1
4	Z1	208277	Reactor, AC Environmental Rda	1
5	CR7	♦188636	Relay, OCV Control (Battery Charging)	1
6		♦081499	Bracket, Mtg Strip Terminal (Battery Charging)	1
7		038620	Link, Jumper Term Blk 30 Amp	1
	1T	189549	Block, Term Assy Standard W/Clamp (includes)	1
8		038621	Block, Term 30 Amp 4 Pole Frict Term Str Both Side	1
9		081499	Bracket, Mtg Strip Terminal	1
		138027	Edge Trim, Style TI750-b2x1/16 Black W/Clips 3.750	2
		020225	Clamp, Nyl .875 Clamp Dia X.500 Wide .203 Mtg Hole	1
10	SR4, SR5	035704	Rectifier, Integ Bridge 40 Amp 800 V	2
11	CB4	045061	Circuit Breaker, Auto Reset 24vdc 7 Amp	1
12		206352	Brace, Front To Center Upright	2
13	T1	205636	Transformer, W/Brkt Environmental	1
14		201697	Pan, Reactor And Rectifier	1
15		173352	Extrusion, Rubber (order by ft.)	1
16		189708	Firewall, Top	1
17		194485	Hose, Air Cleaner	1
18		189764	Air Cleaner, Intake (Engine) (includes)	1
		*192938	Filter, Air Element Primary	1
		*192939	Filter, Air Element Safety	1
		206556	Pipe, Air Cleaner Intake Deutz (Turbo Hose To Air Cleaner Hose)	1
19		189763	Bracket, Mtg Air Cleaner	1
20		206351	Upright, Center Assy	1
21		189464	Seal, Weather Lift Eye	1
22		197613	Air Cleaner, Intake 5.250 In (Compressor) (includes)	1
23		197675	Dust Ejector, Air Cleaner	1
		*197676	Element, Air Cleaner	1
		197677	Cover Assy, Air Cleaner	1
		197678	Body, Air Cleaner	1
		*197679	Element, Air Cleaner Safety	1
24		197829	Bracket, Mtg Air Cleaner	1
25		206696	Hose, Elbow Air Cleaner/Compressor	1
26		198457	Tube, Air Intake Perkins 104	1
27		206697	Hose, Elbow Air Cleaner/Compressor 180 Degree	1
28		207268	Hose, Cwc Flexaust 2.000 Id X 22.000	1
29		+219140	Bracket, Mtg Air Cleaner	1
30		210151	Label, Air Cleaner Location	1
31		♦209612	Lever, Switch Lockout Disconnect Battery	1
32		♦209597	Bracket, Mtg Battery Disconnect Switch	1
33		♦209611	Switch, Disc Battery 2P 6-36 Volts	1
34		196220	Bracket, Holddown Fuel Tank Rear	1
35		192362	Bracket, Mtg Nyl 1/2 Conduit	1
36		+206603	Cover, Top	1
37		189052	Grommet, Plastic Neck Filler Fuel	1
38		190198	Cap, Tank Screw-on 3.500 In W/Vent W/Lanyard 8"	1
39		176103	Label, Use Diesel Fuel Only	1
40		176104	Label, Warning Falling Equipment Can Cause Serious	1
41		♦143915	Mount, Sgl Stud 1.5 Dia X 1.000 Lg .312-18 Stud	1
42		♦205702	Bracket, Mtg Spark Arrestor	1
43		♦205749	Pipe, Exhaust Elbow	1
44		♦603767	Cap, Weather Exhaust No. 3	1
45		♦010875	Clamp, Muffler 2.000 Dia U Pld	3
46		♦205712	Spark Arrestor	1
47		♦205748	Pipe, Exhaust Elbow	1

Item No.	Dia. Mkgs.	Part No.	Description	Quantity
Figure 18-1. Main Assembly (Continued)				
48		176230	Label, Hot Exhaust Parts Do Not Touch	1
49		213895	Manifold, Exhaust Muffler Bf4m2011 Deutz	1
50		202633	Support, Cover E-coat	1
51	Figure 18-6		Air Compressor Assembly	1
52		191577	Guard, Starter Deutz	1
53		191809	Bracket, Mtg Engine LH	1
54		209632	Hose, Tubing Oil Assyw/Fittings 22.380lg	1
55		218619	Engine, Deutz Dsl Elec Bf4m2011 (includes)	1
		193256	Adapter, Engine Deutz 1011	1
		195748	Flywheel, Deutz	1
		195746	Sender, Coolant Temp & 130c Switch	1
		195745	Switch, Pressure Oil 1.5 Bar Nc Cont	1
		*067265	Oil Filter	1
		*066217	Secondary Fuel Filter	1
		208041	Spacer, Stl .323 Id X .625 Od X .141 Thk (Alternator)	1
		193230	Sender, Pressure Oil 0- 100 Psi	1
		194403	Adaptor, Oil Pressure Sender	1
	GLOW PLUG	190059	Glow Plug	1
56		207203	Fan, Engine Cooling 18.000 Suction	1
		208042	Spacer, Stl .800id X 1.188od X .090 Thk (Fan Hub Bolt)	1
57		*207808	Belt, V .375 X 45.125 Lg	1
58		209675	Extension, Hydraulic 37 Deg Flare	1
59		209633	Hose, Tubing Oil Assyw/Fittings 27.040lg	1
60		209621	Ftg, Stl Adapter 3/4 Sae-3/4 Jic	1
61		207269	Guard, Fan LH	1
62		206749	Shroud, Fan Air Pak	1
63		206558	Cooler, Oil Engine/Compressor	1
64		209623	Ftg, Brs Adapter Long 3/4 Sae-3/4 Jic	1
65		201749	Upright, Rear Radiator	1
66		201006	Bolt, J Stl .312-18 X 7.750 Pld	2
67	BATT	190897	Battery, Stor 12v 650 Crk 110 Rsv Gp 24 Maint Free	1
68		108081	Terminal Protector, Battery Post Mtg	2
69		190206	Cable, Bat Neg 42 In Lg 2 Awg W/Clamp & .375 Rng	1
70		190207	Cable, Bat Pos 45 In Lg No 1 Awg W/Clamp & .406 Rng	1
71		203430	Bracket, Battery Holddown	1
72		+201183	Cover, Battery Access	1
73		176108	Label, Warning Battery Explosion Can Blind	1
74		176106	Label, Warning Moving Parts Can Cause Serious	8
75		+206602	Panel, Engine Extension R.H.	1
76		207270	Guard, Fan RH	1
77		210229	Label, Compressor Oil Fill	1
78	Figure 18-6		Air Compressor Assembly	1
79		208024	Pulley, Fan Assy W/Bearings	1
80		206613	Bracket, Mtg Fan/Alternator	1
81		199849	Screw, 625-11x4.00 Hex Hd-pln Gr5 Pld	4
82		071731	Washer, Flat .656idx2.250odx.187t Stl Pld	4
83		191812	Bracket, Mtg Engine R.h.	1
84		071890	Retainer, Mount Eng/Gen	4
85		071730	Tubing, Stl .875 Od X12ga Wall X 2.500	4
86		083476	Mount, Eng/Gen Nprn .875id X 2.500od X 2.000 60 Dur	4
87		135205	Nut, 625-11 .94hex .77h Stl Pld Elastic Stop Nut	4

Item No.	Dia. Mkgs.	Part No.	Description	Quantity
Figure 18-1. Main Assembly (Continued)				
		199505	Hose Assy, Oil Drain 32.000 Lg (includes)	1
88		165271	Valve, Oil Drain 3/8-18 Nptf	1
89		176529	Ftg, Hose Brs Barbed Fem 1/2 Tbg X 3/8 Npt	1
90		113854	Hose, Sae .500 Id X .780 Od Xcoil	2.666
91		176528	Ftg, Hose Brs Barbed Elbow M 1/2 Tbg X 1/2 Npt	1
92		173336	Ftg, Adapter Oil Drain	1
93		066298	Ring (Oil Drain)	1
94		218003	Bracket, Mtg Fuel Filter/Solenoid	1
95		206297	Base, Fuel Filter Assy	1
96		*192744	Filter, Fuel Spin-on	1
		199383	Hose, Sae .312 Id X .560 Od X 8.000 (Fuel Filter To Fuel Pump)	1
		191819	Hose, Sae .312 Id X .560 Od X 14.000 (Fuel Tank To Fuel Filter)	1
97		190992	Keeper, Latch Engine Access Door	1
98		206604	Channel, Stiffener Engine Access	1
99		209093	Bracket, Safety Latch	1
100		209092	Bracket, Mtg Saftey Latch	1
101		174064	Idle, Solenoid Assy (includes)	1
		196036	Bracket, Arm Throttle	1
		125663	Ball Joint, .250-28 Type Sp Lh	1
		175936	Rod, Throttle 5.250	1
		127994	Ball Joint, .250-28 Type Spf Female Rod End	1
		127648	Clevis, Throttle	1
		124974	Solenoid, 12vdc Pull/Hold Type 1" Stroke	1
		601868	Nut, 250-28 .44hex .26h Stl Pld	2
		126388	Nut, 250-28 .44hex .27h Stl Pld Lh	1
		089800	Nut, 250-20 .44hex .22h Stl Pld .58d Flange Defor	1
		108941	Screw, 250-20x1.00 Hexwhd.61d Gr5 Pld	1
		156733	Nut, 250-28 .44hex .13h Stl Pld Sem Cone Wshr.51d	1
102		209090	Bracket, Stiffener Panel	2
103		+209089	Panel, Engine Access Lift Off	1
104		206464	Label, Maintenance Big Blue Air Pak Deutz Ce	1
105		199592	Latch, Paddle Series 20 (Black)	1
106		210681	Handle, Pocket Pull Door Access	1
107		209091	Panel, Rocker Short	1
108		191626	Bumper, Door Engine Access	4
109		+189827	Panel, Gen Rh	1
110		207448	Label, Maintenance I R Compressor	1
111		209059	Label, Schematic Air System	1
112		Figure 18-4	Generator Assembly	1
113		218087	Tank, Fuel (includes)	1
114		124253	Bushing, Tank Fuel	4
115		189912	Ftg, Stl Barbed Elbow W/.047in Orifice Zinc Pld	1
116		189909	Ftg, Stand Pipe Hose .250 X 9.265lg 90 Deg Zinc	1
117		189913	Ftg, Stl Barbed Elbow Zinc Pld	1
118		190142	Sender, Fuel Gauge 9.750 Deep Tank	1
119		189910	Ftg, Stand Pipe Hose .3125 X 9.260lg 90 Deg Zinc	1
120		189908	Valve, Drain Fuel 180 Deg Zinc Pld	1
121		181572	Bushing, Tank Fuel	1
		196219	Hose, Sae .250 Id X .500 Od X 26.000 (Fuel Return Line)	1
122		191446	Extrusion, Rubber w/Adhesive 1.000 x 1.000 (order by ft.)	6ft
123		209094	Bracket, Mtg Hose	1
124		+212224	Base	1
125		191897	Bracket, Mtg Unit	4
126		200864	Label, Do Not Weld On Base CE	2
127		206463	Label, Manufacturing Rating	1
128		182761	Label, Warning General Precautionary CSA	2


Item No.	Dia. Mkgs.	Part No.	Description	Quantity
Figure 18-1. Main Assembly				
.. 129	 R3	 189699	.. Resistor, WW Tap 375 W 10 Ohm W/Mtg Bkt	1
.. 130		 218086	.. Bracket, Holddown Fuel Tank	1
.. 131		Figure 18-2	.. Control Box	1
.. 132		 189731	.. Firewall, Bottom	1
.. 133		 203260	.. Label, Caution Do Not Use Ether	1
.. 134		 191448	.. Cover, Top Front Upright	1
.. 135		 206609	.. Upright, Front	1
.. 136		+206606	.. Box, Valve Ball	1
.. 137		 209682	.. Label, Air Power Ingersoll-Rand	1
.. 138		♦039047	.. Terminal, Pwr Output Red	1
.. 139		+♦207095	.. Box, Battery Charge	1
.. 140		♦039046	.. Terminal, Pwr Output Black	1
.. 141		♦210156	.. Label, Battery Charge (Battery Charge +/-)	1
.. 142		 207096	.. Cover, Box Front Upright	1
.. 143		 209683	.. Label, Warning Safety Air System	1
.. 144		Figure 18-3	.. Panel, Front w/components	1
.. 145	... CT1	 202130	.. Xfmr, Current Sensing (Auto Idle)	1
.. 146		Figure 18-5	.. Main Rectifier Assembly	1
.. 147		 193453	.. Bracket, Mtg Box Fcr	1
.. 148	... PC1	 207397	.. Module, Field Current Regulator	1
.. 149		 085963	.. Spring, Ext .375 Od X .041 Wire X 2.000 (ForSafety Latch)	1
.. 150		 105734	.. Pipe, Muffler Extension Elbow 1.750 OD	1
		 049525	.. Nut, 312-18 U-nut Multi-thread	4
		 049525	.. Nut, 312-18 U-nut Multi-thread	4
		 206470	.. Kit, Label (Includes Safety And Informational Labels)	1
		♦195118	.. Kit, Lock-Out Vandalism (includes)	1
		♦209238	 Door, Access Rh W/Om Pocket	1
		♦209240	 Door, Access Lh	1
		♦209236	 Tab, Lockout	1
		♦209241	 Mount, Access Rh	1
		♦209242	 Mount, Access Lh	1
		♦189975	 Hinge, Door Access 180 Deg.	4
		♦155146	 Sponge, Nprn .060 X 1.000 Wide X 4.000 Sce 41 Close	3

+ When ordering a component originally displaying a precautionary label, the label should also be ordered. Order label individually or as part of Label Kit 206470.

* Recommended Spare Parts.

♦ Optional

To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.



803 325-B

Figure 18-2. Control Box Assembly

Item No.	Dia. Mkgs.	Part No.	Description	Quantity
----------	------------	----------	-------------	----------

Figure 18-2. Control Box Assembly – (Figure 18-1 Item 131)

...	1	...	F1, F2	...	085874	..	Fuse, Mintr Cer Slo-blo 10. Amp 250 Volt	...	2
...	2	...		...	046432	..	Holder, Fuse Mintr .250 X 1.250 Panel Mtg	...	2
...	3	...		...	134201	..	Stand-off Support, Pc Card .312/.375w/Post&lock .43	...	3
...	4	...	PC9	...	192224	..	Circuit Card Assy, Display	...	1
...	5	...		...	201077	..	Control Box, LH	...	1
...	6	...	HM2	..	◆145247	..	Meter, Hour Air Compressor	...	1
...		...		...	219873	..	Harness, Control Box, Weld Control LH (includes)	...	1
...	7	...	CB11,CB12,CB13	...	139266	...	Circuit Breaker, Man Reset 1p 15a 250vac Frict	...	3
...	8	...	SR1	...	035704	...	Rectifier, Integ Bridge 40. Amp 800v	...	1
...		...	RC3	...	158466	...	Conn, Rect Univ 084 12p/S 3row Rcpt Cable/Panel Lkg	...	1
...		...	RC1	...	135133	...	Conn, Rect Univ 084 9p/S 3row Rcpt Cable/Panel Lkg	...	1
...	9	...	C9	...	087110	..	Capacitor, Elctlt 240 Uf 200 Vdc Can 1.39 Di	...	1
...	10	...		...	177136	..	Clamp, Capacitor 1.375 Dia	...	1
...		...		...	204737	..	Cable Tie Mount, Winged Push	...	3
...	11	...		...	201078	..	Control Box, Rh	...	1
...	12	..	CR3,CR6	..	090104	..	Relay, Encl 12vdc Spst 30a/15vdc 5pin Flange Mtg	...	2
...	13	...	PC7	...	195706	..	Module, Pull To Idle, Two Output, 7 Pin	...	1
...	14	...	TD1	...	214928	..	Timer, Delay On Make/Break Open 30 Sec 12vdc	...	1
...	15	...		...	201079	..	Cover, Control Box	...	1
...	16	...		...	217823	..	Label, Layout Control Box	...	1

Item No.	Dia. Mkgs.	Part No.	Description	Quantity
Figure 18-2. Control Box Assembly (Continued)				
.....		217815 ..	Harness, Engine Deutz Bf4m2011 (includes)	1
... 17 ...	CB10	190374	Circuit Breaker, Auto Reset 12vdc 40 Amp	1
.....		156734	Nut, 010-32 .31hex .13h Stl Pld Sem Cone Wshr.38d	4
.....		148850	Socket, Relay 5 Pin	5
... 18 ...	CB14	205927	Circuit Breaker, Auto Reset 12vdc 12 Amp	1
... 19 ...	CB15	083432	Circuit Breaker, Man Reset 1p 10a 250vac Frict	1
.....	S2	021467	Switch,Tgl Spst 3a 250v Off-none-(On) Spd Term (Located On Front Panel, See Figure 18-3)	1
.....		211292	Conn, Body 5 Terminal (For Ignition Switch S1)	1
.....		211293	Conn, Pack Terminal Position Assurance(Lock)	1
... 20 .	CR4, CR10	113247	Relay, Encl 12vdc Dpdt 20a/120vac 8pin Flange Mtg	2
.....		150316	Conn, Rect Univ 039 6p/S 3row Plug Cable Lkg	5
.....	S10	206624	Switch, Tgl Spst 6a 125vac (On)-on-(On) Spd Term (Located On Front Panel, See Figure 18-3)	1
.....		164617	Clip,Wiring Straight	2
... 21 .	C1/D1,C8/D8, C10/D10	189701	Diode/Capacitor Board	3
... 22	CR1	214876	Relay, Encl 6vdc Spst 35a/14vdc 5 Pin	1
... 23	CB8	♦139266 ..	Circuit Breaker, Man Reset 1p 15a 250vac Frict (Air Dryer)	1
... 24	CR14	♦090104 ..	Relay, Encl 12vdc Spst 30a/15vdc 5pin Flange Mtg (Air Dryer)	1
.....	CR15	♦172015 ..	Time Delay Relay (Air Dryer)	1
... 25	CR8	197325 ..	Relay, Encl 12vdc Spst 70a 4pin Flange Mtg	1
... 26	CR5	199999 ..	Relay, Encl 12vdc Dpst-no 30a 6pin Flange	1

♦Optional

*Recommended Spare Parts.

To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.

 Hardware is common and not available unless listed.




Figure 18-3. Panel, Front w/Components

803 326-A

Item No.	Dia. Mkgs.	Part No.	Description	Quantity
----------	------------	----------	-------------	----------

Figure 18-3. Panel, Front w/Components (Figure 18-1 Item 144)

...	1	...	217356	..	Plate, Screened Ident Control Rating	...	1
...	2	...	215014	..	Panel, Engine/Weld Control	...	1
...	3	S3	208278	..	Switch, Range/Changeover	...	1
...			192558	..	Harness, Range Switch (includes)	...	1
...		RC6	148389	...	Conn, Rect Univ 084 4p/S 1row Rcpt Cable/Panel Lkg	...	1
...	4	R1	193118	..	Pot, Cp Flat 1t 2. W 1k Ohm Linear	...	1


Item No.	Dia. Mkgs.	Part No.	Description	Quantity
Figure 18-3. Panel, Front w/Components (Continued)				
		206809	Harness, Weld Control (includes)	1
5	S6	193234	Switch, Rotary 6 Position Gold Contacts	1
6	S5	011609	Switch, Tgl Spdt 15a 125vac On–none–on Spd Term Chr	1
	PLG9	193183	Conn, Rect Cinch 18 Pin	1
		196603	Seal, Switch 6 Position Rotary .250 Shaft	1
	PLG14	141450	Conn, Rect Metrmate 10skt 1row Plug Cable Lkg	1
		164617	Clip,Wiring Straight	2
	PLG10	150316	Conn, Rect Univ 039 6p/S 3row Plug Cable Lkg	1
7	CB5	139266	Circuit Breaker, Man Reset 1p 15a 250vac Frict	1
	CB6	139266	Circuit Breaker, Man Reset 1p 15a 250vac Frict	1
8		202209	Spacer, Nylon .221 Thk	2
9	PC6	192995	Circuit Card Assy, Connector/Receptacle	1
10	S1	212436	Switch, Ignition 4 Position W/Handle	1
11	S10	206624	Switch, Tgl Spdt 6a 125vac (On)–on–(On) Spd Term (Included In Engine Wiring Harness, See Figure Figure 18-2)	1
12	S2	021467	Switch,Tgl Spst 3a 250v Off–none–(On) Spd Term (Included In Engine Wiring Harness, See Figure Figure 18-2)	1
13	CB1	201083	Circuit Breaker, Man Reset 2p 20a 250vac	1
		201553	Clip, Retaining Circuit Breaker	1
		201109	Harness, Receptacle Auxillary Power (includes)	1
14	CB2	093996	Circuit Breaker, Man Reset 1p 20a 250vac Frict	1
15	GFCI1	151981	Rcpt, Str Dx Grd 2p3w 15/20a 125v *5–20r Gfi	1
16	RC1	147632	Rcpt,Tw Lk Grd 2p3w 30a 250v *L6–30r	1
		010146	Clamp, Nyl .625 Clamp Dia X.500 Wide .203 Mtg Hole	2
17	RC5	♦182954	Rcpt, Str 3p4w 50a 125/250v	1
18		♦025248	Stand-off, Insul .250-20 X 1.2	1
19		♦604102	Connector, Clamp Cable 1.000	1
20		♦197527	Guard, Circuit Breaker	1
21		♦197363	Terminal, Ring Tng Screw Clamp	3
22	CB7	♦214926	Circuit Breaker, Man Reset 3p 50a 250vac	1
23		+215347	Panel, Power	1
		+♦215363	Panel, Generator Power (Full KVA Option)	1
	CT2	♦197433	Transformer, Current Sensing	1
24		♦214927	Boot, Circuit Breaker 1 Pole	1
25		♦197508	Plug, Protective	1
26		♦077440	Bushing, Conduit 1 In	1
27		601836	Nut, 250–20 .50hex .19h Brs	3
		010915	Washer, Flat .257idx0.640odx.031t Brs	4
		163167	Washer, Lock .254idx0.489odx.062t Sst Split.250	2
28	GRD	083030	Stud, Brs .250–20 X 1.750 W/Hex Collar	1
29		♦209056	Cover, Receptacle W/Gasket	1
30		200910	Label, Warning Electric Shock And Moving Parts Ce	1
		♦197399	Label, Warning 3 Ph Generator Power	1
31		209056	Cover, Receptacle 2.250 Dia. Lexan	2
32		♦210149	Label, Battery Charge (Switch Position)	1
		♦	Label, Polarity/AC Switch Position	1
33	S12	♦220491	Switch, Polarity/AC	1
	S13	♦210217	Switch, Battery Charge Assy	1
34		201125	Panel, Mtg Terminal Power Output	1
35	PC4, PC5	189744	Circuit Card Assembly, HF	2
36		♦210206	Bracket, Support Switch	1
37		039046	Terminal, Pwr Output Black	1
		180735	Washer, Output Stud	2
38		134201	Stand-off Support, Pc Card .312/.375w/Post&lock .43	8
39		181169	Spacer, Output Stud	2
40		186621	Boot, Generic Output Stud	2

Item No.	Dia. Mkgs.	Part No.	Description	Quantity
Figure 18-3. Panel, Front w/Components (Continued)				
... 41		♦059773	.. Switch, Handle (Polarity/AC Switch)	1
... 42		♦010647	.. Pin (Polarity/AC Switch)	1
...		♦059773	.. Handle, Switch (Battery Charging)	1
...		♦010647	.. Pin, Spring Cs .156 X 1.250 (Battery Charging)	1
...		♦081499	.. Bracket, Mtg Strip Terminal (Battery Charging)	1
... 43		039047	.. Terminal, Pwr Output Red	1
... 44		021385	.. Boot, Toggle Switch Lever	1
... 45		190323	.. Boot, Circuit Breaker Clear Hex Nut	4
... 46		170391	.. Conn, Circ Ms Protective Cap Size 20 Nylon	1
... 47	HM1	210424	.. Meter, Hour 12–24vdc (Snap-in)	1
... 48	FUEL	192265	.. Gauge, Fuel Elec Switch W/O Switchgage Sensor	1
... 49	BAT	193228	.. Meter, Volt DC 8 – 18 Scale 2.250 In Black Face	1
... 50	AIR	206599	.. Gauge, Pressure 0–200 Psi Electric Switch	1
... 51	TEMP	217084	.. Gauge, Engine Temperature	1
... 52	OIL	217083	.. Gauge, Engine Oil Pressure	1
... 53	A1	♦164873	.. Meter, Amp AC/DC 0– 500 0–600 Dc Scale 2.5 In	1
... 54	CT3	♦209274	.. Xfmr, Current (Meters)	1
... 55	V1	♦164874	.. Meter, Volt AC/DC 0– 100 Scale 2.5 In	1
... 56		097922	.. Knob, Pointer .875 Dia X .250 Id W/Set Screwsplstc	1
... 57		189161	.. Handle, Switch Range	1
... 58		010647	.. Pin, Spring Cs .156 X 1.250	1
... 59		097924	.. Knob, Pointer 1.625 Dia X .250 Id W/Set Screwsplstc	1
...		072590	.. Lock, Shaft Pot .375–32 X .250 Dia Shaft Tall	1
...		215207	.. Harness, Unit Weld Control – CV (includes)	1
...	PLG6	114063	.. Conn, Rect Univ 084 4p/S 1row Plug Cable Lkg	1
...	PLG8	193184	.. Conn, Rect Cinch 30 Pin	1
...		147992	.. Conn, Rect Univ 039 10p/S 2row Plug Cable Lkg	1
...	PLG13	158465	.. Conn, Rect Univ 084 12p/S 3row Plug Cable Lkg	1
...		088731	.. Bushing, Snap-in Nyl .375 Id X .500 Mtg Hole	1
...		135873	.. Clip, Conduit Convolute 1/2 In 6.35mm Mtg Hole	3
...		187654	.. Seal, Wire Univ 12p/S 3row	1
...		196602	.. Plug, Cavity 18,30 Position Cinch Connector	7
...		059712	.. Clip, Component .437 Dia Mtg Adh Back	1
...		024103	.. Blank, Snap-in Nyl .750 Mtg Hole Black	1
...		120304	.. Blank, Snap-in Nyl .250 Mtg Hole Black	2
...		025234	.. Plug, Str Grd 2p3w 15a 250v *6–15p	1

♦Optional

+ When ordering a component originally displaying a precautionary label, the label should also be ordered. Order label individually or as part of Label Kit 206470.

To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.



803 327

Figure 18-4. Generator

Item No.	Dia. Mkgs.	Part No.	Description	Quantity
----------	------------	----------	-------------	----------

Figure 18-4. Generator (Figure 18-1 Item 112)

...	1	132053	.. Screw, 375-16x1.50 Hex Hd-pln Gr5 Pld	6
...	2	183387	.. Washer, Cone .380idx .860odx.109t Stl Pld 4000lbs	6
...	3	195911	.. Endbell, Gen (includes)	1
...	4	143220	.. O-Ring 2.859 ID X .139 Cs 70 Duro Viton	1
...	5	AUX STATOR 201099	.. Stator, Exciter/Aux Power	1
...	6	STATOR +208287	.. Stator, Weld Assy Complete	1
...	STATOR +	209220	.. Stator, Weld Assy Complete (3-Phase Generator Option)	1
...	7	176106	.. Label, Warning Moving Parts Can Cause Serious	8
...	8	190197	.. Guard, Generator Wire Mesh	1
...	9	172674	.. Spring, Ext .240 Od X .041 Wire X 3.500 Pld	2
...	10	039207	.. Baffle, Air Gen	1
...	11	ROTOR 212997	.. Rotor, Generator (Includes)	1
...	12	024617	.. Ring, Rtnng Ext 1.375 Shaft X .050 Thk	1
...	13	053390	.. Bearing, Ball Rdl Sgl Row 1.370 X 2.830 X .6	1
...		210447	.. Fan, Rotor Assy Generator (Segmented) (includes)	1
...			.. Hub, Drive (Not Sold Separately)	1
...	14	210332	.. Plate, Flex Hubmount	1
...	15	206242	.. Fan, Rotor Segmented Assy Gen	4
...	16	049026	.. Screw, M10-1.5x 25 Hex Hd-pln 8.8 Pln	10
...	17	083883	.. Washer, Lock .402idx0.709odx.087t Stl Split10mm	10
...	18	080389	.. Screw, 312-18x1.00 Hexwhd.66d Stl Pld Slffmg Tap-rw	8
...	19	083883	.. Washer, Lock .402idx0.709odx.087t Stl Split10mm	4
...	20	049026	.. Screw, M10-1.5x 25 Hex Hd-pln 8.8 Pln	4
...	21	191579	.. Cover, Starter Hole	1
...	22	083883	.. Washer, Lock .402idx0.709odx.087t Stl Split10mm	6

Item No.	Dia. Mkgs.	Part No.	Description	Quantity
Figure 18-4. Generator (Continued)				
... 23		172555	.. Screw, M10-1.5x 50 Hex Hd-pln 8.8 Pld	6
... 24		602159	.. Screw, 312-18x .75 Hexwhd.66d Stl Pld Slffmg Tap-rw	6
... 25		604950	.. Screw, 312-18x2.00 Hex Hd-pln Gr5 Pld	4
... 26		602211	.. Washer, Lock .318idx0.586odx.078t Stl Pld Split.312	4
... 27		139341	.. Washer, Exciter	4
... 28		*190823	.. Brush, Contact Elect .250 X.500 X 1.250 Grd Ay	3
... 29		188560	.. Clip, Spring	3
... 30		189142	.. Brushholder Assy, Generator	1
... 31		602242	.. Washer, Flat .375idx0.875odx.083t Stl Pld	2
... 32		602211	.. Washer, Lock .318idx0.586odx.078t Stl Pld Split.312	2
... 33		604534	.. Screw, 312-18x1.25 Hex Hd-pln Gr5 Pld	2


+ When ordering a component originally displaying a precautionary label, the label should also be ordered. Order label individually or as part of Label Kit 206470.

*Recommended Spare Parts.

◆ Optional

To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.

☞ Hardware is common and not available unless listed.




802 279-A

Figure 18-5. Main Rectifier Assembly

Item No.	Dia. Mkgs.	Part No.	Description	Quantity
Figure 18-5. Main Rectifier Assembly (Figure 18-1 Item 146)				
.....	SR3	215909	Rectifier Complete (includes)	1
... 1		188137	Connection Board, Rectifier Ac	1
... 2		188517	Bus Bar, Conn Bd	3
... 3		188135	Enclosure, Rectifier	2
... 4		134201	Stand-off Support, Pc Card .312/.375w/Post&lock .43	3
... 5	PC3	215755	Circuit Card Assy, Protection	1
... 6		188136	Insulator, Heatsink	8
... 7		188493	Heat Sink, Rectifier Al	2
... 8	D3, D5, D7	037956	Diode, Rect 275. A 300v Sp Do-9 *1n4048	3
... 9	D2, D4, D6	037957	Diode, Rect 275. A 300v Rp Do-9 *1n4048r	3

To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.

 Hardware is common and not available unless listed.



803 328-E

Figure 18-6. Air Compressor Assembly

Item No.	Dia. Mkgs.	Part No.	Description	Quantity
Figure 18-6. Air Compressor Assembly (Figure 18-1 Item 78)				
1		206607	Valve, Ball	1
2		210523	Ftg, Flrd Stl Tube End/Female Pipe End 3/4	1
3		206939	Tank, Oil Separator	1
4		210248	Hose Assy, Air W/Fittings 3/4 X 35.250 Lg	2
5		084999	Ftg, Pipe Brs Elbow St 45 1/4 Npt	1
6		117826	Ftg, Pipe Brs Nipple Close 1/4 Npt	2
7		210053	Valve, Pressure Regulator	1
8		071270	Ftg, Pipe Brs Tee St 1/4 Npt 071 269	1
9		209854	Ftg, Pipe Adapter M 1/4 Npt X 1/4 Line	4
10		218602	Hose, Nylon Blue 44.000lg	1
11		210040	Orifice/Muffler,120	2
12		151662	Ftg, Pipe Brs Plug Hex .125 Npt	1
13		218601	Hose, Nylon Red 36.000lg	1
14		210054	Valve, Automatic Blowdown	1
15		206746	Switch, Pressure 20psi Nc	1
16		602965	Ftg, Pipe Brs Tee 1/8 Npt	1
17		209635	Hose, Assy w/Fittings 42.360lg	1
18		209621	Ftg, Stl Adapter 3/4 Sae-3/4 Jic	1
19		210051	Valve, Check Minimum Pressure	1
20		209767	Ftg, Pipe Stl Connector M 3/4 Sae-npt Adapter	1
21		206615	Sender, Pressure Oil 0- 200 Psi	1
22		073655	Ftg, Pipe Brs Nipple Hex 1/8 Npt	1
23		206937	Manifold, Air	1
24		206743	Valve, Safety Relief 150psi	1
25		209754	Ftg, Pipe Stl Elbow M 45dg 3/4 X (Npt-jic 45dg)	1
26		214685	Hose Assy, Air W/Fittings 3/4 X 21.750 Lg	1
27		209787	Ftg, Pipe Stl Nipple Close 3/4 Npt	2
28		209621	Fitting, Stl Adapter 3/4 SAE - 3/4 JIC	1
29		210058	Gauge, Oil Level Assembly	1
30		Deleted		
31		209766	Ftg, Pipe Stl Tee Street 3/4 Npt M-f-f	1
32		209457	Ftg, Pipe Stl Elbow St 3/4 Npt	2
33		209638	Hose, Oil W/Fittings 25.670 Lg	1
34		209639	Hose, Oil W/Fittings 26.320 Lg	1
35		210254	Bracket, Mtg Tbg	1
36		210251	Ftg, Stl Swivel Straight Thread Conn 3/4 O-ring	1
37		210252	Ftg, Stl Bulkhead Branch Tee 3/4 Flare Tube End	1
38		210250	Hose Assy, Oil W/Fittings 3/4 X 15.500 Lg	1
39		209765	Ftg, Pipe Stl Elbow Adapter 90dg 3/4 Sae-jic-	1
40		208040	Tensioner,Belt w/Pully	1
41		208428	Idler Pulley	1
42		217797	Bracket, Mtg Compressor	1
43		206742	Switch, High Air Temperature 248f Nc	1
		210022	O-ring, High Air Temp Switch	1
44		211904	Manifold, Compressor	1
		218558	Screw, M 8-1.2x 50 Hex Hd-pln 8.8 Pld (Manifold Mtg.Screws)	4
45		209641	Hose, Nylon White 32.000lg	1
46		209855	Ftg, Pipe Stl Adapter M 1/8 Npt X 1/4 Line	2
47		015732	Ftg, Pipe Brs Elbow St 45 1/8 Npt	1
48		209852	Ftg, Pipe Stl Adapter M M10 X 1/8 Npt F	1
49		217936	Brace, Compressor	1
50		084999	Ftg, Pipe Brs Elbow St 45 1/4 NPT	1
51		176518	Ftg, Pipe Brs Elbow St 1/4 Npt	1
52		602887	Ftg, Pipe Brs Plug Hexhd 1/4 Npt	2

Item No.	Dia. Mkgs.	Part No.	Description	Quantity
Figure 18-5. Air Compressor Assembly (Continued)				
... 53		206698	.. Plate, Mtg Compressor To Bracket	1
... 54		218305	.. Valve, Inlet Unloader 90dg	1
...		210016	.. Gasket, Unloader Valve	1
... 55	CLUTCH	210055	.. Clutch, Electro Magnetic 12vdc W/5.75 Dia Pulley	1
... 56		218609	.. Belt, Micro V 21mm X 1485mm	1
... 57		206800	.. Pulley, Crankshaft	1
... 58		210001	.. Airend, Gear-driven W/Tapered Input Shaft	1
... 59		209853	.. Ftg, Pipe Stl Adapter M M16 1.5 X 1/2 Jic	1
... 60		209634	.. Hose, Tubing Oil Assyw/Fittings 15.860lg	1
... 61		206558	.. Cooler, Oil Engine/Compressor	1
... 62		209851	.. Ftg, Pipe Stl Tube End Cap 3/4 Orfs	1
... 63		209825	.. Ftg, Stl Adapter Swivel 12m X Jic-12 F	1
... 64		209764	.. Ftg, Pipe Stl Tee Branch Sae-12 X Jic-12	1
... 65		209828	.. Ftg, Stl Swivel Union Jic-12 F-f	1
... 66		209621	.. Ftg, Stl Adapter 3/4 Sae-3/4 Jic	1
... 67		210052	.. Valve,Oil Temperature Control	1
... 68		206744	.. Thermostat, 170f (w/gasket)	1
... 69		206745	.. Filter, Oil	1
... 70		209756	.. Ftg, Pipe Stl Elbow M 90dg 1/2 Jic X 3/4 Sae	1
... 71		214686	.. Ftg, Pipe Stl Elbow 90dg 3/4bspt M X 3/4 Jic M	1
... 72		210023	.. Filter, Separator Assembly (includes)	1
... 73		206747	.. Separator, Oil/Air Filter	1
... 74		208029	.. Bracket, Mtg Filter Base	1
... 75		209646	.. Tubing, Ssstl .312 Od X.028 W/Ftgs	1
... 76		209856	.. Ftg, Stl Adapter Tube End Reducer 04f X 05m	1
... 77		210027	.. Valve, Check/Scavenge Orifice/Screen	1
... 78		209755	.. Ftg, Pipe Stl Swivel F 1/4 Npt X 1/4 F Jic	1
...		*210056	.. Oil, Compressor 1gal	1
... 79		044772	.. Screw, M12-1.7x 30 Hex Hd-pln 8.8 Pln	6
... 80		602216	.. Washer, Lock .502idx0.879odx.151t Stl Pld Split.500	6
... 81		198447	.. Screw, M10-1.5x 20 Hex Hd-pln 8.8 Pln	1
... 82		602243	.. Washer, Flat .438idx1.000odx.083t Stl Pld	1
... 83		208425	.. Screw, M10-1.5x 60 Hex Hd-pln 8.8 Pld Din 931	1
... 84		198631	.. Nut, M10 Hex Lock Nut Stl Pld	1
... 85		208426	.. Screw, M12-1.75x 40 Hex Hd 12pt Flange Screw 12.9	2
... 86		602216	.. Washer, Lock .502idx0.879odx.151t Stl Pld Split.500	2
... 87		214687	.. Ftg, Pipe Stl 3/4bspp X 3/4 Jic M	1
... 88		214920	.. Seal, Ring Bonded Rbr/Stl .950 Id X 1.380 Od X .100	1
... 89		218423	.. O-Ring	1

To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.

TRUE BLUE® WARRANTY

Effective January 1, 2004
(Equipment with a serial number preface of "LE" or newer)

This limited warranty supersedes all previous Miller warranties and is exclusive with no other guarantees or warranties expressed or implied.

Warranty Questions?

Call
1-800-4-A-MILLER
for your local
Miller distributor.

Your distributor also gives
you ...

Service

You always get the fast,
reliable response you
need. Most replacement
parts can be in your
hands in 24 hours.

Support

Need fast answers to the
tough welding questions?
Contact your distributor.
The expertise of the
distributor and Miller is
there to help you, every
step of the way.

LIMITED WARRANTY – Subject to the terms and conditions below, Miller Electric Mfg. Co., Appleton, Wisconsin, warrants to its original retail purchaser that new Miller equipment sold after the effective date of this limited warranty is free of defects in material and workmanship at the time it is shipped by Miller. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

Within the warranty periods listed below, Miller will repair or replace any warranted parts or components that fail due to such defects in material or workmanship. Miller must be notified in writing within thirty (30) days of such defect or failure, at which time Miller will provide instructions on the warranty claim procedures to be followed.

Miller shall honor warranty claims on warranted equipment listed below in the event of such a failure within the warranty time periods. All warranty time periods start on the date that the equipment was delivered to the original retail purchaser, or one year after the equipment is sent to a North American distributor or eighteen months after the equipment is sent to an International distributor.

1. 5 Years Parts — 3 Years Labor
 - * Original main power rectifiers
 - * Inverters (input and output rectifiers only)
2. 3 Years — Parts and Labor
 - * Transformer/Rectifier Power Sources
 - * Plasma Arc Cutting Power Sources
 - * Semi-Automatic and Automatic Wire Feeders
 - * Inverter Power Sources (Unless Otherwise Stated)
 - * Water Coolant Systems (Integrated)
 - * Intellitag
 - * Maxstar 150
 - * Engine Driven Welding Generators
(NOTE: Engines are warranted separately by the engine manufacturer.)
3. 1 Year — Parts and Labor Unless Specified
 - * DS-2 Wire Feeder
 - * Motor Driven Guns (w/exception of Spoolmate Spoolguns)
 - * Process Controllers
 - * Positioners and Controllers
 - * Automatic Motion Devices
 - * RFCS Foot Controls
 - * Induction Heating Power Sources and Coolers
 - * Water Coolant Systems (Non-Integrated)
 - * Flowgauge and Flowmeter Regulators (No Labor)
 - * HF Units
 - * Grids
 - * Maxstar 85, 140
 - * Spot Welders
 - * Load Banks
 - * Arc Stud Power Sources & Arc Stud Guns
 - * Racks
 - * Running Gear/Trailers
 - * Plasma Cutting Torches (except APT & SAF Models)
 - * Field Options
(NOTE: Field options are covered under True Blue® for the remaining warranty period of the product they are installed in, or for a minimum of one year — whichever is greater.)

- * Induction Heating Coils and Blankets
- * APT & SAF Model Plasma Cutting Torches
- * Remote Controls
- * Accessory Kits
- * Replacement Parts (No labor)
- * Spoolmate Spoolguns
- * Canvas Covers

Miller's True Blue® Limited Warranty shall not apply to:

1. **Consumable components; such as contact tips, cutting nozzles, contactors, brushes, slip rings, relays or parts that fail due to normal wear. (Exception: brushes, slip rings, and relays are covered on Bobcat, Trailblazer, and Legend models.)**
2. Items furnished by Miller, but manufactured by others, such as engines or trade accessories. These items are covered by the manufacturer's warranty, if any.
3. Equipment that has been modified by any party other than Miller, or equipment that has been improperly installed, improperly operated or misused based upon industry standards, or equipment which has not had reasonable and necessary maintenance, or equipment which has been used for operation outside of the specifications for the equipment.

MILLER PRODUCTS ARE INTENDED FOR PURCHASE AND USE BY COMMERCIAL/INDUSTRIAL USERS AND PERSONS TRAINED AND EXPERIENCED IN THE USE AND MAINTENANCE OF WELDING EQUIPMENT.

In the event of a warranty claim covered by this warranty, the exclusive remedies shall be, at Miller's option: (1) repair; or (2) replacement; or, where authorized in writing by Miller in appropriate cases, (3) the reasonable cost of repair or replacement at an authorized Miller service station; or (4) payment of or credit for the purchase price (less reasonable depreciation based upon actual use) upon return of the goods at customer's risk and expense. Miller's option of repair or replacement will be F.O.B., Factory at Appleton, Wisconsin, or F.O.B. at a Miller authorized service facility as determined by Miller. Therefore no compensation or reimbursement for transportation costs of any kind will be allowed.

TO THE EXTENT PERMITTED BY LAW, THE REMEDIES PROVIDED HEREIN ARE THE SOLE AND EXCLUSIVE REMEDIES. IN NO EVENT SHALL MILLER BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING LOSS OF PROFIT), WHETHER BASED ON CONTRACT, TORT OR ANY OTHER LEGAL THEORY.

ANY EXPRESS WARRANTY NOT PROVIDED HEREIN AND ANY IMPLIED WARRANTY, GUARANTY OR REPRESENTATION AS TO PERFORMANCE, AND ANY REMEDY FOR BREACH OF CONTRACT TORT OR ANY OTHER LEGAL THEORY WHICH, BUT FOR THIS PROVISION, MIGHT ARISE BY IMPLICATION, OPERATION OF LAW, CUSTOM OF TRADE OR COURSE OF DEALING, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE, WITH RESPECT TO ANY AND ALL EQUIPMENT FURNISHED BY MILLER IS EXCLUDED AND DISCLAIMED BY MILLER.

Some states in the U.S.A. do not allow limitations of how long an implied warranty lasts, or the exclusion of incidental, indirect, special or consequential damages, so the above limitation or exclusion may not apply to you. This warranty provides specific legal rights, and other rights may be available, but may vary from state to state.

In Canada, legislation in some provinces provides for certain additional warranties or remedies other than as stated herein, and to the extent that they may not be waived, the limitations and exclusions set out above may not apply. This Limited Warranty provides specific legal rights, and other rights may be available, but may vary from province to province.





Owner's Record

Please complete and retain with your personal records.

Model Name

Serial/Style Number

Purchase Date

(Date which equipment was delivered to original customer.)

Distributor

Address

City

State

Zip



For Service

Call 1-800-4-A-Miller or see our website at www.MillerWelds.com to locate a DISTRIBUTOR or SERVICE AGENCY near you.

Always provide Model Name and Serial/Style Number.

Contact your Distributor for:

Welding Supplies and Consumables

Options and Accessories

Personal Safety Equipment

Service and Repair

Replacement Parts

Training (Schools, Videos, Books)

Technical Manuals (Servicing Information and Parts)

Circuit Diagrams

Welding Process Handbooks

Contact the Delivering Carrier to:

File a claim for loss or damage during shipment.

For assistance in filing or settling claims, contact your distributor and/or equipment manufacturer's Transportation Department.

Miller Electric Mfg. Co.

An Illinois Tool Works Company
1635 West Spencer Street
Appleton, WI 54914 USA

International Headquarters—USA

USA Phone: 920-735-4505 Auto-Attended
USA & Canada FAX: 920-735-4134
International FAX: 920-735-4125

European Headquarters – United Kingdom

Phone: 44 (0) 1204-593493
FAX: 44 (0) 1204-598066

www.MillerWelds.com

