SPEAKMAN COMPANY VS-117 Installation, Maintenance & Operation Instructions VERSATILE ® VACUUM BREAKER

DESCRIPTION

VERSATILE® chrome plated brass in-line vacuum breaker.

SPECIFICATIONS

SUPPLY INLET: ½" NPSM FEMALE OUTLET : ½" NPSM MALE SHIPPING WEIGHT: XXX LBS.

INSTALLATION


Connect, using rubber washer, to supply piping. Connect accessories to vacuum breaker. Firmly hand tighten connection. Turn water supply on and check for leaks.

Note: Do not install VS-117 in concealed locations or where spillage under certain service conditions might cause water damage. Avoid continuous pressure applications (shut off valve downstream of the vacuum breaker).

MAINTENANCE

The gleaming finish of your SPEAKMAN VERSATILE® VS-117 vacuum breaker can be cleaned by using mild soap and warm water. Dry immediately with a soft, clean cloth for best results.

ROUGH-IN MEASUREMENTS



Product improvements may cause specification and dimensional changes without notice.

SPEAKMAN COMPANY P.O. Box 191, Wilmington, DE 19899-0191 USA 1-800-537-2107, Fax: 1-800-977-2747 Website: www.speakmancompany.com