Assembly Instructions for: Item 3517 Otto series – Single Sconce



## LAMP INSTALLATION & ASSEMBLY

- 1. Shut off power to outlet box.
- Unscrew canopy screws and remove mounting plate from canopy. Attach the mounting plate to the gem box using outlet box screws.
- Make appropriate electrical connections using wire nuts. The green wire is the ground wire and must be connected to a grounding terminal or a ground wire in the outlet box.
  It is important that these connections are well insulated to prevent short circuits.
  Place connections in outlet box.
- 4. Secure canopy to mounting plate with canopy screws.
- 5. Install candelabra base bulb (not included)
- 6. Place shade on lamp post, inserting shade supports into holes in the lamp post.

