SONNEMAN[®]

Important: Always disconnect the power before installing or replacing bulbs and before cleaning or other maintenance.

This light should be installed by a licensed electrician

LAMP INSTALLATION AND ASSEMBLY

- 1. Shut off power to the outlet box. (fig. A)
- 2. Determine the height at which the fixture is to be hung. Screw stem sections together to achieve desired length.
- 3. Release set screw in fixture hang straight, screw fixture hang straight to threaded stem 1, turn until tight, and tighten with set screw.
- 4. Make appropriate electrical connections using wire nuts: a.Connect the fixture's hot wire (black) to the black outlet box wire. b.Connect the fixture's neutral wire (white) to the white outlet box wire. c.Connect fixture's ground wire (green or uncoated) to the ground outlet box wire. If no ground is present in outlet box, connect fixture's ground wire to the mounting plate using the green screw (included). d. Carefully place connections in outlet box.
- 5. Wire cable through cable stop, and tighten with stop screws. (fig B)
- 6. Attach the mounting plate to the outlet box, using outlet box screws.
- 7. Attach canopy to mounting plate with canopy screws.
- 8. Install A19 bulbs. (not included)
- 9. Attach shade by inserting shade pins into holes of the shade holder plate threaded stem.
- Attach the upper platic plate and the glass diffuser on threaded stem 2. Secure diffuser with lower plastic plate and lower metal plate. Tighten with finial.
- 11. Restore power to the fixture.

SHADE ADJUSTING INSTRUCTIONS

If the shade does not hang level in relation to glass diffuser, adjust height of shade holder plate threaded stems to flush the bottom of the shade to the diffuser.

CARE INSTRUCTIONS

Dusting — Use a clean, dry cloth. Cleaning — To protect the finish, avoid any harsh abrasives or chemicals.



