## SONNEMAN<sup>®</sup>

## Assembly Instructions for item : 3507 Berlin Series - Torchiere

Important: Always unplug the power cord before installing or replacing bulb and before cleaning or other maintenance.

## LAMP INSTALLATION AND ASSEMBLY

1. Attach lamp base to lamp body by aligning threaded stem and locating screws with holes in lamp base. Secure with flat washer,lock washer,and hex nut using wrench.(included)

2. Attach glass diffuser by placing over sockets and lining up glass diffuser holes with studs on metal plate. Tighten with glass diffuser nuts.

3. Install 18W quad CFL G24q-2 Base bulbs. (not included)

4. Attach shade to lamp body by lining up shade tabs with shade tab holders.

5. Plug in the power cord and on/off foot switch is in the power cord.

## CARE INSTRUCTIONS

Dusting — Use a clean, dry cloth. Cleaning — To protect the finish, avoid any harsh abrasives or chemicals.

