

Important: Always disconnect the power before installing or replacing bulb and before cleaning or other maintenance.

This light should be installed by a licensed electrician

Assembly & Installation Instructions

1. Shut off power to outlet box (Fig A).
2. 1722 - Insert G9 xenon bulbs in socket (included). turn glass barriers on to sockets.
1722F - Insert 18W quad CFL G24q-2 base bulb (not included).
3. Attach shade to backplate tighten with shade thumbscrew.
4. Make appropriate electrical connections using wire nuts:
 - a. Connect the fixture's hot wire (black) to the black outlet box wire.
 - b. Connect the fixture's neutral wire (white) to the white outlet box wire.
 - c. Connect fixture's ground wire (green or uncoated) to the ground outlet box wire. If no ground is present in outlet box, connect fixture's ground wire to the mounting plate using the green screw (included).
 - d. Carefully place connections in outlet box.
5. Place mounting plate over outlet box and secure with outlet box screws.
6. Attach backplate over mounting plate and tighten with back plate screws
7. Restore power to fixture.

CARE INSTRUCTIONS

- Dusting – Use a clean, dry cloth.
Cleaning – To protect the finish, avoid any harsh abrasives or chemicals.

