## SONNEMAN<sup>®</sup>

T10 bulb

Important: Always disconnect the power before installing or replacing bulb and before cleaning or other maintenance.

## This light should be installed by a licensed electrician

Assembly & Installation Instructions

- 1. Shut off power to outlet box (Fig A).
- 2. Make appropriate electrical connections using wire nuts:
- a.Connect the fixture's hot wire (black) to the black outlet box wire.

b.Connect the fixture's neutral wire (white) to the white outlet box wire. c.Connect fixture's ground wire (green or uncoated) to the ground outlet box wire. If no ground is present in outlet box, connect fixture's ground wire to the mounting plate using the green screw (included).

d. Carefully place connections in outlet box.

3. Place mounting plate over outlet box and secure with outlet box screws.

4. Attach backplate over mounting plate (Fig B)

- and tighten with back plate screws on top.
- 5. 1845 Insert T10 medium base bulb in socket. (not included).
- 1845F Insert 18W quad CFL G24q-2 base bulb. (not included)
- 6. Attach shade to shade holder using spring clips.
- 7. Restore power to fixture.



