SONNEMAN
A WAY OF LIGHT

Important: Always disconnect the power before installing or replacing bulb and before cleaning or other maintenance.

This light should be installed by a licensed electrician

LAMP INSTALLATION AND ASSEMBLY
1. Shut off power to the outlet box. (fig. A)
2. Attach the mounting plate to the outlet
box using outlet box screws. Using anchors and mounting
screws for extra support
3. Make appropriate electrical connections using wire nuts.
If there is no green ground wire from the outlet box, then
connect the fixture wire to the mounting plate with the
green screw provided. Place connections in outlet box.
4. Attach back plate to mounting plate with backplate screws.
5. Attach the metal shade to the socket, align the screw
holes,and tighten with the metal shade screws.
6. Install G9 xenon bulb (included)
7. Push the glass shade into socket cup and twist until tight.
8. Restore power to the fixture.

A

OFF

OFF

mouting plate

backplate screws

4903

anchors

mounting screws

backplate

4904

metal shade

metal shade screws

G9 xenon bulb

glass shade