

Important: Always disconnect the power before installing or replacing bulb and before cleaning or other maintenance.

This light should be installed by a licensed electrician

LAMP INSTALLATION AND ASSEMBLY

1. Shut off power to the outlet box. (fig. A)
2. Attach the metal shade to the socket, align the screw holes, and tighten with the metal shade screws.
3. Loosen strain relief in canopy to adjust length of wire. Be sure to secure the strain relief once the desired length is obtained.
4. Attach the universal bar to the outlet box using outlet box screws.
5. Make appropriate electrical connections using wire nuts. If there is no green ground wire from the outlet box, then connect the fixture wire to the universal bar with the green screw provided. Place connections in outlet box.
6. Attach canopy to universal bar with canopy nuts.
7. Install G9 xenon bulb (included).
8. Push the glass shade into socket cup and twist until tight.
9. Restore power to the fixture.

