

ASSEMBLY INSTRUCTIONS FOR YOUR

Jonathan Adler PARKER PENDANT

****IT IS RECOMMENDED THAT A LICENSED ELECTRICIAN INSTALL THIS FIXTURE****

Warning: If any special control devices are used with this fixture, follow the instructions carefully to assure full compliance with N.E.C. requirements. If there are any questions, contact a qualified electrical contractor.

Assembly Instructions

SHUT OFF MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.

Caution: To clean, use a soft cloth only. Do not use any chemical or abrasive cleaners.

1. Remove all parts carefully from the box.
2. Remove mounting plate (A) from canopy (D) by removing canopy screws (E).
3. Affix mounting plate (A) to "J BOX" with mounting plate screws (C) provided.
4. Measure desired drop for fixture to hang from "J BOX." Loosen clamp screw (G) on wire clamp (F) (located inside canopy (D)), and pull wire through canopy until desired drop is reached.
5. If removed, guide wiring back through housing (H) in canopy (D), making sure to run wiring through wire clamp (F). Tighten clamp screw (G) on wire clamp (F).
6. Cut excess cord leaving 3 or 4 inches of length for wire connections.
7. Lift fixture to "J BOX". Make proper electrical connection. A licensed electrician is recommended.
8. Connect the grounding wire (green) from the fixture to the grounding wire in the outlet box (copper, green, or silver). Connect the black wire of the fixture (or smooth side of the wire) to the black wire in the outlet box using wire nuts (B). Connect the white wire of the fixture (or rough side of the wire) to the white wire in the outlet box using wire nuts (B).
9. Slide canopy (D) over mounting plate (A) and align holes in mounting plate (A) with holes in canopy (D). Thread canopy screws (E) into holes to secure fixture to ceiling.
10. Remove shade support arms (I) from socket housing (L) and set metal shade (N) aside.
11. Align holes in glass shade (M) with holes in socket housing (L). Insert threaded ends of shade support arms (I) through holes in glass shade (M) into threaded holes of socket housing (L) and turn until securely fastened.
12. Remove threaded nuts (J) from shade support arms (I) and set aside. Caution, make sure not to unthread shade support arms (I) when removing threaded nuts (J).
13. Carefully place metal shade (N) over glass shade (M). Align holes in metal shade (N) with shade support arms (I). Thread nuts (J) into ends of shade support arms (I) securing metal shade (N) to fixture.
14. Insert one (1) Type A, 60 watt bulb into socket (K).

