



Tools Needed:

- -Cordless Drill (12V or higher)
- -#2 Square Drive Bit
- -Hammer
- -Tape Measure
- -Speed Square



Little Cottage Co. PO Box 455 Berlin, OH 44610 330-893-4212 www.cottagekits.com

© 2008-2009 Little Cottage Co.





Locate the wheels and the back panel.



1



Next set up panel as shown.





Fasten wheels on bottom as shown with 2 1/2' deck screws.



Locate the 3 sides.





Secure with 1 1/4" screws as shown.



Make sure the top plates are flush.

**Construction** Manual

© 2008-2009 Little Cottage Co.





9



Continue with the panels and fasten with 1 1/4" screws as shown.



Attach to the wall with wheels and secure with  $1 \frac{1}{4}$  screws as shown.



Next pick up the 3 section wall as shown.

10



Continue fastening with 1 1/4" screws on all corners as shown.





Lay the coop on it's side as shown.



Next install the floor with 1"x1" mesh as shown.

**Construction Manual** 

© 2008-2009 Little Cottage Co.





Make sure the bottom is flush as shown.

14



Secure with 2 1/2" screws as shown. 2 screws on each side.



Continue fastening the floor.



Next install the bottom rail with chicken mesh as shown.

13

15



Secure with 2 1/2" screws.



Repeat on the opposite end.

Construction Manual

© 2008-2009 Little Cottage Co.

21



Secure with 2 1/2" screws.



Next set it up and slide in the dropping pan.



Continue with fastening.



Lay the building on the end as shown.





Locate all nest parts.

**Construction Manual** 



Install the nest floor as shown. Measure  $1 \frac{1}{2}$ " from the opneing to the outside of the floor.

© 2008-2009 Little Cottage Co.

27



Make sure the 2x2s are flush as shown. Secure with 2 1/2" screws.



Install the nest side panel as shown and secure with  $1 \frac{1}{4}$  screws.



Set the building on it's runners again.



Make sure the 2x2's are flush with the inside of the opening.





Secure with 2 1/2" screws.



Repeat on the other side.

Little Cottase C

Construction Manual

© 2008-2009 Little Cottage Co.







Install the back panel. Make sure the top is flush.

33



Next install nest box lid as shown.



Fasten with 1 1/4" screws on all corners.



Lay it on it's side as shown.

35



Install chicken ramp. Secure with 2 1/2" deck screws. Two in the back and two in the front.



Continue with the ramp.

**Construction** Manual

© 2008-2009 Little Cottage Co.





Next insert the screw from the bottom up as shown in predrilled holes.



Next install the exterior fence as shown



Set the coop back up on it's runners.



Secure with 2 1/2" screws.

41



Continue with exterior fence as shown.



Then locate the Gable end.

Construction Manual

© 2008-2009 Little Cottage Co.

**45** 



Secure with 2 1/2" screws as shown.



Continue with the rafters.



Next locate the rafters and secure with 1 1/4" screws.

46



Install the roof, make sure the roof overhangs 1" on the sides.





Secure with 1 1/4" screws on the bottom corner.



Continue with roof.

Construction Manual

© 2008-2009 Little Cottage Co.





Secure with 1 1/4" screws.



Locate aluminum corners.



Repeat on the backside.



Install aluminum corner on top for ridge and fasten with white trim nails as shown.

**49** 

51



Install aluminum corners on the outside as shown, and secure with white trim nails.



Continue with aluminum corners as shown.

**Construction Manual** 

© 2008-2009 Little Cottage Co.



55



Your finished product!

57

58

**56** 

59



**Construction Manual** 

© 2008-2009 Little Cottage Co.