

1



Locate the Wheels and the back panel.

2



Fasten wheels on the bottom as shown with 2 1/2" deck screws.

3



Next install the nest box floor. Make sure it is flush on bottom as shown.

4



Measure 1 1/2" from the opening to the outside of nest floor.

5



Secure with 2 1/2" screws as shown.



Locate the 4 pieces for the nest box.



7



Install the nest side panel as shown and secure with 1 1/4" screws.

8



Repeat on other side.

9



Make sure the opening is flush on the inside and secure with 2 1/2" screws.

10



Install the back panel. Make sure the top is flush.

11



Next install the nest box lid as shown.



Locate the 3 sides.



13



Secure with 1 1/4" screw as shown.

14



Continue with the walls.

15



Secure with 1 1/4" Screws.

16



Next locate the bottom rail.

17



Secure with 2 1/2" screws.



Repeat on the opposite side.



19



Secure with 2 1/2" screws.

20



Next set up the 3 section wall as shown.

21



Attach the wall with the wheels and secure with 1 1/4" screws as shown.

22



Lay coop on it's side as shown.

23



Install the chicken ramp. Secure with 2 1/2" screws. Two in the back and two in the front.



Continue with the ramp.



25



Next insert 2 1/2" screw from the bottom up as shown in predrilled holes.

26



Next install 1" x 1" mesh floor.

27



Make sure the floor is flush with the bottom of the wall as shown.

28



Secure floor with 2 1/2" screws as shown.

29



Continue fastening floor with 2 1/2" screws.



Next set coop back up.



31



Insert dropping tray.

32



Next install exterior fence as shown.

33



Secure with 2 1/2" screws.

34



Repeat from the opposite side.

35



Next locate end gable.



Secure with 2 1/2" screws as shown.



37



Next locate the rafters and secure with 1 1/4" screws.

38



Continue with the rafters.

39



Continue with rafters.

40



Install roof, Make sure roof overhangs 1" on sides, and secure with 1 1/4" screw.

41



Next install the roof on the lower section. Secure with $1 \frac{1}{4}$ screws.



Continue with the roof.



43



Locate all of the aluminum corners.

44



Install the aluminum corner for the ridge.

45



Install aluminum corners on top for the ridge and fasten with white trim nails as shown.

46



Install aluminum corners on the outside as shown and secure with white trim nails.

47



Continue with corners



continue with corners



49



Your finished Product!

51

52

50

53