



“Reflections for a new millennium”

Installation Instructions for “METRO” SINGLE DOOR CABINETS

Dear AFINA Customer:

We appreciate your purchase of our **AFINA “METRO”** Bath Cabinet, and would like to provide you with the following helpful hints.

- For protection in shipping, the **GLASS SHELVES** for your cabinet have been neatly placed under the cabinet body (top & bottom). They are clearly identified by a label marked **“GLASS SHELVES”**. Please look carefully and remove before installation.
- **SHELF PINS** are inside the cabinet in an envelope marked **“SHELF PINS”**.
- It is important to make sure the cabinet body is level and plumb upon installation. Use a leveling instrument to ensure accuracy, or the door may not close and/or secure itself properly.
- You can hang your new cabinet **hinge left** or **hinge right** just by turning the cabinet over.
- When **RECESSING** the cabinet, use the two pre-drilled holes on each side of the cabinet interior. (top and bottom) Screws are **not** supplied, as we do not know the type of material you are going into (i.e., wood studs, metal studs). Make sure the cabinet is level and plumb before securing into framing studs.
- When **SURFACE MOUNTING** – See separate **SURFACE MOUNTING INSTRUCTIONS** with your optional surface mount kit.
- When cleaning your new Afina cabinet, we recommend a mild cleanser, applied first to a rag or paper towel. Do not spray directly on to the mirror or frame.

We are confident your **AFINA** cabinet will reflect the quality and prestige you wish to convey in your home or business environment.

Thank you for purchasing **AFINA** products.

www.afinacorporation.com