

MODEL 300 CLOCK INSTALLATION INSTRUCTIONS

- 1** Install toggler or appropriate fastener in wall at desired location 1 1/4" above center of clock.
- 2** Install 2 1/2" long sheet rock screw into toggler leaving approx. 1" protruding from the wall.
- 3** Remove protective tag on (+) positive side of battery to start clock & set to correct time.
- 4** Place hanger bracket of clock over the sheet rock screw & center on wall.

CAUTION : THESE INSTRUCTIONS ARE INTENDED FOR **DRYWALL INSTALLATION ONLY!** IF INSTALLATION IS TO BE OTHER THAN DRYWALL, THE INSTALLER SHALL USE APPROPRIATE HARDWARE FOR THE WALL STRUCTURE.

PLEASE NOTE: THESE INSTRUCTIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE.



Peter Pepper Products, Inc. • T: 310.639.0390 x 7 • F: 310.639.6013 • E: customerservice@peterpepper.com