

1. Lock the T10 bulb(A) into socket (B)
  2. Insert the shade (D) to the lamp body(C)
- Note: 1. If you want to use white pleat shade then need to attach the shade ring to the shade first and fix it by clips on the shade ring.
2. The shade is packed separat by another box

