

INSTRUCTION SHEET FOR LEVELING WEDGES



An unever floor may cause the unit to twist slightly, causing uneven gaps around the doors. Insert the enclosed plastic wedges under the unit sides until they are snug and the door gaps are even. Usually it will work best to put them under one front corner and the opposite back corner. When the unit is level, break off the protruding portion of the wedges.

