# **MONTEREY**



# FR42504BME

Bulbs: 4-100W MED. Replacement Parts: GLASS: R42504GL, R42504SH

# ASSEMBLY INSTRUCTIONS

Assembly of this fixture will be accomplished by first assembling the body of the fixture, installing the mounting hardware to the junction box, making all necessary electrical connections, hanging the fixture and then installing the fixture glass and shade.

SAFETY WARNING: Read wiring and grounding instructions [FRIS 18] and any additional directions. Turn power supply off during installation. If new wiring is required, consult a qualified electrician or local authorities for code requirements.

### STEP 1

- 1 Thread tubing (2) into coupler (a), located in the center of the socket assembly (1), approximately 3/8".
- 2 Tighten hex nut (3) up against coupler (a) to lock threaded tube (2) in place.
- 3 Slip diffuser plates (4) over threaded studs located on plate (b).
- 4 Thread on ball knobs (5) to secure diffuser plates.
- 5 Fixture can now be installed.

 $STEP\ 2$  Refer to Hanging Instruction Sheet [FRIS19] to hang fixture. Then refer back to this sheet to continue assemble of this fixture.

### STEP 3

- ${\bf 1} \qquad \text{To install glass first slip tube (6) over threaded tube (2), installed earlier and hold piece in place.}$
- 2 Slip cap (7) over the threded tube and onto end of tube (6), and hold in place.
- 3 Slip rubber washer (8) onto threaded tube, friction of washer on tube will hold parts in place.
- 4 NOTE: getting assistance during this step is recommended. Slip glass (9) onto threaded tube and hold in position.
- While holding glass in position, slip rubber washer (10) followed by metal washer (11) onto threaded tube and hold pieces in place.
- 6 Thread hex nut (12) onto threaded tube and tighten to secure glass to fixture.
- Slip cap (13) onto threaded tube and the thread ball knob (14) onto end of threaded tube and tighten.
- 8 Slip tabs (c) located on the top lip of the shade (15) over edge of glass to finish assembly.

#### [DRAWING 1]



