
ASSEMBLY INSTRUCTIONS



Description: 2 SEAT PORCH SWING

Item No : SW-53941

ITEM NO : SW-53941

REVISED APR 11, 2013

Printed in Vietnam

BEFORE ASSEMBLY

Thank you for purchasing this quality product. This product has been designed for easy assembly and constructed for durability. All parts were checked prior to packaging to insure quality. Prior to beginning assembly, however, make sure all parts and hardware are included and free of obvious defect. If a part is missing or defective, please contact the store where purchased. If hardware is missing, or you need help with assembly, please call toll free 888-944-8396.

IMPORTANT NOTE:

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Remove all wrapping material, including staples & packing straps before you start to assemble.
- DO NOT tighten all screws and bolts until completely assembled.
- Keep all hardware parts out of reach of children.

PART LIST

When unpacking, please be careful not to discard any parts with the packaging. Before continuing, please make sure you have the following parts:

N O	Description	Qt y	Sketch	N O	Description	Qt y	Sketch
А	Back frame & Seat frame	1		В	Arm frame (L&R)	2	

ITEM NO : SW-53941 Printed in Vietnam

HARDWARE LIST


When unpacking, please be careful not to discard any parts with the packaging. Before continuing, please make sure you have all of the following hardware:

N O	Description	Qt y	Sketch	NO	Description	Qty	Sketch			
1	Bolt (M8x65mm)	4		2	Hexagon nut (M8x 13mm)	4				
3	Lock washer (Φ8.5x13mm)	4		4	Flat washer (Φ8.5x19mm)	4				
5	Wrench (13mm)	1								
6	Chains (\$\phi4x1220mm)\$ Chains (6.1) (\$\phi4x865mm)\$ Chains (6.2) (\$\phi4x915mm)\$	2	6.1							

ITEM NO : SW-53941 Printed in Vietnam
REVISED APR 11, 2013

STEP 1


Carefully open seat frame and back frame (A).



ITEM NO : SW-53941 Printed in Vietnam
REVISED APR 11, 2013

STEP 2


Attach arm frames (B) to seat frame and back frame (A) with bolts (1) and nuts (2), lock washers (3) and flat washer (4). Tighten with the wrench (5) as shown below.



ITEM NO : SW-53941 Printed in Vietnam
REVISED APR 11, 2013

STEP 3

Attach chains (6) to seat frame and back frame (A) as shown below.



ITEM NO : SW-53941 Printed in Vietnam