

**Stone Counter Top Installation Guide
For Undermount Sink****Step 1**

Apply adhesive caulking around the topside of rim near the edge as shown

Step 2

Carefully raise sink in place, align, and press firmly.

Step 3

Attach 4 undermount clips to hold lavatory in place.

Step 4

Secure top & back splash to cabinet by using adhesive caulk.

