## 6 CORPORATE PARKWAY SUPPLY WIRE and GOOSE CREEK, SC. 29445 GROUND WIRE www. quoizel. com CROSSBAR with GROUND SCREW **LOCK WASHER** STEM with HEX NUT FIXTURE PAN SOCKET **LOCK WASHER** PLAIN WASHER HEX COUPLING CENTER STEM SHADE RUBBER WASHER 9 PLAIN WASHER HEX NUT CAP **FINIAL**

## ASSEMBLY/INSTALLATION INSTRUCTIONS:

- 1. Before beginning installation, be sure to carefully unpack all parts referring to illustration for parts identification.
- 2. With power to the installation point OFF. Locate the CROSSBAR WITH GROUND SCREW and attach to the ceiling mounted OUTLET BOX. Do this using (2)OULTET BOX SCREWS (not supplied). Locate the LOCK WASHER and STEM WITH HEX NUT and then thread top end of STEM into the center of the CROSSBAR. Position the FIXTURE PAN over the outlet box. Pass the MOUNTING HOLE on the inside deck of the FIXTURE PAN over the end of STEM WITH HEX NUT. There should be approx. 3/8" of end of STEM WITH HEX NUT protruding from MOUNTING HOLE on inside deck of FIXTURE PAN. If STEM length is excess of 3/8", thread STEM further into center of STEM. Remove FIXTURE PAN and snug HEX NUT against underside of CROSSBAR with pliers to secure STEM.
- 3. Making the connections: (Quoizel recommends 2 people for this step).

  Position the FIXTURE PAN over the outlet box and attach the HOUSE GROUND WIRE to the FIXTURE GROUND WIRE. Proceed to attach both to the CROSSBAR with the GREEN GROUND SCREW. Using wire connectors (not supplied) connect the HOUSE WHITE WIRE to the FIXTURE SUPPLY WIRE (WHITE SIDE); connect the HOUSE BLACK (or RED)WIRE to the FIXTURE SUPPLY WIRE(BLACK SIDE). Wrap all connections with approved electrical tape.
- 4. Secure FIXTURE PAN to ceiling by aligning and passing MOUNTING HOLE over end of STEM secure to CROSSBAR. Pass the PLAIN WASHER and LOCK WASHER over the end of the NIPPLE and thread HEX COUPLING onto the bottom end of STEM. Snug assembly until FIXTURE PAN is flush against ceiling. Be sure that there are no trapped or pinched wires.
- 5. Install bulbs referring to fixture markings and/or labels for maximum wattage.
- 6. Locate the SHADE, RUBBER WASEHR and PLAIN WASHER over the end of CENTER STEM. Secure by threading HEX NUT onto the end of CENTER STEM. Hand tighten until snug. Locate the CAP over the end of CENTER STEM. Secure by threading FINIAL onto the end of CENTER STEM. Hand tighten until snug.
- 7. Restore power to the installation point ON. Keep this sheet for future reference.