

INSTALLATION INSTRUCTIONS

1. Before beginning the installation, carefully unpack and identify all parts referring to the illustration.
2. Turn the power to the installation point OFF at circuit breaker.
3. Position the hole on the bottom of the SHADE over the SCREW inside of the SHADE HOLDER. Locate the RUBBER WASHER over the SCREW and thread the HEX NUT onto the SCREW to secure them. Hand tighten until snug.
4. **Quoizel recommend 2 people for this step.** Thread the HEX NUTS onto the SCREWS. Locate the BACKPLATE inside of the SHADE and match the holes on the SHADE SUPPORT STRAP with the holes on the side of SHADE. Position the SCREWS with the HEX NUTS through the holes from inside of the SHADE. And then locate the SIDEARMS. Make the holes on them over the STUDS on the side of the SHADE HOLDER and the SCREWS extruding from the side of the SHADE. Secure them together by threading LOCK BALLS onto the SCREWS and the STUDS. Hand tighten until snug.
5. **Make the wiring connections:**
Using wire connectors(not supplied), connect the HOUSE GROUND WIRE to the FIXTURE GROUND WIRE; connect the HOUSE WHITE WIRE to the FIXTURE WHITE(or RIBBED) WIRE; connect the HOUSE BLACK(or RED) WIRE to the FIXTURE BLACK(or SMOOTH) WIRE. Wrap each connection with approved electrical tape.
6. Proceed to secure the BACKPLATE to the wall mounted outlet box by using (2)OUTLET BOX SCREWS(not supplied). Prior to this, determine how many METAL TABS will need to be removed from the backplate in order to align the BACKPLATE with the mounting holes on the outlet box. To remove the METAL TABS, use a flat head screw driver to apply pressure from the backside of the BACKPLATE. Once the METAL TAB moves forward, remove with pliers.
7. Install bulb referring to fixture markings and/or labels for maximum wattage.
8. Restore the power to the installation point ON. Retain this sheet for future reference.

