



IMPORTANT
TURN OFF THE POWER AT THE MAIN FUSE
OR CIRCUIT BREAKER BOX
BEFORE STARTING INSTALLATION

Carefully unpack and identify all parts before assembly. Bulbs are not included.

1. Spread open all arms so they are evenly spaced apart to each other.
2. Lock lower tier arms by fastening with cap screw onto center body.
3. Slip notched cover and upper leaf through threaded pipe, which is located at top of fixture. Lock all together by fastening with fixture loop. Note: make certain arms are locked into notches of the notched cover.
4. Follow enclosed supplement installation instructions for electrical and fixture installation onto house outlet box. If you do not have an outlet box at desired location to attach the fixture than hire a qualified electrician to create one.
5. Install lower leaf assembly by screwing onto bottom of fixture.
6. Install bobeche by slipping through socket until it securely sits onto fitter.
7. Slip candle tube over sockets.
8. Install bulbs (not included). See relamping label located near socket area for type and maximum allowed wattage.
9. Hang all crystal glass parts as shown on drawing. NOTE: To replace broken crystals extras are included in hardware bag. Replace by gently bending open pin, remove broken crystal, hook new one, then close back pin. Avoid bending pin into sharp angle.