

IMPORTANT TURN OFF POWER AT MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE STARTING INSTALLATION

Carefully unpack and identify all parts before assembly. Bulbs are not included.

- 1. Fasten two provided long machine screws into mounting plate into holes corresponding with fixture plate two holes. Lock machine screws by fastening with small hex nuts, from side opposite screw heads.
- 2. Gently pull out house supply wires from outlet box and pass through center hole of mounting plate. Then fasten mounting plate to outlet box using two screws supplied with outlet box.
 - **Note:** To install mounting plate onto octagonal or round outlet box, see fig. 1 diagram for correct mounting hole location. To install mounting plate onto 2" X 4" outlet box, see fig. 2.
- 3. Test mount fixture plate to outlet box to make certain the two machine screws protrude about 1/4" (5mm) out from fixture plate. If not, then must loosen small hex nuts and adjust accordingly the length of machine screws.

4. ELECTRIC CONNECTION:

- Before starting wire connection, enlist a helper to support the fixture, or rest on a stepladder, or make a hook from a wire coat hanger and temporarily suspend the fixture from mounting plate.
- A. Connect fixture wire- without tracer (round & smooth) or black- to black or red house supply wire with plastic wire connector.
- B. Connect fixture wire- with tracer (square & ridged) or white- to white house supply wire with plastic wire connector.
- C. Connect fixture ground wire to house supply ground wire (usually with green insulation) with plastic wire connector. NOTE: If there is no supply ground wire at outlet box then attach fixture ground wire securely onto green grounding screw located at mounting plate. IMPORTANT: Never connect ground wire to black or white house supply wires. Make certain no loose conductors protrude outside of wire connectors. Make certain all wires are securely held together by wire connectors, and use electrical tape to secure them together.
- 5. Install fixture plate onto outlet box by fastening with enclosed ball cap nuts onto protruding machine screws.
- 6. Place shade over threaded socket then spacer tube and secure with counter ring, using supplied wrench.
- 7. Install bulb (not included). See relamping label located at socket area for type and maximum allowed wattage.

©MURRAY FEISS IMPORT CORP.

MURRAY FEISS