

YFUR-SBA1324200
CRANK TABLE

YOSEMITE HOME DECOR



**YFUR-SBA1324200
CRANK TABLE**

IMPORTANT SAFETY INSTRUCTIONS

- Please read all instructions carefully before assembling
- For your safety, assembly by two or more adults is strongly recommended
- Keep instructions for future use
- Use only vendor supplied hardware to assemble. using unauthorized hardware could jeopardize the structural integrity for the item:-

PRE-ASSEMBLY:-

- Remove all parts and hardware from the box and lay out on a clear carpeted or scratch-free work surface as this will avoid damaging parts during assembly. The shipping box provides an ideal work surface.
- Do not dispose of any packaging or contents of the shipping carton until assembly is completed to avoid accidentally discarding small parts or hardware
- Use the parts and hardware lists below to identify and separate each of the pieces included.
- The illustrations provided allow for easier assembly when used in conjunction with the assembly instructions
- The use of power tools to aid in assembly is not recommended. Power tools can damage hardware and split wood.

PARTS INCLUDED:-

- A. ALAN KEY BOLT 6 PC
- B. ALAN KEY 1 PC
- C. WRENCH 1 PC
- D. IRON LEGS 3 PC



(HARDWARE)

HARDWARE

Assembly instruction steps:- 1



(A)



(B)
REMOE ALL THE 3ALAN KEY BOLT
TOOL REQUIRED (INCLUDED):-

(C)



PUT IRON LEGS WITH LEG NUMBER (A)

STEP 2. PUT IRON LEGS WITH LEG NUMBER (B)



FIX THE ALL ALAN KEY BOLT WITH HELP OF ALAN KEY AND TIGHT IT

STEP3.

THE TABLE IS SHIPPED WITH THE HANDLE ASSEMBLY ON THE INSIDE OF THE TABLE BASE FOR EASE OF PACKING. YOU WILL NEED TO DISSASSEMBLE THE HANDLE AND RE ASSEMBLE IS SHOW PICTURE .TIGHTEN THE OUT SIDE NUT USING THE WRENCH (C)



STEP 4.

ASSEMBLE THE TABLE TOP TO THE BASE BY INSERTING THE THRADEEL ROD ON UNDER SIDE OF THE TABLE TOP TO THE TABLE BASE METAL TUBE . ROTATE TOP CLOCK WISE UNTIL IT IS SECURELY ATTACHED TO THE TABLE BASE SHOW IN PICTURE.



COMPLETEY ASSEMBLED

