

Installing Universal Tilt Wall Mount to Metal Stud Walls (Metal Stud Accessory Kit ACC 215 Required)

Models: ST 630, ST 630-S,
ST 630P, ST 630P-S

⚠ WARNING

- Drywall must be 1/2" or thicker, and metal stud must be 24 gauge or thicker.
- Make sure that the wall will safely support the combined load of the equipment and all attached hardware and components.

1 Using a stud finder, locate and mark the edges of the metal stud used in mounting this product. Use of an edge to edge stud finder is highly recommended. Use a level to draw a level, vertical line down the center of the stud. Level tilt assembly (**B**), and mark the center of the two mounting holes. Make sure that the mounting holes are on the stud centerlines. Drill two 1/2" holes through drywall and metal studs. **Note:** It may be necessary to drill 5/32" pilot holes prior to drilling 1/2" holes.

Refer to instruction sheet included with Peerless accessory kit ACC 215 for metal studs to install togglers. Loosely fasten tilt assembly (**B**) to wall using two 1/4-20 x 2-1/2" screws as shown. Level, hold, and then tighten all screws.

Skip to step 2 on page 6 of main instruction sheet.

