

KOHLER® Roughing-In

K-T10055-9, K-10044, K-T10056-9, K-T10057-9 OBLO™ RITE-TEMP® BATH/SHOWER VALVE TRIM

Product Information

Applicable product*:	
Bath/shower valve trim with 1/2" IPS threaded spout	K-T10055-9
Shower valve trim, less diverter spout	K-T10056-9
Mixing valve trim	K-T10057-9
Bath spout	K-10044
Required Rite-Temp® pressure-balancing valve:	
Without stops, NPT connections OR	K-304-K
With stops, CPVC connections	K-304-KP
With stops, NPT connections OR	K-304-KS
Pressure-balancing valve, push-button diverter OR	K-305-K
Pressure-balancing valve, push-button diverter and screwdriver stops OR	K-305-KS
HiFlow with stops, NPT connections	K-306-KS
Optional accessories:	
Deep rough-in kit – for use with K-304-K, K-304-KP, K-304-KS and K-306-KS	1073881

Deep rough-in kit for valves with push button diverter – for use with K-305-K and K-305-KS

1092535

Installation Notes

Install this product according to the installation guide.

Install the Rite-Temp valve according to the installation guide.

NOTICE: If installing with the K-306-KS valve: Use 1-5/8" (4.1 cm) screws when attaching the seal plate to the valve. Do not use 2-3/8" (6 cm) screws, which will damage the valve.

Avoid cross-flow conditions. Do not install a shut-off device on either valve outlet.

Cap the shower outlet if the deck-mounted spout, diverter, or handshower is connected to the spout outlet.

Install a 7" (17.8 cm) to 18" (45.7 cm) straight pipe or straight tube with single bath elbow between the valve and the wall-mount spout.

