INSTALLATION MANUAL

METAL CBU TYPES I, II, III, AND IV 1570 "F" SERIES



5935 CORPORATE DRIVE MANHATTAN, KANSAS 66503


> Ph. 800-275-1747 Fax. 800-275-5081

www.auth-florence.com

TABLE OF CONTENTS

DESCRIPTION	PAGE
CBU INFORMATION	2
SITE PREPARATION AND PEDESTAL INSTALLATION	3
SECURITY TOOL REQUIREMENTS	4
INSTALLATION OF AN ARROW LOCK	5
PARCEL ARROW LOCK INSTALLATION	7
PEDESTAL TO CBU INSTALLATION	9


YOUR ISO 9001 MAILBOX SUPPLIER



	TYPE I	TYPE II	TYPE III	TYPE IV
INSTALLED HEIGHT	62"	62"	62"	62"
DEPTH	17-7/8"	17-7/8"	17-7/8"	17-7/8"
WIDTH	30-1/2"	30-1/2"	30-1/2"	30-1/2"
WEIGHT (WITHOUT PEDESTAL)	107 LBS	111 LBS	147 LBS	137 LBS
WEIGHT (WITH PEDESTAL)	125 LBS	129 LBS	162 LBS	152 LBS
	8	12	16	12
QTY OF STANDARD COMPARTMENTS	0	12	16	13
QTY OF PARCEL COMPARTMENTS	2	1	2	1
PARCEL COMPARTMENT HEIGHT	10", 13"	10"	10", 13"	10"

91194_F_INSTALL AF PART # 91194 Rev A

2



IMPORTANT NOTICE FOR USPS INSTALLERS

METAL CBU TYPES I, II, III, AND IV 1570 "F" SERIES

INSTALLER MUST ORDER McGARD SCREW DRIVER (USPS - MAIL EQUIPMENT SHOP PART NUMBER 110050)
TO INSTALL AND SERVICE THE PARCEL ARROW LOCK COVER ON THE NEW AUTH-FLORENCE CBU.

IF THE

McGARD SCREW DRIVER MES NO. 110050

NEEDS TO BE ORDERED IT MAY BE ORDERED BY FAXING AN "OFF CATALOG" eBUY REQUEST TO:

> USPS MAIL EQUIPMENT SHOP FAX NO. (202) 281-2643




QUESTIONS? CALL THE USPS MAIL EQUIPMENT SHOP AT (202) 281-2620

INSTALLATION OF AN ARROW LOCK

METAL CBU TYPES I, II, III, AND IV 1570 "F" SERIES

- OPEN ARROW LOCK DOOR
- REMOVE FOUR (4) 86091 10-32 LOCK NUTS, AS WELL AS 92303 PLATE - LOCK SUPPORT
- 3 PLACE ARROW LOCK INTO POSITION
- INSTALL 92303 PLATE LOCK SUPPORT AS SHOWN
- **5** REPLACE FOUR (4) 86091 10-32 LOCK NUTS

	PART #	DESCRIPTION
REQUIRED TOOLS	86091	10-32 LOCK NUT
3/8" SOCKET WRENCH	92303	PLATE - LOCK SUPPORT
PLIERS		ARROW LOCK




PARCEL ARROW LOCK INSTALLATION METAL CBU TYPES I, II, III AND IV 1570 "F" SERIES

- OPEN PARCEL DOOR AND REMOVE FOUR (4) 86091 10-32 LOCK NUTS
- INSTALL ARROW LOCK AS SHOWN AND REPLACE FOUR (4) 86091 10-32 LOCK NUTS
- INSTALL PARCEL LOCK COVER 91255
 USING TWO (2) 84994 10-32 X .375 UNF2A 18-8 SS PASSIVATED 1-WAY TAMPER
 PROOF FASTENERS, AND ONE (1) 84995
 8-32 x .250 UNF-2A 18-8 SS PASSIVATED
 1-WAY TAMPER PROOF FASTENER.
- INSTALL PARCEL LOCK COVER 91259 US-ING TWO (2) 84993 10-32 X .312 UNF-2A 18-8 SS PASSIVATED MCGARD FASTEN-ERS.

REQUIRED TOOLS			
FLAT SCREWDRIVER			
USPS PROPRIETARY MCGARD TOOL			
3/8" SOCKET WRENCH			

	PARI #	DESCRIPTION
	84993	10-32 x .312 UNF-2A 18-8 SS
		PASSIVATED MCGARD
	84994	10-32 X .375 UNF-2A 18-8 SS
		PASSIVATED 1-WAY TAMPER PROOF
	84995	8-32 x .250 UNF-2A 18-8 SS
		PASSIVATED 1-WAY TAMPER PROOF
	86091	10-32 LOCK NUT
l	91255	COVER - LATCHING ASSEMBLY
	91259	COVER - ARROW LOCK
ĺ		ARROW LOCK
İ		

PARCEL ARROW LOCK INSTALLATION



PEDESTAL TO CBU INSTALLATION METAL CBU TYPES I, II, III AND IV 1570 "F" SERIES

- OPEN MASTER LOADING DOORS
- REMOVE LEFT AND RIGHT SIDE 91079
 FLOATING SHELVES, EXPOSING MOUNTING HOLES
- 3 PLACE UNIT ON PEDESTAL
- FROM UNDERNEATH UNIT, INSERT FOUR
 (4) 86101 3/8-16 X 1.25 CARRIAGE BOLTS
 UPWARD
- FROM ABOVE BOTTOM SHELVES, ADD FOUR (4) 86097 3/8" X .688 OD LOCK WASHER AND TIGHTEN FOUR (4) 86089B 3/8-16 HEX NUTS
- REPLACE LEFT AND RIGHT SIDE 91079
 FLOATING SHELVES

	PAKI #	DESCRIPTION
	86089B	3/8-16 HEX NUT
REQUIRED TOOLS	86101	3/8-16 X 1.25 CARRIAGE BOLT
9/16" SOCKET WRENCH	91079	FLOATING SHELF
	91129	PEDESTAL FOR TYPE I, II
	91121	PEDESTAL FOR TYPE III, IV
	86097	3/8" X .688 OD LOCK WASHER

PEDESTAL TO CBU INSTALLATION

10

