

## SPECIAL INSTRUCTIONS VERTICAL GANG ATTACHMENT KIT FOR RECESSED MOUNTED UNITS:

- 1) **Construct framing per Figure below. The center beam must be 1 ½”**
- 2) **Install the cabinets in the frame constructed using the screws and Instruction Sheets provided.**
- 3) **Adjust the hinges to balance out the gaps between the mirrors.**
- 4) **Carefully peel the protective vinyl and apply the trim to the face flanges of the adjacent cabinets.**

