



# Registers and Vents

## SURFACE MOUNT REGISTER INSTALLATION INSTRUCTIONS

1. Position your new register into the duct opening.
2. Gently press downward on the register to properly seat the unit squarely in the duct opening and flush with the floor surface.
3. Rotate damper control for desired air flow.

## BASEBOARD DIFFUSER INSTALLATION INSTRUCTIONS

1. Open vent by separating face of vent from the base.
2. Place your new vent in desired position and install using screws appropriate for your wall material.
3. Position interior duct flap to create an opening for air flow.
4. Snap vent face onto base.

## FLUSH MOUNT VENT INSTALLATION INSTRUCTIONS

1. Place vent frame in desired position prior to installation of wood floor.
2. Fit wood flooring into the sides of the vent.