

EASEL ACCESSORIES

White Board Package



Contains 1 each red, blue, green and black dry erase markers, one eraser, one bottle of white board cleaner and one telescopic pointer.

Paper Pad Package



Consists of 1 each red, blue, green and black dry erase markers, one standard paper pad, and one telescopic pointer.

Dry Erase Markers



- Blue
- Red
- Black
- Green

Dry Erase Markers



One each: blue, green, red and black.

Red Laser Pointers



Select from three models.

- Laser Pointer
- Blinking Laser Pointer
- Jumbo Laser Pointer

Paper Pads



Contains 5 pads per carton, 35 sheets per pad.

- A-306 Plain 27" x 34"
- R-305 Grid ruled 1", 27" x 34"
- T-106-Junior Plain 19" x 24"

Contains 10 pads per carton, 20 sheets per pad.

- S-200 Plain 27" x 34"

Contains 2 pads per carton, 30 sheets per pad.

- P-400-Post-It® Plain 25" x 30"

Carrying Case

Durable nylon zippered case fits all sizes of paper pad, writing surface and folding dual-purpose easels.



- Standard Paper Pad, Porcelain, or A-Frame
- D-305 Portable Easel
- H321, Brass Easels or H323

RF PowerPoint Remote with Green Laser Pointer



- Page Up/Down functions.
- Radio frequency range of 30 feet.
- Extremely visible green laser pointer.

Green Laser Pointers



Select from two models.

- Laser Pointer
- Jumbo Laser Pointer