

COASTER[®]
Fine Furniture

700395

3PCS COFFEE TABLE SET

ASSEMBLY INSTRUCTION
COASTER FINE FURNITURE



www.coastercompany.com

Assembly Instruction





ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.





Warning !

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.


PARTS IDENTIFICATION:

A		WOOD TOP	1PC
B		LEG	4PCS
C		WOOD TOP	2PCS
D		LEG	8PCS


HARDWARE PACKAGE:

E	WASHER		ϕ 5/16*22mm	12PCS
F	SPRING WASHER		ϕ 5/16	12PCS
G	SCREWS		ϕ 5/16*2-1/4"	12PCS
H	ALLEN WRANCH		4mm	1 PC


Step : 1



Step : 1



Step : 2



Step : 2

