

Duck Covers

Instruction Manual



duckCOVERS.com
Like water off a duck's back

Thank you for purchasing your Duck Cover including patent pending Duck Dome from Flexible Storage Group. Your new cover is designed to provide maximum weather protection, eliminate pooling of water and debris, and prevent mold and mildew build up that often occurs when patio furniture covers are kept on furniture for an extended period of time.

How To Keep Your Duck Cover Looking Like New

Proper care and use of your new Duck Cover will significantly increase the life of your Duck Cover and Duck Dome. Failure to adhere to care instructions may void the warranty.

- Keep your Duck Cover material clean:
 - Spot wash, hand wash or launder in a front-loading washing machine, using cold water and mild detergent only.
 - Hang to dry. DO NOT PUT IN DRYER OR IRON. Exposure to high heat can damage the fabric beyond repair.
 - Do not use abrasive cleaners or cleaners with bleach.
 - Avoid using abrasive cleaning tools. Use only a clean cloth, sponge or soft bristled brush.
- Keep your Duck Dome clean:
 - Wipe clean with water.
- Avoid pulling your cover across rough surfaces by folding or rolling it up before moving from one location to another.
- Avoid placing the Duck Dome near sharp objects during installation, removal and storage.
- Fold your Duck Cover and Duck Dome when not in use. Loosely fold or roll your Duck Dome to avoid creation of deep creases and possible damage.
- Always store your Duck Cover and Duck Dome dry.
- Do not expose Duck Covers inflator to water and always store in a warm, dry place.

Installation Instructions

Rectangle / Oval, Square Tables with Chairs -- Ottomans or Coffee Tables

1. Install Duck Dome First:

- Place Duck Dome flat on table with the inflation valve facing upward.
- Center Duck Dome on table both lengthwise and widthwise.
- Tie down all four corners to your chairs with the ropes provided*. Leave a little slack to allow for the growth of the Duck Dome during inflation. Adjustments in the Duck Dome position can be made after inflation.
- Unscrew valve cap and inflate the Duck Dome completely using your Duck Covers inflator.
- Screw valve cap back on securely.

**Duck Domes for ottomans and coffee tables do not have corner tie down ropes. Simply place inflated Duck Dome on your ottoman or coffee table and install cover over the Duck Dome.*

2. Install Duck Cover over the Duck Dome and Outdoor Furniture:

- Place cover over Duck Dome and table with chairs.
- Center cover.
- If the cover is slightly large pull out chairs close to the seam.
- Tie down one end of the cover tight using attached tie downs.
- Pull other end tight and tie down using attached tie downs.
- Pull one side tight and tie down using attached tie downs.
- Pull other end tight and tie down attached tie downs.
- Cover should be tight and look like picture on packaging.

Round Table with Chairs

1. Install Duck Dome First:

- Place Duck Dome flat on table with the valve of the base ring facing upward (Duck Dome will be upside down for the first step).
- Unscrew the valve cap and inflate base ring using your Duck Covers inflator.
- Screw valve cap back on securely.
- Flip the Duck Dome upright so that the inflated ring is resting on the tabletop.
- Unscrew the valve cap that is now on top and inflate Duck Dome using your Duck Covers inflator.
- Screw valve cap back on securely.
- Center Duck Dome on table.

2. Install Duck Cover over the Duck Dome and Outdoor Furniture:

- Place cover over Duck Dome and table with chairs.
- Center cover.
- If the cover is slightly large pull out chair backs close to the cover seam.
- Tie down one side of the cover tightly using attached tie downs.
- Pull other side tight and tie down using attached tie downs.
- Make your way around cover and tightly fasten remaining tie downs.
- Cover should be tight and look like picture on packaging.

Chat Table with Chairs

1. Install Duck Dome First (5 Duck Dome airbags are provided):

- Turn chairs so that chair backs are facing the table (seat should be facing away from table).
- Place the 36"x36" Duck Dome flat on the table top with the valve facing upward and tie down corners using attached tie downs.
- Unscrew valve cap and inflate Duck Dome using your Duck Covers inflator.
- Screw valve cap back on securely.
- Prior to installing the four remaining 24"x32" Duck Domes on your outdoor furniture, unscrew valve cap and inflate Duck Domes using your Duck Covers inflator.
- Place Duck Domes in each chair lengthwise from the seating surface and angle towards the backrest.
- Center Duck Dome on the furniture and tie down corners using attached tie downs.

2. Install Duck Cover over the Duck Dome and Outdoor Furniture:

- Place cover over Duck Domes and table with chairs.
- Center cover.
- Tie down one side of the cover tight using attached tie downs.
- Pull other side tight and tie down using attached tie downs.
- Make your way around cover and tightly fasten remaining tie downs.
- Cover should be tight and look like picture on packaging.

Sofa, Loveseat, Chair, Chaise

1. Install Duck Dome First:

- Prior to installing Duck Dome on your outdoor furniture, unscrew valve cap and inflate the Duck Dome using your Duck Covers inflator.
- Screw valve cap back on securely.
- Place Duck Dome on seating surface lengthwise between arms and angle towards the backrest.
- Center Duck Dome on the furniture.
- Tie down all three or four corners depending on airbag size to your chairs with the ropes provided**. Leave a little slack to allow for the growth of the Duck Dome during inflation. Adjustments in the Duck Dome position can be made after inflation.

***If your furniture does not have gaps through which to secure the Duck Dome tie downs, your Duck Cover will hold the Duck Dome in place once securely fastened to your outdoor furniture.*

2. Install Duck Cover over the Duck Dome and Outdoor Furniture:

- Place cover over Duck Dome and sofa, loveseat, chair or chaise.
- Center cover.
- Tie down all four corners tightly using attached tie downs.
- Cover should be tight and look like picture on packaging.

BBQ Covers

1. Install Duck Cover over the BBQ:

- Place cover over BBQ.
- Center cover.
- Fasten Velcro straps on either end of the cover to prevent cover from coming off during windy conditions.
- Cover should fit evenly over both ends of the BBQ.
- Cover in place should look like picture on packaging.

Air Pump

This is a high volume at low-pressure pump intended to inflate/deflate the Duck Dome.

- Prior to initial use and for all subsequent recharging, the battery must be charged for 10 hours minimum or overnight.
- As the batteries weaken from use, it is time to recharge them. Do not wait until they are fully discharged.
- Nozzle adapters provided to inflate/deflate boats, pool toys and air mattresses (not to be used for Duck Dome inflation).

To Inflate:

- Insert end marked “Inflate” into valve opening on the Duck Dome and switch on for inflation. No nozzle adapters required.
- The “ - ” symbol on the switch means ON, “ O ” means OFF.
- Ensure valve is not obstructed; otherwise it could overheat and damage the pump.
- Inflate Duck Dome completely.

To Deflate:

- Insert end marked “Deflate” into valve opening on the Duck Dome and switch on for deflation. No nozzle adapters required.
- The “ - ” symbol on the switch means ON, “ O ” means OFF.
- Ensure valve is not obstructed; otherwise it could overheat and damage the pump.
- Deflate Duck Dome completely.

If you have any questions please contact us at www.duckcovers.com OR view our “How To Install” video at www.duckcovers.com.

Limited Warranty

Duck Covers are warranted to be free of material or workmanship defects for a period of 2 years from the date of purchase. Exchanges due to size, fit or style selection problems may be made within 30 days of purchase. No exchanges will be made after 30 days. The warranty protects your furniture cover against damage when used under normal conditions and does not cover damage from acts of god, vandalism, neglect, misuse, or improper use. The warranty is in lieu of all warranties expressed or implied, and under no circumstances shall we be liable for any damages in excess of the covers’ original purchase price. Should any trouble occur during the warranty period, please contact Customer Service at (888) 919-FLEX (3539) or via email at customer.service@flexiblesg.com for support. Proof of purchase is required to validate warranty coverage.