

PINPOINT MOUNTS

AM-24 Universal Speaker Wall Mount Installation Manual

Attaching the AM-24 to the wall

1. Remove cover plate

2. Remove mounting Tip

3. Install mount body to Ceiling

4. Replace Cover Plate

5. Replace Mounting Tip with speaker Mounted & make alignment adjustments. When all adjustments are complete, tighten all set screws with allen key.

It is recommended that you inspect the location you intend to use this product prior to installation to insure it will be capable of supporting the total weight of the speaker and mount. Please read through this installation sheet prior to installing the mount. If you do not understand any part of the installation, contact our customer support department.

Attaching the speaker to the AM-25

The AM-24 can attach to speakers using a Keyhole, Single or Dual mounting points. These are the 3 most common types of mounting points found on speakers. Examine your speaker(s) to determine the mounting point used and follow the directions shown. When the installation is complete, check to insure all screws and bolts are tight.

Keyhole
Parts used:
6,10

Single Point
Parts used:
4,5,6
12,13

To test the threaded mounting point of the speaker, the correct bolt should thread with out effort.

Dual Point
Parts used:
1,4,12,13
11
7 or 8

To test the threaded mounting point of the speaker, the correct bolt should thread with out effort.

Parts

MT.	1. Dual Point Adapter x1	4. M6 x 25mm x1	9. Wood Screw x2
	2. Drywall/Ceiling Anchor x2	5. 1/4-20 x 1" x1	10. Keyhole Slot Adapter x1
	3. Allen Key Wrench x1	6. M5 x 25mm x1	11. Large Washer x2
		7. M6 x 12mm x2	12. Small Washer x1
		8. 1/4-20 x .5" x2	13. Split Washer x1
			14. M5 x 12mm x2

