Quality is not an act, it is a habit...

The Nightingale CXO™ is 94% Recyclable

Quality is not an act, it is a habit...

The Nightingale CXO™ is 94% Recyclable

Quality is not an act, it is a habit...

The Nightingale CXO™ is 94% Recyclable

How To Care For Your CXO™

With regular care and maintenance, your CXO™ will provide many years of superior performance and satisfaction. To maintain the quality of your Nightingale product, please follow the cleaning procedures outlined here.

Mechanism

Oil sparingly moving parts once a year with light machine oil. NOTE: to prevent dripping, avoid over lubrication which may cause damage to surrounding surfaces.

ABLEX™ Mesh

Clean with mild detergent and water applied with a damp clean cloth or sponge. Rinse with water. Never use hot water and avoid scrubbing. Use gentle movements.

Plastic parts

Clean with mild detergent and water. Do not use abrasives or excessive amounts of cleaner.

Frame

Powder coat frames can be cleaned by wiping with a damp cloth and any mild detergent.

* The instruction for the care and maintenance of Nightingale Products are provided to you as a service. No warranty is implied since results may vary.



Nightingale Office Chairs Toll-Free Phone: 1.800.363.8954 Fax: 1.800.637.6784 Website: www.nightingalechairs.com Email: info@nightingalechairs.com



SCAN this QR Code To Learn More About How To Use This CXO Chair?

User Guide Instructions









Congratulations On Purchasing Nightingale's CXO™

Please read and understand this user guide with instructions before operating this office chair.



How To Use and Adjust My CXO™



A. Pneumatic Height Adjustment To lower, turn the paddle up while seated. To raise, turn paddle up with your weight off seat.

D. Tension Knob Turn clock-

wise to increase tension, turn

counter-clockwise to decrease

G1. Arm Pivot Adjustment

Push button in to pivot, release

Adjustment (Back button on side

of pad) Push button in to move to desired position, release

(Front button on side of pad)

button to lock into position.

G2. Arm Pad Front To Back

button to lock into position.

tension



B. Seat Slider Pull lever bar up to unlock, move seat to desired position, release lever to lock into position.

E. Arm Height Adjustment To raise or lower arm height,

pull trigger up and move to desired position. Release

H. Horizontal Lumbar Adjustment

Press button down and move

lumbar to desired depth, release

button to lock into position.

top position.

To raise lift lumbar to desired

position. To lower lumbar, lift to

trigger to lock into position.



To lock chair in position. turn paddle up, to allow free movement, turn paddle



F. Horizontal Arm Adjustment Pull arm out from seat to desired position from bottom of arm, for increased width, Push arm in to decrease width.



I. Ratchet Height Adjustable Headrest Simply lift headrest to desired position and headrest locks auto-matically. To lower headrest lift headrest to top position. Headrest Feature Available Only On The 6200D







CXO Version.



Office

Chairs

PASS IT ON!

Our customers often tell us their friends stop and ask about their CXO™ If this happens to you, please give your friend this card so they can learn more about our chairs.

1.800.363.8954 info@nightingalechairs.com



Office

Chairs

PASS IT ON!

Our customers often tell us their friends stop and ask about their CXO™ If this happens to you, please give your friend this card so they can learn more about our chairs.

1.800.363.8954 info@nightingalechairs.com



Office Chairs



PASS IT ON!

Our customers often tell us their friends stop and ask about their CXO™ If this happens to you, please give your friend this card so they can learn more about our chairs.

1.800.363.8954 info@nightingalechairs.com