




## CEILING FIXTURE INSTALLATION INSTRUCTIONS

### ASSEMBLY AND INSTALLATION

#### TURN OFF POWER FROM THE MAIN CIRCUIT BEFORE INSTALLING FIXTURE.

1. Tools and materials needed: screwdriver, pliers, wire nuts, electrical tape.
2. To help prevent the possibility of electrical shock, the use of rubber sole shoes is recommended.
3. Exercise care when handling the fixture to avoid cuts or abrasions.
4. If a ladder is needed, make sure to use a sturdy wooden one.
5. Carefully remove fixture and all parts from box and place them on an even smooth surface.
6. Remove glass lens carefully by turning three screws counter clockwise.
7. Remove the lamp if provided from Lampholder, gently separate the lamp from the lampholder by holding the base of the lamp in your fingers. Do not try to remove the lamp by holding the tube (glass) section. And turn it anti clockwise.
8. Electrical connections: Attach the green or bare copper wire to the ground screw on the cross bar. (Ground must be securely attached or unit may not work properly). Connect white supply wire to white fixture wire, cover the wires with wire nut/or twist wires together and cover really well with Electrical tape. Connect black supply wire to black fixture wire, cover the wires with wire nut/or twist wires together and cover really well with Electrical tape. Make sure on both connections no wires are exposed at all. Push connected wires back into electrical box.

9. Turn the mounting screws through the key holes to the outlet box. Tighten the screws.
10. Install the lamp into the lampholder by gently pushing the lamp into the lampholder. Holding onto the base of the lamp, turn it clockwise until it snaps into place. CAUTION: Refer to re-lamping label located near the lampholder for recommended maximum wattage. Do not exceed recommended wattage.
11. Carefully place the Glass Lens on, and use phillips screwdriver to turn three screws in to lock and hold the lens. Helpful Hint: Please get one more person to hold the Glass Lens when turning the screws.
12. Turn power on.



#517326  
#517318  
#517334

Customer Service :  
1-500-558-8700