

ASSEMBLY INSTRUCTIONS

MODEL NO. 978L "HEIRLOOM CHERRY"
(or) **979L** "NOSTALGIC OAK"

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify, and count all parts and metal hardware. Compare with parts list to be sure all parts are present. If any part(s) are missing or damaged, phone, fax, or mail to our Customer Service Department. For efficient and speedy service, please indicate the model number and code letter of part(s) needed.

IMPORTANT NOTE: Follow instructions listed below in the proper sequence as numbered to assure fast, easy and correct assembly.

- Note:** Upon opening, thoroughly clean all wood surfaces with furniture polish to remove dust and dirt that may have settled onto finish during shipment. If you have residue from tape on the glass, use a warm damp washcloth to wet the surface and remove the residue.
- Slide Legs (C) into grooves on ends of Posts (B). Tighten End Caps (D) into ends of Posts (B) to secure Legs (C) in place.
- Insert Machine Screws (G) through holes near base of Posts (B) and tighten into ends of Cross Brace (E). Insert Wood Plugs (H) into screw holes.
- Push Handles (F) through Posts (B), Spacers (I) and tighten into Mirror sides (A). Remove tape from glass by holding Mirror frame (A) firmly and peeling tape slowly and gently away from glass. Avoid putting excessive pressure on Mirror (A) and observe the same care that you would take with any glass article.
- Your furniture has been handcrafted and skillfully finished by fine craftsmen. Rich, deep antique finishes have been applied which require very little polish. However, should you desire a shinier finish, simply use any good grade of furniture polish, rubbing the finish lightly as it is being applied. Allow to dry and buff lightly with a soft cloth.




If you have a problem, we want to have the opportunity to make it right!

PARTS


- (A) MIRROR
- (B) POSTS (2)
- (C) LEGS (4)
- (D) END CAPS (2)
- (E) CROSS BRACE
- (F) HANDLES (2)
- (G) MACHINE SCREWS (4)
- (H) WOOD PLUGS (4)
- (I) SPACERS (2)

HARDWARE ILLUSTRATIONS



Tools required: Screwdriver (not included)

ATTENTION: SOME NUMBERED PARTS LISTED ON THE INSTRUCTION SHEET MAY NOT BE IN PARTS BAG AS THEY MAY ALREADY BE ASSEMBLED. CAREFULLY CHECK PARTS AND PACKING MATERIALS PRIOR TO ORDERING REPLACEMENTS.



Should there be any missing or defective part(s),
PLEASE DO NOT RETURN THIS PRODUCT TO THE STORE

(Many problems can be resolved without returning this product to the retailer)

Model No.

- 978L "Heirloom Cherry"
 979L "Nostalgic Oak"

FAX this form to (310) 841-0842

or call Customer Service at (800) 622-4456 or (310) 204-2224
Have your model number and part code letter handy.

Part Letter	Description	Quantity
Part Letter	Description	Quantity
Part Letter	Description	Quantity

Name _____
Address _____
Daytime Phone () _____
Reason for Replacement _____
Place of Purchase _____