


Intuitive Frame (IT Leg)



Step 1:
Place
crossbar
over C-
bracket



Step 2: Line up holes
and screw fasteners to
top and bottom of each
side of frame.

All-terrain (AT Leg) Skip Step 1&2



Step 3: Align slots on legs with metal
insert holes in tops and tighten
screws. Flip over table and enjoy
years of use.

Adjusting Height

Remove
Set-
Screw
with Hex
Tool



Slide
Out
Leg
Lower



Take
off
Bezel



Place
Bezel at
Desired
Height
&
Replace
Set-
Screw



Height Settings

it leg top height	23.5"	24.5"	25.5"	26.5	27.5"	28.5"	29.5"	30.5"	31.5"	32.5"	33.5"	34.5"
AT leg top height	24.5"	25.5"	26.5	27.5"	28.5"	29.5"	30.5"	31.5"	32.5"	33.5"	34.5"	35.5"
# of holes showing	0	1	2	3	4	5	6	7	8	9	10	11