




Pair your new Trailblazer<sup>®</sup> with accessories for superior performance.



**Most common stock numbers:**

- Trailblazer 275: #907 506-001
- Trailblazer 325: #907 510-001
- Trailblazer 325 w/Excel power: #907 510-003
- Trailblazer 325 EFI: #907 512
- Trailblazer 325 EFI w/Excel power: #907 512-001

# TRAILBLAZER



### Stick Welding

- #173 851 2/0 weld cable set (includes electrode holder and ground clamp)
- #S119944-089 10 lb. Plastic Pak Hobart<sup>®</sup> 418 1/8" 7018 stick electrode
- #S116544-089 10 lb. Plastic Pak Hobart Pipemaster<sup>®</sup> 60 6010 stick electrode



### Wire Welding with Voltage Sensing (VS) Feeder

- #951 185 SuitCase<sup>®</sup> X-Treme<sup>™</sup> 12VS wire feeder (includes Bernard<sup>®</sup> Dura-Flux gun)
- #191 981 Connector for feeder (Tweco)
- #243618050 50' 2/0 weld cable from power source to feeder (includes connectors)
- #243671050 50' 2/0 weld cable from power source to work (includes ground clamp and connector)
- #S225719-053 Hobart Fabshield<sup>®</sup> XLR-8 1/16" 33 lb. spool flux-cored wire



### Wire Welding with Remote Control (RC) Feeder

- #951 188 SuitCase 12 RC wire feeder (includes Bernard Q300 gun)
- #191 981 Connector for feeder (Tweco)
- #242205050 50' control cable extension
- #243618050 50' 2/0 weld cable from power source to feeder (includes connectors)
- #243671050 50' 2/0 weld cable from power source to work (includes ground clamp and connector)
- #32-80-580 Smith inert gas regulator/flowmeter
- #244905050 50' of gas hose assembly
- #S307608-085 Hobart Quantum Arc<sup>™</sup> 6 .035" solid wire
- #151 032 .035" V-grooved drive roll kit



### Spoolgun System

- #130 831 Spoolmatic<sup>®</sup> 30A
- #32-80-580 Smith inert gas regulator/flowmeter
- #137 549 WC-24 weld control
- #243671050 50' 2/0 weld cable from power source to work (includes ground clamp and connector)
- #404303504 MAXAL<sup>®</sup> 4043 .035" 1 lb. plastic spool aluminum wire

**Your Trailblazer welder/generator can do even more with these hard-working options:**

#### Excel<sup>™</sup> Power

Excel power provides 120V, 60Hz of pure sine wave generator power at idle speed and while welding. When connected to the Excel power receptacle, you get up to 2400 watts of the cleanest generator power available. Plus, you can run most jobsite tools — like grinders, chop saws, drills and lights — at idle speed.

#### Electronic Fuel Injection

Electronic Fuel Injection (EFI) offers better fuel economy, longer runtimes, fast starts, reliable operation and reduced emissions.

**See reverse for more Trailblazer and Bobcat<sup>™</sup> welder/generator accessories**






Pair your new Bobcat™  
with accessories for  
superior performance.

**Most common stock numbers:**

- Bobcat 225: #907 498-001
- Bobcat 250: #907 500-001
- Bobcat 250 EFI: #907 502

**BOBCAT**



**Stick Welding**

- #173 851** 2/0 weld cable set (includes electrode holder and ground clamp)
- #S119944-089** 10 lb. Plastic Pak Hobart® 418 1/8" 7018 stick electrode
- #S116544-089** 10 lb. Plastic Pak Hobart Pipemaster® 60 6010 stick electrode
- #S112244-089** 10 lb. Hobart 335a 1/8" 6011 stick electrode



**Wire Welding with Voltage Sensing (VS) Feeder**

- #951 185** SuitCase® X-Treme™ 12VS wire feeder (includes Bernard® Dura-Flux gun)
- #191 981** Connector for feeder (Tweco)
- #243618050** 50' 2/0 weld cable from power source to feeder (includes connectors)
- #243671050** 50' 2/0 weld cable from power source to work (includes ground clamp and connector)
- #S222112-029** Hobart Fabshield® 21B .045" 33 lb. spoolflux-cored wire



**Spoolgun System**

- #130 831** Spoolmatic® 30A
- #32-80-580** Smith inert gas regulator/flowmeter
- #137 546-011** WC-115A w/contactor
- #243679050** 50' weld cable from power source to WC115A
- #243671050** 50' 2/0 weld cable from power source to work (includes ground clamp and connector)
- #404303504** MAXAL® 4043 .035" 1 lb. plastic spool aluminum wire

**Electronic Fuel Injection**

Electronic Fuel Injection (EFI) offers better fuel economy, longer runtimes, fast starts, reliable operation and reduced emissions.

**Accessories for Bobcat and Trailblazer® Welder/Generators**

- #907 335 Millermatic® 140 Auto-Set™
- #907 422 Millermatic® 211 Auto-Set™ with MVP™
- #907 405 Millermatic® 212 Auto-Set™
- #907 531 Spectrum® 625 X-TREME™
- #907 099-011 Dynasty® 200
- #907 627 Diversion™ 180
- #300 517 Adapter Cord, Full KVA for Engine Drives
- #300 913 Multi-Terrain Running Gear
- #300 919 Protective Cover (for use without protective cage)
- #300 917 Hose and LP Tank Mounting Assembly
- #300 430 Remote hand control (Trailblazer only)