


- Lay on the ground.
- Insert shelves and bottom into slots.
- DO NOT lock into final position yet.


Note:

Every tab has a groove on one side. Every slot has an indent.

The groove and the indent need to align to work correctly.



2




- Place back followed by side .
- Align all slots and tabs and press firmly.

Note:

Pressing tabs together creates Tension Lock. This will require effort. Stand up, and use your weight to press down.

Press tabs almost to the end, as shown below.



Parts



VS007RX



VS007LX



Sp002KX



HZ001KX




BK004KX







■ Press down on bottom **d** to lock in securely.





- Attach the top **(1)**. Press down firmly to secure top piece.
- Assemble bins (see instructions on bin) and slide into place





sqo.so/nsa see online assembly video

& more



- Adult assembly only
- Assemble completely before use

For children ages 4-7