
Think® Chair Assembly Instructions

- Lift seat depth adjustment handle, found under the front edge of the seat (1a). Hold the handle up and slide the seat all the way forward (1b).
- Lay the chair's back frame on top of the seat and align the back stops (2a). Holding onto the bottom of the back frame, rotate the back frame up until the back stops connect (2b).
- 3. Using the enclosed Allen-wrench, install screws on both sides of the back frame. Tighten screws.
- Please keep the original packaging materials for 14 days to facilitate a return if necessary (see warranty statement for details). After this period, we encourage you to recycle the packaging material.

If you have any questions, problems or requests please contact us at 888.STEELCASE (1.888.783.3522).

Outside the U.S.A., Canada, Mexico, Puerto Rico, and the U.S. Virgin Islands call 1.616.247.2500.





Adjust Your Think Chair to Fit You

The Think chair adjusts itself to your body. Simply sit and don't give it another thought. If you'd like to fine tune your chair, the card attached to the chair explains how. Additionally, you can print a PDF user guide and watch a demonstration of how to adjust your chair for the best ergonomic fit on our web site: steelcase.com.

Think of the Future

Many years from now, when your Think chair reaches the end of its useful life, it is designed to be easily separated for recycling in about five minutes using common hand tools. For disassembly and recycling instructions, call 888.STEELCASE or go to steelcase.com.

