

User Instructions.

Rocker / Recliner Chair

Please read the Instruction Manual below carefully before use.

This is a Rocker Recliner Chair. At anytime in a reclined seat position or in the upright position. You may enjoy the rocking motion by using your body weight in a back-front rocking motion.

Supervise children use of this Rocker Recliner.

To get into a reclined posture - Recline backrest

Sit into the seat.


Place your feet apart and or to either side of the footrest.

Place your left arm onto the left armrest.

Position your right hand to pull the handle(1) outwards and towards you.

Synchronise a backward push with your left arm.

Use your body weight and push backwards into the seat into a fully reclined position.




To get out of chair - move Seatback into Upright Position

Tilt your body weight slightly forward and upwards. Using your right hand, pull the handle(1) towards you.

The seat back will come up to an upright position.

Where necessary, use either your left arm or right arm to help lift- push yourself out of the seat.



Care & Maintenance

- 0 5
- Do not put HOT items directly on furniture surface.
- s Å
- Do not clean furniture with HARSH cleansers or polish.
- To prolong product lifetime, AVOID placing furniture under direct sunlight.



- Do not place furniture near heating or cooling vents.
- Do not write on furniture without a padded barrier to protect the surface.



To prolong the product lifetime, avoid extended and lengthy exposure to rain and sunshine. Where possible, place under covers and or patio and or awnings.



For residential use only. Not for commercial use.



Stains may be removed with mild soap solution and damp cloth.



Dust and pick-up spills using a clean, non-colored, lint-free cloth.