



OWNER'S MANUAL (FIRE PIT)

- PLEASE READ AND FOLLOW INSTRUCTIONS CAREFULLY BEFORE ASSEMBLY OR USE.
- FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN SERIOUS BODILY INJURY AND/OR PROPERTY LOSS.
- THIS FIRE PIT IS INTENDED FOR DOMESTIC OUTDOOR USE ONLY. NOT FOR COMMERCIAL USE.
- IT IS RECOMMENDED TO WEAR PROTECTIVE GLOVES WHEREVER NECESSARY.
- CAUTION IS TO BE TAKEN WHEN HANDLING THE FIRE.
- THESE INSTRUCTIONS MUST BE KEPT WITH THE CONSUMER AND RETAINED FOR FUTURE USE.

PRECAUTIONS AND SAFETY WARNINGS!

Read and follow the instructions. Retain these instructions for future reference.

- The product is intended for OUTDOOR Use Only Keep in a well-ventilated area.
- NEVER use the fire pit unless it's completely assembled and all parts are securely fastened and tightened.
- Always place the fire pit on a level surface and far away from combustibles.
- NEVER use gasoline, kerosene, alcohol or any other highly inflammable liquid for lighting!
- DO NOT leave the fire pit unattended while in use or while cleaning.
- NEVER touch metal parts of fire pit until it has completely cooled to avoid injuries.
- DO NOT move fire pit when it is lit or when it is hot.
- WARNING! Keep the fire pit out of reach of children & pets. NEVER wear loose clothing around the fire pit while it is in operation or while hot.
- NEVER remove charcoal as while in use or while cooling.
- NEVER dismantle this appliance while in use or hot.
- DO NOT use in windy conditions.

WHERE TO PLACE FOR USE

- DO NOT use fire pit indoors, on recreational vehicles or on boat.
- Locate this fire pit in an area with good ventilation.
- NEVER use or store any combustible or flammable material within 3 Feet spacing of fire pit.
- This fire pit should NEVER be used in a fully or partially enclosed area such as A garage, breezeway, carport and porch or under a surface that can catch fire.
- As the base of fire pit will get hot, it should be placed on a suitable surface that can withstand this heat.
- This fire pit is for OUTDOOR use only.

HOW TO USE

- Ensure that the assembly instructions given on previous pages are followed correctly.
- Locate the fire pit as per the guidelines given above and away from areas that may catch fire.
- Use charcoal or kindling wood and a suitable lighting method do not use kerosene, alcohol, gasoline or any other highly flammable liquid.
- ALWAYS WEAR SUITABLE PROTECTIVE GLOVES WHEN HANDLING.
- Please ensure that the fire pit has completely cooled before removing the ash.
- It is recommended to keep a fire extinguisher within reach.

KEEP THIS DOCUMENT IN A SAFE PLACE FOR FUTURE REFERENCE



HOW TO ASSEMBLE



WARNING

- While every effort has been made in the manufacture of your fire pit to remove any sharp edge, you should handle all components with care to avoid accidental injury.

1. Attach Leg (F) to the Bottom Ring (H) by using Bolt (AA) and Nut (CC), please DO NOT tighten the hardware at this time.



2. Attach the legs to the top ring (E) by using Bolt (BB). Insert one side of Decorative piece (G) into the connector inside of Bottom Ring (H) and attach another end on Top Ring (E) by using Bolt(BB). Repeat this step for rest Decorative piece (G). Tighten all the hardware at this time.




3. Attach the handle (A) into the mesh cover (B) by using Nut (CC), then place all the parts in order as the last figure. Now, the fire pit is ready for use



CONTENTS

Please check parts against the list below before assembling your fire pit. Take a few moments to familiarize yourself with the contents. Check that all holes are clear of paint before assembly.

No.	PARTS	Qty
A	Handle	1
B	Mesh cover	1
C	Wood grate	1
D	Fire bowl	1
E	Top ring	1
F	Legs	4
G	Decorative piece	12
H	Bottom ring	1
I	Poker	1



HARDWARE LIST

No.	Hardware	Qty
AA	M6X14 bolt	4
BB	M6X8mm bolt	16
CC	M6 Nut	5



WARNING

- Dispose of all packing carefully and keep out of the reach of children.
- Please read the section on fire pit safety prior to using your fire pit.

*Please refer to the picture of final product in case of any difficulty.

*Tool required for assembly: screwdriver which is not included in the hardware pack.