

# **DIMENSIONAL SPECIFICATIONS**

## **Overall Dimensions:**

<u>Nominal Dimension</u>: 68" x 15" x 37" (W-D-H) <u>Actual Dimension</u>: 68-5/8" x 14-5/8" x 36-7/8" (W-D-H)

#### **Space Between Endpanels:**

66-1/4" x 12-25/34" x 19-53/64" (W-D-H)

## **MATERIAL SPECIFICATIONS**

#### Top:

- 1-1/8" thick particleboard with Kraft backer bottom and high-pressure laminate (HPL) top cover.
- <u>*Top dimensions*</u>–66-1/8" x 14-9/64" (W-D)
- <u>*Top end caps*</u>: solid hardwood

#### **End Panels:**

- 1-1/8" thick particleboard with melamine surface back, and high-pressure laminate (HPL) surface top cover and .8 mm edge trim on the bottom.
- <u>End panel dimensions</u> -14-5/8" x 35-29/32" (W-H)

#### **Back:**

- 7/16" fiberboard with a wood grain pattern.
- <u>Back dimensions</u>-66-1/4" x 16-1/4" (W-H)

#### **Doors:**

- 3/4" particleboard with melamine both front and back, and .5 mm edgebanding on all four sides.
- <u>Door Dimensions</u>-13-1/4"x 16-13/32" (W-H)

## Hardware:

<u>End Panel Pack</u>- 262-3106/ 262-3107 <u>Product Pack</u>-262-3039 <u>Hardware Pack</u>-251-1326 MODEL: 10734

# **MODEL: 10734**

PECIFICATIONS



# **MODEL FEATURES**

- <u>10700</u> Series wood produce meets or exceeds ISTA shipping and ANIS/BIFMA X5.5 (latest Rev.) testing requirements for office furniture.
  - **Door Hinge Adjustment:**
  - The concealed "European" hinges on HON doors allow easy threeway adjustment of door alignment.
  - To raise or lower the door, locate the recessed Phillips screw farthest to the rear of the hinge. Rotate this screw to adjust the height of the door. You do not need to loosen the center locking screw to make this adjustment.
  - To adjust the side-to-side gap between the doors, adjust the Phillips screw closest to the door on the surface of the hinge body. You do not need to loosen the center locking screw to make this adjustment.
  - To adjust the in-out pitch of the doors faces, carefully loosen the center locking screw and slide to the correct position. <u>CAUTION</u>: Do not move this screw outside the adjustment seat range or the door may dislodge and fall. Tighten the center locking screw when the correct adjustment has been made.
- \*\*\*Classical contemporary styling, with hardwood accents.
- \*\*\*Attach all stack ons to base unit using the double coated tape supplied with the stack on. Application is permanent and removal will call damage to base unit.

## PARTICLEBOARD: All particleboard is ANSI grade IM3 or better.

# **CARTONING INFORMATION**

Carton-Outside Dimensions: 70-7/8" x 19-3/8" x 20-1/4" (W-H-D) Cubes: 16.1 Carton #: 242-2471 Weight: 1751b

## REVISIONS

1.1-Added instruction for proper door hinge adjustment. (8-29-02) 1.2-Corrected carton size and cube. (1-19-04)