88 5603 34 Terra Cotta Bistro Table (Terra Cotta Tile/Black Finish)

IMPORTANT NOTE

Carefully remove all the parts from the carton and put them individually on a soft cloth to prevent scratches or other damages occuring to the parts.

We have taken great care in the design of this product and request that you carefully and strictly follow our assembly instructions to ensure a completed product as it was designed.





Hardware List Part List Β. С Flat A. Top Leg 1 pc. Leg 1 pc. Wing Nut 4 pcs.(+1 extra) Washer 4 pcs.(+1 extra) 1 pc. **Table Assembly** Place Top (A) upside down on a soft cloth. Attach Leg (B) to Top (A) with Flat Washers and Wing Nuts, tighten Nuts half way. Attach Leg (C) to Top (A) and Leg (B) with Flat Washers and Wing Nuts, tighten up all Nuts. Wing Nut Turn the table to its' upright position. Flat Washer To level the table, adjust the adjustable levelers on the bottom of legs. В (See figure 1) n n 'n Figure 1

Note: Frozen precipitation may damage the top. Store inside in freezing weather.