


# 88 5800 80 Barrel Accent Chair



*Home Styles*

## IMPORTANT NOTE

Carefully remove all the parts from the carton and put them individually on a soft cloth to prevent scratches or other damages occurring to the parts.


We have taken great care in the design of this product and request that you carefully and strictly follow our assembly instructions to ensure a completed product as it was designed.

## Part List


**A.**  
**Side**  
1 pc.



**B.**  
**Side**  
1 pc.



**C.**  
**Seat**  
1 pc.



## Hardware List



**Key Wrench**  
1 pc.



**Small Hex Wrench**  
1 pc.



**Head Cap Bolt**  
8 pcs.(+1 extra)



**Spring Washer**  
8 pcs.(+2 extra)




**Flat Washer**  
8 pcs.(+1 extra)

For assembly also need the following:

### 88 5800 80 Cushion and Back



**88 5800 80\_**  
**E.**  
**Cushion**  
1 pc.



**88 5800 80\_**  
**D.**  
**Back**  
1 pc.

Tools recommended for assembly : Level

**Home Styles Consumer Assistance Line 888-680-7460 and 877-831-0319**  
**servicedesk@homestyles-furniture.com**



# Assembly Instructions

## IMPORTANT

- \* Do not tighten up all the bolts until each part is properly assembled.
- \* You should keep Hex Wrench in a safe place as you may need to tighten up the Head Cap Bolts in the future.
- \* After assembly, item must be level to work properly. Use the included adjustable levelers to level.
- \* Use a soft cloth between these parts and the floor.

## STEP 1

Attach Side (A) to Back (D) with Head Cap Bolts, Spring Washers and Flat Washers.





## STEP 2

Attach Seat (C) to unit with Head Cap Bolts, Spring Washers and Flat Washers.

## STEP 3

Attach Side (B) to unit with Head Cap Bolts, Spring Washers and Flat Washers.



## STEP 4

Turn the unit to its' upright position.

Place Cushion (E) onto unit.

To level the unit, adjust the adjustable levelers on the bottom of unit. (See figure 1)




Figure 1