
# **MASSAGE**

# **RECLINER**





## **UPC CODE:**

**MODEL No.:** 

0-65857-16252-3	Sand Microfiber
0-65857-16253-0	Taupe Microfiber
0-65857-16254-7	Black PU
0-65857-16255-4	Brown PU

### **NOTE:**

THIS INSTRUCTION BOOKLET **CONTAINS IMPORTANT SAFTEY** INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Lot number
(TAKEN FROM CARTON)

	Date of purchases	
/_	/	

#### DO NOT RETURN PRODUCT TO THE STORE.

If a part is missing or damaged, contact our customer service department. We will replace the part FREE of charge.



Tel #: 1-800-295-1980 E-Mail: das@dorel.com Fax #: 514-353-7819

#### **CUSTOMER SERVICE**

If you are missing parts or have any questions about this product, contact our customer service representative first!

**CALL 1-800-295-1980** 

You can also order parts by writing to the address listed below. Please include the product model number, color and a detailed description of the part.

Customer Service Department No. 413 12345 Albert-Hudon Boulevard, Suite 100 Montreal, Quebec Canada H1G 3L1

E-MAIL: das@dorel.com



## WARNING

**DO NOT** leave children unattended on or beside the recliner.

**DO NOT** use your recliner as a step stool.

**DO NOT** sit on the edge of the seat, armrests or on the backrest as this could make the recliner tip over.

The power unit is intended to be correctly orientated in a vertical or floor mount position.

## **NOTES**

- \* Ensure that all parts and components are located before beginning assemble.
- \* Assemble on soft surfaces to prevent damage to the product finish.
- \* Read all instructions before use of the recliner.
- \* **Do not** use the unit if it is damaged or broken.
- \* Caution: Adult assembly required.
- \* Assembly will require 2 people.
- \* Estimated assembly time: 5 minutes.

**NOTE:** This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and the receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

#### **CARE AND CLEANING**

Wipe away spills immediately to prevent staining. Use a cloth dampened with water or a professional product to clean the fabric. Always test an inconspicuous area first. Allow upholstery to dry and brush lightly. Keep away from heat to avoid glazing, melting or scorching.

#### **MAINTENANCE**

Check bolts/screws periodically and tighten them if necessary.

#### LIMITED WARRANTY


Dorel Asia warrants its product to be free from defects in material and workmanship and agrees to remedy any such defect. This warranty covers 1 year from the date of original purchase. This warranty is valid only upon presentation of proof of purchase. This is solely limited to the repair or replacement of defective furniture components and no assembly labor is included. This warranty does not apply to any product which has been improperly assembled, subjected to misuse or abuse or which has been altered or repaired in any way. The warranty does not cover the wearing, tearing or fading of the fabric. This warranty gives you specific legal rights and you may also have other rights which vary from State to State.



WARNING: Should this product become damaged, and/or components are broken or missing, DO NOT USE.

# MASSAGE RECLINER DA6248F-S/ DA6248F-DT / DA6248-BK / DA6248-BR

# **PARTS LIST**




# MASSAGE RECLINER

# DA6248F-S/ DA6248F-DT / DA6248-BK / DA6248-BR

# STEP 1

Attach back frame (A) to seat frame (B) by sliding the brackets on the back frame (A) into the brackets on the seat frame (B).

**NOTE:** Both sides should be inserted in the base at the same time. This step is best performed with 2 people.




# MASSAGE RECLINER DA6248F-S/ DA6248F-DT / DA6248-BK / DA6248-BR

## **STEP 2:**

Connect the wires from back rest (A) to seat frame (B) by linking white connectors. Connect the wires from seat frame (B) to power adapter (C) by linking the black connectors. Place the flap into position using the Velcro strips.

Plug adapter (C) into the electrical outlet.

This power unit is intended to be correctly orientated in a vertical or floor mount position.




### MASSAGE RECLINER

# DA6248F-S/ DA6248F-DT / DA6248-BK / DA6248-BR

### **Using the Remote Control**

- \* You must use the remote control to activate the massage function.
- \* The top switch will activate the massage function on the back frame (A), the lower switch will activate the seat frame (B).
- \* You can adjust the speed of the massage function by placing the switch in the LOW or HIGH position.
- \* Always make sure the massage function is in the OFF position when the recliner is not in use.



### DO NOT RETURN PRODUCT TO THE STORE.

If a part is missing or damaged, contact our customer service department. We will replace the part **FREE** of charge.



Tel #: 1-800-295-1980 E-Mail: das@dorel.com Fax #: 514-353-7819

# **Customer Service**

## PLEASE DO NOT RETURN THIS PRODUCT TO THE STORE

PLEASE CONTACT CUSTOMER SERVICE REPRESENTATIVES AT THE FOLLOWING NUMBERS SHOULD THERE BE ANY MISSING OR DEFECTIVE PART(S).

	Service Phone Number 1-800-295-1980 Service Fax Number 514-353-7819	Email: das@dorel.com
Request Date:		
Name:		
Shipping Address:		
Street & Number:		
City & State: Zip Code:		
Day Time Phone Number: (including area code)		
Date & Place of Purchase:		
	Part(s) description and quantity: (Please be sure to	o list model number or SKN number