

























ASSEMBLY INSTRUCTIONS
ITEM: FV21036
DES: BRIDGEPOINT 60" TV STAND





**If you have any questions about the product or assembly,
please call Wayfair.com at 1-877-929-3247.**

Detailed View





Parts List		Qty.	Hardware		Qty.
A		1	1		15
			2		15
B		1	3		28
			4		4
C		2	5		8
			6		12
D		1	7		2
			8		2
E		1	9		2
			10		1
F		4	11	 Sticker cover	16
			12		
G		1			
H		4			
J		2			


STEP 1




STEP 2



STEP 3



1




4PCS

2




4PCS

3




4PCS

STEP 4



1




4PCS

2




4PCS



3




4PCS


STEP 5




3		4PCS	4		4PCS
---	---	------	---	--	------



STEP 6



6		12PCS
---	---	-------

STEP 7





3		8PCS	5		8PCS
---	---	------	---	---	------

Adjust Glide


STEP 8




COMPLETED




Sticker cover	
11	 16PCS


STEP 9



7		2PCS	8		2PCS	9		2PCS
---	--	------	---	---	------	---	--	------

STEP 10



10		1PC
----	---	-----