

**CX1337S parsons dining chair -Black
bonded leather**


**CX1337S parsons dining chair -Red
bonded leather**

**CX1337S parsons dining chair -White
bonded leather**

Assembly Instructions



For assistance with assembly contact:
Wayfair Customer Service,
877-WAYFAIR (877-929-3247)
www.wayfair.com




PARSONS DINNING CHAIR

Parts List


Before beginning assembly, separate all parts and carefully study the parts diagrams below.
Review all parts and hardware before disposing of any packaging.
You may receive extra hardware with your unit.
Call Customer Service for missing hardware.

A **Quantity
of 1**




Back panel

B **Quantity
of 1**




Seat

C **Quantity
of 2**




Leg

1 **Quantity
of 6**




Short Bolt Ø 5/16*2"L

2 **Quantity
of 4**




Long Bolt Ø 5/16*3-3/4" L

3 **Quantity
of 6**




Flat Washer

4 **Quantity
of 10**



Spring Washer

5 **Quantity
of 1**



Allen Wrench

Care and Cleaning Instructions:

Please see care and cleaning label attached to bottom of chair seat.

For replacement parts or questions, please call Customer Service at 877-WAYFAIR (877-929-3247)

PARSONS DINNING CHAIR

Assembly Instructions




Figure 1

Unpack and lay parts on clean, padded surface like carpet or blanket. Check that you have all parts indicated on the front page.

Lift the Velcro strip from the bottom of the Seat (B).




Figure 2

Attach Seat (B) to Back Panel (A) with short bolts (1), spring washers (4) and flat washers (3). Tighten them by using Allen wrench (5) as shown in Figure 2.




Figure 3

Insert long bolts (2), flat washers (3) and spring washers (4) into seat (B) inner corner pre-drilled holes.

Tighten long bolts (2) using Allen wrench (6) as shown in Figure 3.

PARSONS DINNING CHAIR

Assembly Instructions




Figure 4

Attach the legs (C) to the seat (B) as shown in Figure 4.





Figure 5

Use short bolts (1) with flat washers (3) and spring wash (4) to connect legs (C) to seat (B).


Tighten short bolts (1) by using Allen wrench (5).



Close the Velcro strip from the bottom of the Seat (B)

PARSONS DINNING CHAIR

Assembly Instructions



Re-check all bolts are securely tightened.

Turn over the dining chair.

Now your dining chair is ready to use!

Figure 7