




Product Instructions for:
98240/98440 Adjustable Bar stool










98240/98440 Adjustable Bar stool

For assistance with assembly or questions contact:
Wayfair Customer Service, 877-WAYFAIR (877-929-3247) | www.wayfair.com

Before beginning assembly, separate all parts and carefully study the parts diagrams below. Review all parts and hardware before disposing of any packaging. You may receive extra hardware with your unit. Call Customer Service for missing hardware.





Parts List

<p>(1)x1</p> <p>Seat</p> 	<p>(5)x4</p> <p>Screws</p> 
<p>(2)x1</p> <p>Stand</p> 	<p>(6)x1</p> <p>Collar</p> 
<p>(3)x1</p> <p>Base</p> 	<p>(7)x1</p> <p>Allen key</p> 
<p>(4)x1</p> <p>Airilift</p> 	

For assistance with assembly or questions contact:
Wayfair Customer Service, 877-WAYFAIR (877-929-3247) | www.wayfair.com

Product Instructions for:

98240/98440



For assistance with assembly or questions contact:
Wayfair Customer Service, 877-WAYFAIR (877-929-3247) | www.wayfair.com