3pc Set

ASSEMBLY INSTRUCTION

MODEL : 10104 METROPOLITAN SQUARE DINING TABLE

Before you begin, Please follow Assembly Instruction carefully. Then follow them step by step

PART LIST		
A	TABLE TOP	1 PC
B	TABLE LEGS	4PCS
HARDWARE LIST		
C	HEX SCREW	8 PCS
D	FLAT WASHER	8 PCS
E	HEX WRENCH	1 PC
F	SPRING WASHER	8 PCS



IMPORTANT NOTE : PLACE ALL WOODEN PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
FIX THE TABLE LEGS(B) TO THE CORNER BLOCK WITH HEX SCREW (C) SPRING WASHER (F). AND FLAT WASHER (D).THEN TIGHTEN THE HEX SCREW(C) BY USING THE HEX WRENCH(E).



ASSEMBLY INSTRUCTIONS

MODEL : 10118 METROPOLITAN DINING CHAIR

IMPORTANT NOTE :

* PLACE ALL WOODEN PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
* BEFORE YOU BEGIN, KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.
* FOLLOW THE INSTRUCTRION CLOSELY, DO NOT TIGHTEN SCREWS / BOLTS UNLESS IS INSTRUCTED.
* AFTER FEW DAYS OF INITIAL ASSEMBLY, THE PRODUCT MAY HAS ACCLIMATED TO NEW ENVIRONMENT, PLEASE TIGHTEN ALL HARDWARE AGAIN.



HARDWARE LIST (FOR ONE CHAIR)

NO	DESCRIPTION	QTY
A	JCBC BOLT (LONG)	4 PCS
B	JCBC BOLT (SHORT)	10 PCS
C	SPRING WASHER	6 PCS
D	WOOD DOWEL	12 PCS
E	WOOD SCREW	4 PCS
F	JRN NUT	6 PCS
G	ALLEN KEY	1 PC
H	MINI SCREW DRIVER BIT	1 PC

PART LIST (FOR ONE CHAIR)

NO	DESCRIPTION	QTY
1	CHAIR BACK	1 PC
2	LEFT & RIGHT BACK LEG	2 PCS
3	LEFT & RIGHT FRONT LEG	2 PCS
4	SIDE RAIL	2 PCS
5	FRONT RAIL	1 PC
6	BACK RAIL	1 PC
7	CUSHION SEAT	1 PC

TOOLS REQUIRED (NOT PROVIDED) :



* DO NOT USE POWER TOOLS FOR ASSEMBLY

Step 1



ASSEMBLY INSTRUCTIONS

MODEL : 10118 METROPOLITAN DINING CHAIR

Step 2



Step 3



Step 4



Step 5



ASSEMBLY INSTRUCTIONS

MODEL : 10118 METROPOLITAN DINING CHAIR

Step 6



Step 7



Step 8



*INSERT THE SEAT BEFORE FULLY TIGHT UP

Step 9



FULLY SET UP